

# TRACERMATE II

## User Manual



providing world-class leak test and assembly verification solutions



## IMPORTANT INFORMATION

Information in this document is subject to change without notice and does not represent a commitment on the part of Cincinnati Test Systems, Inc. No part of the manual and/or software may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose, other than the purchaser's personal use, without the express permission of Cincinnati Test Systems, Inc.

No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, Cincinnati Test Systems, Inc. assumes no responsibility for errors or omissions.

Because of the variety of uses for this equipment and because of the differences between this solid-state equipment and electromechanical equipment, the user of and those responsible for applying this equipment must satisfy themselves as to the acceptability of each application and use of the equipment. In no event will Cincinnati Test Systems be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The illustrations, charts, and layout examples shown in this manual are intended solely to illustrate the text of this manual. Because of the many parameters and requirements associated with any particular installation, Cincinnati Test Systems cannot assume responsibility or liability for actual use based on the illustrative uses and applications.



**CAUTION** – When you see this warning symbol on the product, refer to the instruction manual for information before proceeding.



**CAUTION** – To avoid personal injury due to electric shock, disconnect all power services before servicing.

If this instrument is not used according to the instructions of this manual, the protection provided by this equipment design may be compromised.

© 2019 Cincinnati Test System



# Table of Contents

Chapter 1 – Introduction .....	12
Unpacking .....	12
Instrument Attachment & Clearance.....	12
Installation .....	12
User Interface Navigation .....	14
Menu Structure.....	17
Chapter 2 – Instrument Setup .....	18
Program Linking & Sequencing .....	18
Selecting Test Types.....	20
Test Type Table .....	21
Tooling Control .....	23
Programming the Inputs and Outputs.....	23
Channel Configuration .....	24
Setting the Units of Measure.....	24
Setting the Leak Standard Values.....	25
Program Configuration .....	26
Pressure Select .....	26
Selecting the Test Port .....	26
Setting the Pneumatic Regulator.....	26
Setting the Test Parameters .....	27
Verifying Setup .....	27
Security .....	27
Backup the Instrument Settings.....	27
Chapter 3 – Sniffer Test .....	28

Test Sequence Overview .....	29
Options Menu .....	30
Sniffer Menu: .....	32
Timers Menu: .....	34
Pressure Menu .....	37
Test Parameters – Evacuation Decay .....	38
Test Parameters – Gross T-Gas Decay & Tracer Leak Rate .....	39
Test Parameters – Fine T-Gas Decay & Tracer Leak Rate .....	40
Inputs .....	42
Outputs .....	42
Valve Outputs .....	44
Chapter 4 – Accumulation Test .....	44
Options Menu .....	46
Sniffer Menu: .....	47
Timers Menu: .....	49
Pressure Menu .....	52
Test Parameters – Evacuation Decay .....	53
Test Parameters – Gross Leak Decay & Tracer Leak Rate .....	54
Test Parameters – Fine Leak Decay & Tracer Leak Rate .....	55
Inputs .....	56
Outputs .....	57
Chapter 5 – Basic Hard Vacuum Test .....	59
Options Menu .....	60
Sniffer Menu: .....	61
Timers Menu: .....	63
Pressure Menu .....	65
Test Parameters – Evacuation Decay .....	66
Test Parameters – Gross T-Gas Decay & Tracer Leak Rate .....	67
Test Parameters – Fine T-Gas Decay & Tracer Leak Rate .....	68

Inputs .....	69
Outputs .....	70
Chapter 6 – Basic HV (Pre-charged) Test .....	71
Chapter 7 – Advanced Hard Vac Test .....	72
Test Description .....	72
Options Menu .....	73
Sniffer Menu: .....	75
Timers Menu: .....	77
Pressure Menu .....	80
Test Parameters – Evacuation Decay .....	81
Test Parameters – Gross Leak Decay & Tracer Leak Rate .....	82
Test Parameters – Fine Leak Decay & Tracer Leak Rate .....	83
Inputs .....	84
Outputs .....	85
Chapter 8 – Adv Hard Vac (Pre-charged) .....	87
Chapter 9 – Clean Part (Evac/Purge) .....	88
Options Menu .....	89
Timers Menu .....	90
Pressure Menu .....	91
Chapter 10 – Evac & Fill .....	92
Typical Graph Set for the Evac & Fill Test: .....	92
Options Menu .....	93
Timers Menu .....	94
Pressure Menu .....	95
Chapter 11 – Step to Proof Test .....	96
Options Menu .....	97
Timers Menu: .....	97
Pressure Menu .....	97
Chapter 12 – Refrigerant Fill Test .....	98

External Pneumatics: .....	99
Measured Weight Value: .....	100
Scale interface:.....	100
Manual Fill: .....	100
Test results:.....	101
Hold button operation: .....	101
Options Menu.....	102
Weight Menu.....	103
Timers Menu.....	104
Pressure Menu.....	106
Test Menu.....	106
Digital Outputs.....	107
Digital Inputs .....	107
Chapter 13 – Pressure Decay- $\Delta$ P Test .....	108
Timer Parameters .....	109
Pressure Parameters.....	110
Test Parameters .....	111
Chapter 14 – Pressure Decay-Leak Std Test .....	112
Timer Parameters .....	114
Pressure Parameters.....	115
Test Parameters .....	116
Program Calibration.....	118
Initiating the Program Cal Sequence .....	118
Calibration Parameters.....	120
Chapter 15 – Occlusion Test .....	121
Timer Parameters .....	122
Pressure Parameters.....	122
Test Parameters .....	123
Chapter 16 – Pressure Verify Test .....	124

Options Menu .....	124
Timer Parameters .....	124
Pressure Parameters.....	125
Test Parameters.....	126
Chapter 17 – Program Linking.....	127
Parent Program Linking .....	127
Rules for Parent Program Linking .....	128
Parent Program Linking Example.....	128
Link Execution Pause .....	130
Timer Parameters .....	131
Sequential Linking.....	132
Chapter 18 – Tooling Control.....	133
Advanced Tooling Control.....	135
Chapter 19 – Inputs and Outputs .....	138
Input and Output Connector Pinout.....	139
25 Pin Digital IO Cable Diagram and Pinout Table .....	141
Programmable Inputs and Outputs Menus .....	143
Output Timing Diagram .....	157
Tooling Example.....	158
Chapter 20 – Communication .....	169
RS232 Connector Pinout.....	169
Establishing RS232 Communication.....	169
Establishing Ethernet (TCP/IP) Communication via TELNET .....	170
Understanding the Header Information .....	172
Test Results via RS232 or Ethernet (TCP/IP) Communication .....	172
Streaming Measured Data .....	175
Parsing Data Packets.....	175
Reports.....	176
Chapter 21 – Security.....	177

Chapter 22 – Features.....	179
Selecting the Display User Level .....	179
Setting the Date & Time.....	179
Changing the Instrument Language.....	179
Copy & Paste Programs .....	180
Instrument Backup & Restore.....	180
Instrument Cloning .....	181
Adjusting the Light Bar Control.....	181
Open Internal Leak Standard .....	181
Selecting the Proper Internal Leak Standard .....	181
Self-Test .....	182
Update Firmware .....	183
Saving a Barcode with Results .....	183
Holding Pressure in the Part after Test (No Exhaust) .....	184
Changing the Functionality of the Prefill Timer .....	185
Turning On/Off Pressure Correction.....	185
Setting the Cal Method and Leak Standard Location .....	185
Auto Run .....	187
Chapter 23 – Instrument Calibration .....	188
Calibrating a Transducer .....	188
Transducer Cal 1 (Pressure) .....	188
Transducer Cal 3 (Hard Vacuum) .....	189
Verifying a Transducer .....	189
Calibrating an Electronic Regulator .....	191
Chapter 24– Webserver.....	192
System Requirements .....	192
Viewing the Web Server .....	192
Home Page.....	192
Web Server Login.....	194

Navigation - Web Server .....	195
Parameter Configuration via Web Server .....	199
Chapter 25– Monitor Screen Examples.....	200
Monitor Screen Examples .....	200
Chapter 26– Results Screen Examples.....	202
Result Data Screens .....	202
Appendix A – Messages & Error Codes.....	204
Appendix B - Environmental Drift Correction .....	216
How it works .....	216
Appendix C – Leak Detector Support.....	217
Inficon P3000 .....	218
Adixen ASM 142 / Adixen ASM 182T .....	220
Inficon ISH2000 / Adixen ASH2000 / Sensistor H2000 / Sensistor Sentrac .....	222
Agilent VS-MR15 .....	224
Inficon LDS2010 .....	225
Adixen ASI20 .....	227
Adixen ASI30 .....	229
Agilent PHD-4.....	230
Adixen ASI30 .....	<b>Error! Bookmark not defined.</b>
Agilent VS-C15.....	232
Inficon HLD5000.....	233
Licor LI-7000.....	235
Inficon LDS3000 .....	237
Oerlikon Leybold PhoeniXL300 .....	239
VIC MD-490S .....	241
Inficon E3000 .....	242
Ohaus 3000 .....	<b>Error! Bookmark not defined.</b>
Appendix E - Communication Code Tables .....	246
Data Type or Header Codes .....	246

Program Evaluation Codes.....	246
Test Evaluation Codes.....	247
Segment Codes .....	251
Variable Codes .....	255
Technical Specifications .....	270

# Chapter 1 – Introduction

*In this chapter you will be introduced to the basic pneumatic, electrical connections, and the simple menu structure and navigation of the instrument.*

Thank you for purchasing the TracerMate II™ charge system instrument. The TracerMate II is capable of testing using a variety of pre-packaged test algorithms designed to get you testing as quickly and easily as possible. Let's get started!

## Unpacking

Carefully remove the instrument from the shipping carton. Locate the Colder™ quick connect test port with Self-Test cap, and power cord supplied with the instrument. If this is not a standard instrument you may install any suitable plug fitting into the manifold test port. See the print series shipped with your instrument for the proper thread specifications.

## Instrument Attachment & Clearance

There are four (4) rear mounting holes for ¼ inch (6 mm) socket head cap screws, 3½ inches (90 mm) long (for a ¼ inch **minimum** mounting plate thickness). The instrument is supplied with four (4) ¼ inch – 28 x 3½ inch socket head cap screws for convenience.

Please allow 4 inches (100 mm) clearance under the instrument for installation of test line and for hand clearance.

## Installation

The leak test instrument is a modular, flexible instrument designed to operate in a manufacturing, clean room, or lab environment. To operate trouble-free, it requires:

- Clean, dry instrument air for test and pilot air (recommend 0.3 and 5.0-micron coalescing filter). ISO 8573-1, Class 2 filters are recommended, with class 3 being acceptable.
- Vacuum for vacuum test applications (unless the venturi option is configured)
- Supply power: 88-264 VAC 50/60 Hz auto sensing/switching electrical +/- 10% of nominal.
- I/O: Switch to select internal or external 24 VDC electrical power for the inputs and outputs

Because this is a precision instrument, it is preferable to locate this instrument at least 15 feet away from high electromagnetic energy devices (induction heat treat equipment and welders) whenever possible. In addition, plants having poor quality electrical power or ground systems should consider using isolation transformers on the power drops.

**Note: When supplying power, always be certain that there is nearly zero voltage ( $< 1\text{ V}$ ) difference between the neutral and earth ground wires connected to the instrument.**

## User Interface Navigation

There are multiple monitoring screens available for the instrument. Selecting the Monitor Icon will give you access to all these screens. This menu is also where the user selects to view the graphs available with the unit.



The instrument is designed with a simple graphical icon-based interface. The main menu is activated by pressing the Main Menu button.



The Arrow/Enter Selection buttons are used to navigate through the icons on the screen and select the appropriate menus. The center Enter arrow is also used to select parameters for editing and saving the edits once they are complete.



The Cancel/Back button is used go back to the previous menu. Multiple presses will eventually exit you out of the menu structure entirely and place you on the Monitor Screen. This button is also used to cancel out of any edits before saving.



The Information button is used to get a help screen that is associated the parameter corresponding to where the cursor is located.



The USB button allows a shortcut directly to the USB menu. The menu is located under the Main Menu -> Global Config -> USB menu.

*Note: With a USB memory stick located in the USB connection, holding this button down until it beeps will take a screen shot of the screen and save it to the USB memory stick. Do not remove the USB memory stick until the instrument tells you it is finished writing the image.*



The instrument can store up to 99 different programs. Switching between these programs is done with the Program Select Buttons on the front of the instrument. The current program is shown in the lower right-hand corner of the screen designated by “P” and then a two-digit number corresponding to the current program number.

*Hint: Holding down the “+” button for 2 seconds will prompt a screen to appear in which the value of the program may be entered using the arrow buttons. The up and down arrows will increment and decrement the ones digit. The right and left arrows will increment and decrement the tens digit.*




*Note: The Program may also be changed via Digital I/O (See [Chapter 19](#)), RS232 or TCP/IP Communication (See [Chapter 20](#)).*



## Menu Structure

Below is an overview of the menu structure for the TracerMate II instrument.

*Note: Not all menus are available for all configurations and Test Types.*



*NOTE: Viewing menus with Security enabled in the Misc menu above.*

## Chapter 2 – Instrument Setup

In this chapter, questions will be asked on how you intend for the instrument to function to conduct the test or sequence of tests for the application.

Setting up the instrument to meet specific application requirements is most effectively accomplished by answering these questions. They will guide you through the initial stages of the setup and point you to the appropriate chapters that detail specific instructions based on the answers.

It is highly recommended that each type of part being tested, whether they differ in volume or construction, have their own set of parameters defined in the instrument via individual Programs. Pressure decay leak testing is a volume dependent function. Flow testing can be setup to be volume independent; however, to optimize the testing, it is recommended that each type of part have its own set of parameters. In certain cases, it is possible to group “like parts” together to use the same parameters. In this case we recommend you talk to a CTS applications specialist to assure proper functionality.

### Program Linking & Sequencing

The instrument can support multiple tests on one part. The instrument is also able to conduct these tests on a part with multiple chambers by multiplexing through multiple test ports (if configured).

#### *Question:*

---

*Are you planning to conduct multiple tests on one part as described in either of the two examples in the paragraph above?*

**Yes:** It is important that you understand the concepts of Parent Program Linking. This test type is defined on the first page of Chapter 17. See [Chapter 17](#) and then come back and continue the setup.

**No: Proceed**

The instrument can conduct tests on multiple operations in a set sequence. The **Sequential Linking** test type may be used to test multiple unique parts, or tests may be run on the same chamber, or on different chambers in the part. The way that test results are reported and how tooling is controlled are not the same as the **Parent Program Linking** method.

*Question:*

---

*Are you planning to conduct tests on multiple unique parts as described above?*

**Yes:** It is important that you understand the concepts of Sequential Linking. This test type is defined on the last page of Chapter 17. See [Chapter 17](#) and then come back and continue the setup.

**No:** Proceed

## Selecting Test Types

The first step in setting up the instrument is to select the type of test you would like to conduct via the pre-packaged test sequences. Once you set up one type of test repeating this step under a different program will enable you to configure up to 99 different test configurations. The table on the following page includes the different test types available in the instrument, a brief description, and the associated chapter that details the pre-packaged test program. The availability of these test types is based on the configuration of the instrument.



Once you determine which test type is appropriate for your application go to Program 1 (press the + or – buttons until you see a P01 in the lower right-hand corner of the screen).



Press the Main Menu button to view the icons in the Main Menu screen.



Select Program Config icon using the Arrow/Enter Selection buttons.



Select the Test type icon using the Arrow/Enter Selection buttons.



Select the appropriate test type using the Enter button to enable editing and then the up and down arrows to view the options. When you see the desired selection press the Enter button to select.

To simplify the instructions in this manual, the steps above are reduced to the following: The **Test Type** menu is located in **Main Menu > Program Config > Tst type** icon.

## Test Type Table

TEST TYPE	DESCRIPTION
Sniffer <a href="#">Chapter 3</a>	Measures tracer gas concentration leaking from an external part (not in a chamber) at atmospheric pressure conditions, using a Sniffer Leak Test device, connected to the TracerMate II's RS232 port. The test may be performed in a manual, semi-auto, or automatic mode.
Accumulation <a href="#">Chapter 4</a>	Measures tracer gas concentration leaking from a part at atmospheric pressure conditions, in an enclosed hood or chamber using a Sniffer Leak Test device, connected to the TracerMate II's RS232 port.
Basic Hard Vac <a href="#">Chapter 5</a>	Measures the tracer gas leak concentration using Hard Vacuum chamber and a Tracer Gas Leak Test device. Chamber valve control is provided externally and coordinated through the leak detector interface to the TracerMate II. Parts are evacuated and filled by the TracerMate II.
Basic HV (Precharged) <a href="#">Chapter 6</a>	Measures the helium leak concentration using Hard Vacuum chamber and a Tracer Gas Leak Test device. Chamber valve control is provided externally and coordinated through the leak detector interface to the TracerMate II. Parts are not evacuated, just tested, because they are already PRECHARGED with tracer gas.
Advanced Hard Vac <a href="#">Chapter 7</a>	Measures the helium leak concentration using Hard Vacuum chamber and a Tracer Gas Leak Test device. Chamber valve control is provided by the TracerMate II. Parts are evacuated and filled by the TracerMate II.
Adv Hard Vac (Precharged) <a href="#">Chapter 8</a>	Measures the helium leak concentration using Hard Vacuum chamber and a Tracer Gas Leak Test device. Chamber valves control is provided by the TracerMate II. Parts are not evacuated, just tested, because they are already PRECHARGED with tracer gas
Clean Part <a href="#">Chapter 9</a>	Cleans Part by first evacuating, then simultaneously opening fill and exhaust valves flowing air or nitrogen through the part to purge tracer gas from the part.
Evac & Fill <a href="#">Chapter 10</a>	Provides a method for evacuating and back filling an external part (not in a chamber) with a tracer gas for testing later. Also serves as Nitrogen backfill prior to shipping.
Step Proof	Measures and monitors the Peak Pressure over a fixed time.

TEST TYPE	DESCRIPTION
<a href="#">Chapter 11</a>	Determined from the maximum pressure during test pressure steps and duration of the test timers. The result is presented in units of pressure.
Refrigerant Fill <a href="#">Chapter 12</a>	Provides a method for evacuating external part (not in a chamber) and backfilling with refrigerant to a specified weight, measured on a scale that is connected to the TracerMate II's RS232 port.
Pressure Decay- $\Delta P$ (Gross Decay- $\Delta P$ ) <a href="#">Chapter 13</a>	Measures the pressure loss ( $\Delta P$ ) over time, determined from the pressure loss over the duration of the Test timer. The result is presented in units of delta pressure.
Pressure Decay-Leak Std (Gross Decay-Leak Std) <a href="#">Chapter 14</a>	Calculates the Leak Rate, based on the pressure loss over the duration of the Test timer. The result is presented in units of flow.
Occlusion <a href="#">Chapter 15</a>	Measures the Back Pressure (part blockage), determined from the pressure at the end of the test timer. The result is presented in units of pressure.
Pressure Verify <a href="#">Chapter 16</a>	Measures the Pressure at the isolated test port (no fill). Determined from the pressure at the end of the Test segment timer. The result is presented in units of pressure.
Parent Program Linking <a href="#">Chapter 17</a>	Facilitates linking individual programs into a single test sequence for conducting multiple tests on one part or one part with multiple chambers. Contains tooling control parameters and link definitions. Each link defines the target program to execute and evaluation conditions for additional program execution.
Sequential Linking <a href="#">Chapter 17</a>	Facilitates linking individual programs into a single test sequence to test multiple parts sequentially. Each link defines the target program and the next program to execute and evaluation conditions for additional program execution. Tooling control parameters are defined in the linked programs.

Before we begin setting the parameters of the program, we need to determine some of the capabilities and features that are required for the leak test application.

## Tooling Control

The instrument is capable of controlling tooling to potentially eliminate the need for a PLC or other computer that would control cylinders and sealing.

### *Question:*

---

*Are you planning to use the TracerMate II to control any sealing operations?*

**Yes:** It is important that you understand the concepts and safety requirements of Tooling Control. See [Chapter 18](#) then come back and continue the setup.

**No: Proceed**

## Programming the Inputs and Outputs

The instrument comes with 12 inputs and 12 outputs (24VDC) that are user configurable for each program.

### *Question:*

---

*Are you planning to use the TracerMate II to control any ancillary devices or communicate with a PLC using discrete I/O?*

**Yes:** See [Chapter 19](#) and then come back and continue the setup.

**No: Proceed**

## Channel Configuration

### Setting the Units of Measure

The instrument has the capability to utilize different units of measure for each configured program. In order to keep things simple and user friendly if you always use the same unit of measure, you can set the units in one place and have them apply instrument wide. This is done in the Channel Configuration menu.

#### *Question:*

---

*Are you planning to use the same units of measure for every program?*

**Yes:** Press the Main Menu button. Select the Channel Config Icon. From the Channel Config menu select the Units Icon. Change the Unit/Prec Define parameter to “Channel”. Set the desired units on that same screen. These units will apply to every program.

**No:** Press the Main Menu button. Select the Channel Config Icon. From the Channel Config menu select the Units Icon. Change the Unit/Prec Define parameter to “Program”. The Unit Icon will now appear under the Program Config menu. When a program is created, the units for the program will use the units under the Channel Config menu as the default settings but can now be changed per program.

*Note: The units set on the Channel Config screen are also the units used for Self-Test and Set/Span Routines.*

*Note: The precision displayed for each unit may also be set on this screen.*

## Setting the Leak Standard Values

The instrument has the capability to utilize different leak standards for each configured program that uses a leak standard. In order to keep things simple and user friendly if you always use the same leak standard, you can set the leak standard value and pressure in one place and have it applied instrument wide to any program that uses a leak standard. This is done in the Channel Configuration menu.

### *Question:*

---

*Are you planning to use the same leak standard for every program that requires a leak standard?*

**Yes:** Press the Main Menu button. Select the Channel Config Icon. From the Channel Config menu select the Leak/Cal Icon. Change the Leak Std/Cal Define parameter to “Channel”. Set the leak standard value and the pressure at which it was calibrated on that same screen. This leak standard value will apply to every program that utilizes a leak standard for calibration.

**No:** Press the Main Menu button. Select the Channel Config Icon. From the Channel Config menu select the Leak/Cal Icon. Change the Leak Std/Cal Define parameter to “Program”. The leak standard parameters will now appear on the TST:\*\*\* screen under the Program Config menu. When a program is created, the units for the program will use the leak standard value under the Channel Config menu as the default settings but now can be changed per program.

*Note: Every time the leak standard value changes due to a calibration or when a new leak standard is used this value needs to be modified to reflect the new value.*

*Note: The parameter that determines whether the physical leak standard is located either inside the instrument or connected to a port on the outside is also located in the Leak/Cal Menu or the TST menu. However, to view this parameter you must be in the “Advanced” or “Admin” Display User Level. To change the Display User Level, see [Chapter 22 “Features”](#).*



*Remember: Press the information button with the cursor on a parameter if you need help or a description of the available options.*

## Program Configuration

Now that you have created a program, configured the tooling and associated I/O, and set the channel level parameters, it is time to set the regulators to the correct test pressure.

### Pressure Select

To select the proper source for the test, we need to inform the instrument which regulator to use for the current program. For the Pressure Decay test types, this setting is in the **Program Config > Misc** menu. The parameter called Pressure Source will need to be set to match the proper regulator. For the Sniffer test types, the Pressure/Vacuum source options are found in the **Program Config > Options** menu. Find the regulator with the proper range. Locate the label that has the Source Number on it and select that source for the Pressure Source parameter.

### Selecting the Test Port

Next, select the proper test port (if required).

#### *Question:*

---

*Does your instrument have multiple test ports (optional configuration)?*

**Yes:** from the same Program Config - Misc menu select the Test Port Number you would like to conduct the test on. The port numbers will count upwards from left to right.

**No:** Proceed

## Setting the Pneumatic Regulator

### *Question:*

---

*Does the pressure source you are using for this program have an electronic regulator?*

**Yes:** The electronic regulator has been setup and calibrated at the factory and will be ready to use. For calibrating the electronic regulator see [Chapter 23](#).

**No:** Setting the regulator is done via the Channel Config screen under the Set/Span menu. In order to set the regulator, the test port will need to be blocked which will allow the instrument to hold pressure. Standard instruments are supplied with a quick connect Colder<sup>TM</sup> fitting with an attached “Self-Test cap” for ease at startup. If this instrument is not a standard setup this may be done with a plug inserted into the test port. For proper plug thread specifications, consult the print set shipped with your instrument.

### **Setting the Test Parameters**

It is time to set the test parameters to fit your application. Refer to the chapter associated with the test type chosen from [TABLE 1 – TEST TYPES](#), on pages 10-11.

### **Verifying Setup**

Once you have everything programmed, run a repeatability study based on your company’s quality standards to assure you are getting the results you desire.

### **Security**


Now that the instrument is setup the way you want, make sure to lock down the parameters that you don’t want changed until a key or password is used. See Security parameters in [Chapter 21](#).

### **Backup the Instrument Settings**

The setup of the instrument for one program is completed. You may now go back and setup multiple programs. Once you have completed setting up programs, it is highly recommended that you create a backup of the instrument. This can be done with a USB memory stick. See Instrument Backup and Restore in [Chapter 20](#).

## Chapter 3 – Sniffer Test

*This chapter explains the theory and parameters for conducting a sniffer test. The TracerMate II controls evacuation and tracer gas fill of the part and communicates with a variety of external sniffer devices. The result of this test can include test results for: Vacuum Decay tests, Gross T-Gas Leak and Fine T-Gas Leak pressure decay tests, Sniffer Test tracer gas leak rate values for individual test points, and cumulative tracer gas Leak values measured with the Sniffer during the Gross T-Gas Leak test and Fine T-Gas Leak test segments (if those test were run).*



## Test Sequence Overview

The following is a brief overview of the test sequence using a helium sniffer.

- **Tooling** – Optional tool motion before start of test.
- **Vacuum and Vacuum Decay** – Evacuate and test the part using a vacuum source and test for gross leaks, as well as prepare the part for charging with helium. The vacuum decay test can also be useful to avoid contamination of the test environment with excessive helium if the test part has a gross leak.
- **Charge with Helium** – Pressurize the part with Helium. If both Air and Helium sources are available, a configurable percentage mix of He/Air can also be used for testing.
- **Sniffer Leak Test** – The operator will be prompted to begin testing the part with the RS232 sniffer probe, while also continuing to monitor for unexpected pressure loss. The operator manually signals the completion of the test, or the test ends with an alarm/alert after a configurable timeout period.
- **Evacuate Helium** – Remove helium from part. If a recovery system is available, internal or external valves can be manipulated to route the helium to the recovery system.
- **Tooling** – Optional tool motion at completion of test.
- **Report** – The Test Result is recorded with an overall ACCEPT/REJECT evaluation and includes multiple Pass/Fail/Skipped results depending on the test option settings. The Vacuum Decay, Gross T-Gas Decay and Fine T-Gas Decay tests all report Pass/Fail/Skipped with measured part pressure and tracer gas pressure loss values. The Sniffer Test reports Test Point Number and Measured T-Gas Leak Rate for each test point as well as cumulative Sniffer leak rates measured during the Gross T-Gas Leak test and Fine T-Gas Leak test segments (if they were run).

Using the configuration options, tests can be created to provide:

- Basic evacuate & fill testing (without communication with the external Sniffer device)
- Advanced testing (with external Sniffer communication)
- Gross T-Gas Decay testing, Fine T-Gas Decay testing
- Clamshell testing

## Options Menu

The options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
External Sniffer	Enable/disable communication with external Sniffer Leak Test Device on RS232 port.	Advanced, Admin
Clamshell	Enable/disable Clamshell outputs during Sniffer Test.	Advanced, Admin
Test Mode	Defines the Sniffer Test mode. Auto, Semi-Auto, Inficon Normal, Inficon I-Guide, Manual.	Basic Advanced, Admin
Sample Points	Number of test points measured during the test. This parameter is hidden in some test modes.	Basic Advanced, Admin
Part Evacuation	Enable/disable evacuation of the part before filling with T-Gas. Options are: Disabled, Enabled, or Evac to Press.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Evacuation Xdcr	Transducer that will be used to measure evacuation pressure.	Advanced, Admin
Vacuum Decay	Enables vacuum decay test prior to tracer fill.	Advanced, Admin
Re-Evac After Test	Allows re-evacuation of part after Sniffer Test completion. If enabled, Exhaust/Re-Evac timer is available before the Exhaust timer.	Advanced, Admin
Close Inner Purge	Allows the Inner Purge Ring to be closed before the start of the Tracer Gas Fill segment. This option is available in Clamshell mode.	Advanced, Admin
T-Gas Source	Specifies the manifold pressure source to utilize for the Sniff Test Tracer pressure. The T-Gas Source must be specified even if the T-Gas Fill option is Disabled.	Advanced, Admin
Gross T-Gas Fill	Fill method for the Gross T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Gross Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Gross T-Gas Decay	Enables Gross Leak Decay Test during sniffer test.	Advanced, Admin

Option	Description	User Display Mode
Fine T-Gas Fill	Fill method for the Fine T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Fine Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure). Continuous Fill (t-gas fill valve remains open through end of test segment)	Advanced, Admin
Fine T-Gas Decay	Enables Fine Leak Decay Test during sniffer test.	Advanced, Admin
T-Gas Recovery	Specify method used to remove tracer gas from the part after a test. Options are: Fixed Timer or Exh to Press.	Advanced, Admin

## Sniffer Menu:

The Sniffer specific options for the program may be viewed by going to the Program Config menu and selecting the Sniffer Icon.

Option	Description	User Display Mode
Part Sniffer Type	Sniffer Type used by this part program.	Viewable in Basic & Advanced Editable in Admin
Sniffer Init	Defines when sniffer initialization is performed. Options are before or after part evacuation and fill.	Advanced, Admin
T-Gas Sampling	Specifies result reporting method for measured leak rate. Average reports the average leak rate measurement during the sample period. Peak reports the highest leak rate measurement during sample period.	Advanced, Admin
Sample Gas Number	Sample Gas ID number to be used by the sniffer device. This parameter is hidden if not available on the active leak detector.	Advanced, Admin
Device Zero	If enabled, forces the leak detector to set its Zero level at the end of the Cleanup segment. This parameter is available for use with the Inficon P3000 leak detector.	Advanced, Admin
Autozero Enable	Internal Autozero function. The T-Gas leak rate measurement at the end of the Autozero Delay timer will be applied as a zero offset to reported leak rate measurements during the testing cycle. This option is available in Clamshell mode.	Advanced, Admin
Min T-Gas Mode	Mode for checking Minimum T-Gas leak rate. Continuous: Leak rate must achieve and maintain setpoint. One-Time: Leak rate must achieve but need not maintain setpoint. Disabled: No minimum setpoint.	Advanced, Admin

Option	Description	User Display Mode
LD Min T-Gas Setpt	Minimum Tracer Gas leak rate that must be measured for a valid test. If the measured sniffer leak rate is below this value, a Tracer Min Fault is generated.	Advanced, Admin
LD Background Limit	Maximum Tracer Gas background level allowed prior to starting a Test. If the sniffer reports a tracer level exceeding this value, a Tracer Background Fault is generated.	Advanced, Admin
Cleanup Setpoint	Leak rate setpoint for the Chamber Cleanup Fault. Part will not be charged with tracer gas if exceeds this limit.	Advanced, Admin
Device Mode	Sniffer Device testing mode option. Some leak detectors operate in multiple modes (i.e. Sniff Mode, Accumulation mode, HardVac Mode). This parameter specifies which mode should be used. Hidden for single mode leak detectors.	Advanced, Admin

## Timers Menu:

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Sniff Init	Maximum time allowed for establishing communication with the leak detector and completing the device's initialization. When the device indicates it is ready for testing, any remaining time is aborted, and the test sequence continues. If this timer expires before the device has reached a ready state, a Sniffer Not Ready fault is generated.	Advanced, Admin
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
Continue to Evac	Available if Part Evac is set to Evac to Press. Time to continue to fill after target vacuum is achieved.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure source.	Basic Advanced, Admin
Evac Decay 1	Timer for the Evacuation decay test.	Basic Advanced, Admin
Purge Off	Delay time from the end of the evacuation sequence before closing the Inner Purge valve or output. This parameter is hidden if the Clamshell option is Disabled or if the Close Inner Purge option is No.	Advanced, Admin
Cleanup	Maximum time allowed for the measured leak rate from the sniffer to fall below the Chamber Clean Setpoint. Remaining time is aborted once the setpoint is reached.	Basic Advanced, Admin
Auto-Zero Delay	Delay time for taking the T-Gas leak rate measurement to be used for Auto-Zero from the leak detector. Delay begins when the Chamber Cleanup Setpoint is achieved.	Advanced, Admin

Timer	Description	User Display Mode
Dev Zero Delay	Delay time before sending the Device ZERO command to leak detector. Available on Inficon P3000.	Advanced, Admin
Gross Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Gross Fill	Time allocated to reach the specified Gross T-Gas Target Pressure. The source valve is pulsed open once per second for the time specified by the Gross Fill Pulse parameter.	Basic Advanced, Admin
Gross Fill Pulse	Length of time per second to open the T-Gas pressure source valve while adding pressure during Gross T-Gas Fill.	Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to the Stabilize segment for execution before continuing.	Basic Advanced, Admin
Gross Wait #	Delay timer before beginning the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Gross Sample #	Length of the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Fill	Time allocated to reach the specified Fine T-Gas Target Pressure.	Basic Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to the Stabilize segment for execution before continuing.	Basic Advanced, Admin
Fine Wait #	Delay timer before beginning the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Fine T-Gas Sample #	Length of the sampling period at a leak rate measurement point.	Basic Advanced, Admin

Timer	Description	User Display Mode
T-Gas Exh	Time allocated to recovering Tracer Gas from the part after a test. During this time the Reclaim valve is opened. This timer is only present if the Reclaim Valve is defined and the T-Gas Recovery option is set to reclaim.	Basic Advanced, Admin
Continue T-Gas Exh	Available if Recovery is set to Exh to Press. The testing cycle jumps to this timer when part pressure falls below T-Gas Exh Press setpoint.	Basic Advanced, Admin
Exh/Re-Evac	Time allocated to exhaust and re-evacuate the part after a test. This timer is present if the Re-Evacuate After Test option is Yes. The part is first exhausted, and Re-Evacuation will not begin until the part reached a safe pressure. Timer must be long enough to accommodate both.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Advanced, Admin
Gross T-Gas Min	Minimum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Gross T-Gas Target	Target pressure for Tracer Gas Gross T-Gas Fill and Test.	Basic Advanced, Admin
Gross T-Gas Max	Maximum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Min	Minimum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Target	Tracer Gas target pressure that is to be achieved. Setpoint for Sniff Test Tracer Fill.	Basic Advanced, Admin
Fine T-Gas Max	Maximum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
T-Gas Exh Press	Available if Recovery is set to Exh to Press. As this setpoint is crossed, the testing cycle jumps to the Continue T-Gas Exh timer.	Basic Advanced, Admin

## Test Parameters – Evacuation Decay

The Test parameters for the Evacuation Decay test program may be viewed and modified by going to the Program Config menu and selecting the TST:SVD1 Icon. This icon and test menu will be hidden if the Evacuation Decay test is disabled.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Gross T-Gas Decay & Tracer Leak Rate

The Test Parameters for the Gross T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNG2 Icon. This icon and test menu will be hidden if the Gross T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1-20	High limit T-Gas Leak Rate for the sniffer test for each of 1-20 individual test points.	Basic Advanced, Admin
Reject Rate Total	High limit T-Gas Leak Cumulative Rate. This value is the limit for total measured leak rate across all configured test points.	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Fine T-Gas Decay & Tracer Leak Rate

The Test Parameters for the Fine T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNF2 Icon. This icon and test menu will be hidden if the Fine T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1-20	High limit T-Gas Leak Rate for the sniffer test for each of 1-20 individual test points.	Basic Advanced, Admin
Reject Rate Total	High limit T-Gas Leak Cumulative Rate. This value is the limit for total measured leak rate across all configured test points.	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit



## Inputs

Input	Description	Functional Group
Sniffer Ready	The Sniffer Ready input is used to coordinate sharing of a single leak detector between two TracerMate instruments. If the input is defined for a test, the program will wait during the sniffer initialization segment for the input to go high before attempting to communicate with the leak detector. Once active, the input must remain high until the end of the initialization segment or a Sniffer Ready Input fault will be generated.	Sniffer Control Group
Sniffer Present	When the Sniffer Present input is defined, a fault will be generated if the input is not active at any time during the test cycle where tracer gas measurements are expected.	Sniffer Control Group
Ext Press Sw 1-2	External Pressure Switch inputs for the Evac(1) and Tracer(2) sources. If defined, this input must go high before the end of the Fill segment or an ERR EXT SW fault will be generated.	Test Control Group
Clamshell Flow 1-5	The Clamshell Flow inputs are used to verify purge flow during a clamshell test. The flow input numbers correspond to the test point numbers during the test. If the input is no active during the test point measurement cycle a fault is generated.	Test Control Group

## Outputs

Output	Description	Functional Group
Ready To Sniff	The Ready To Sniff output goes high after the part has been charged with tracer gas and is ready for testing with the leak detector.	Sniffer Control Group
In Sample 1-5	The In Sample output goes high at the beginning of each sample period returns low at the end of each sample period.	Sniffer Result Group
Sample Accept	The Sample Accept output goes high at the end of each sample period if the evaluated value for measured leak rate is less than the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will	Sniffer Result Group

Output	Description	Functional Group
	remain active until the start of a new test.	
Sample Reject	The Sample Reject output goes high at the end of each sample period if the evaluated value for measured leak rate exceeds the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sniffer Busy	The Sniffer Busy output is used to coordinate sharing of a single leak detector between two TracerMate instruments. It goes high at the start of the initialization segment and remains high until communication with the sniffer is completed at the end of the test sequence. This output can be used to control an external interface to provide switching of the RS232 link between the TracerMate and leak detector. The Sniffer Ready input is used as feedback to the TracerMate instruments to indicate which has connection to the leak detector.	Sniffer Control Group
T-Gas Leak Std	The T-Gas Calibration output is turned on to control an external calibrated leak for use in leak detector calibration. It goes high during the Sniffer tests when the Run Leak Calibrate option is Enabled.	Chamber Control Group
Inner Purge Ring	The Inner Purge Ring output is used during the Sniffer Test Type when the Clamshell option is Enabled. It goes high at the start of a sequence. If Close Inner Purge option is Yes, it goes low at the start of the Cleanup segment. If Close Inner Purge option is No, it remains high until the end of the test sequence.	Chamber Control Group
Outer Purge Ring	The Outer Purge Ring output is used during the Sniffer Test Type when the Clamshell option is Enabled. It goes high at the start of a sequence and remains high until the end of the test sequence.	Chamber Control Group
In Recover	The In Recover output is high during the Tracer Gas Recovery segment.	Test Cycle Group
In Re-evac	The In Re-Evac output is high during the Tracer Gas Re-Evacuation segment.	Test Cycle Group

Output	Description	Functional Group
Sample Fault	This output is active during a sniffer test manual cycle whenever the light ring is flashing red to indicate a leak rate reading above the Reject Setpoint.	Sniffer Control Group

## Valve Outputs



The following optional valves are supported by this test:

- Reclaim Valve
- T-Gas Calibration
- Inner Purge Ring
- Outer Purge Ring

## Chapter 4 – Accumulation Test

*While similar to the Sniffer Test Type it also provides additional outputs to control an accumulation chamber. Outputs configured as either digital outputs or valve outputs are provided for an Inlet Blower, Outlet Blower, and a Circulation Fan. Variables on the Timer Menu control output on/off times and delays.*

The Test Result is recorded with an overall ACCEPT/REJECT evaluation and includes multiple Pass/Fail/Skipped results depending on the test option settings. Evacuation, Gross and Fine Decay tests report Pass/Fail/Skipped with Measured Pressure and Pressure Loss. Sniffer Tests report Measured T-Gas Leak Rate.



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before filling with T-Gas. Options are: Disabled, Enabled, or Evac to Press.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Evacuation Xdcr	Transducer that will be used to measure evacuation pressure.	Advanced, Admin
Vacuum Decay	Enables vacuum decay test prior to tracer fill.	Advanced, Admin
Re-Evac After Test	Allows re-evacuation of part after Sniffer Test completion. If enabled, Exhaust/Re-Evac timer is available before the Exhaust timer.	Advanced, Admin
T-Gas Source	Specifies the manifold pressure source to utilize for the Sniff Test Tracer pressure. The T-Gas Source must be specified even if the T-Gas Fill option is Disabled.	Advanced, Admin
Gross T-Gas Fill	Fill method for the Gross T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Gross Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Gross T-Gas Decay	Enables Gross Leak Decay Test during sniffer test.	Advanced, Admin
Fine T-Gas Fill	Fill method for the Fine T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Fine Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Fine T-Gas Decay	Enables Fine Leak Decay Test during sniffer test.	Advanced, Admin
T-Gas Recovery	Specify method used to remove tracer gas from the part after a test. Options are: Fixed Timer or Exh to Press.	Advanced, Admin

## Sniffer Menu:

The Sniffer specific options for the program may be viewed by going to the Program Config menu and selecting the Sniffer Icon.

Option	Description	User Display Mode
Part Sniffer Type	Sniffer Type used by this part program.	Viewable in Basic & Advanced Editable in Admin
Sniffer Init	Defines when sniffer initialization is performed. Options are before or after part evacuation and fill.	Advanced, Admin
T-Gas Sampling	Specifies result reporting method for measured leak rate. Average reports the average leak rate measurement during the sample period. Peak reports the highest leak rate measurement during sample period.	Advanced, Admin
Sample Gas Number	Sample Gas ID number to be used by the sniffer device. This parameter is hidden if not available on the active leak detector.	Advanced, Admin
Device Zero	If enabled, forces the leak detector to set its Zero level at the end of the Cleanup segment. This parameter is available for use with the Inficon P3000 leak detector.	Advanced, Admin
Autozero Enable	Internal Autozero function. The T-Gas leak rate measurement at the end of the Autozero Delay timer will be applied as a zero offset to reported leak rate measurements during the testing cycle. This option is available in Clamshell mode.	Advanced, Admin
Min T-Gas Mode	Mode for checking Minimum T-Gas leak rate. Continuous: Leak rate must achieve and maintain setpoint. One-Time: Leak rate must achieve but need not maintain setpoint. Disabled: No minimum setpoint.	Advanced, Admin
LD Min T-Gas Setpt	Minimum Tracer Gas leak rate that must be measured for a valid test. If the measured sniffer leak rate is below this value, a Tracer Min Fault is generated.	Advanced, Admin

Option	Description	User Display Mode
LD Background Limit	Maximum Tracer Gas background level allowed prior to starting a Test. If the sniffer reports a tracer level exceeding this value, a Tracer Background Fault is generated.	Advanced, Admin
Cleanup Setpoint	Leak rate setpoint for the Chamber Cleanup Fault. Part will not be charged with tracer gas if exceeds this limit.	Advanced, Admin
Device Mode	Sniffer Device testing mode option. Some leak detectors operate in multiple modes (i.e. Sniff Mode, Accumulation mode, HardVac Mode). This parameter specifies which mode should be used. Hidden for single mode leak detectors.	Advanced, Admin

## Timers Menu:

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Sniff Init	Maximum time allowed for establishing communication with the leak detector and completing the device's initialization. When the device indicates it is ready for testing, any remaining time is aborted, and the test sequence continues. If this timer expires before the device has reached a ready state, a Sniffer Not Ready fault is generated.	Advanced, Admin
Inlet On 1	Time delay after turning on the accumulation chamber Inlet output.	Advanced, Admin
Outlet On 1	Time delay after turning on the accumulation chamber Outlet output.	Advanced, Admin
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
Continue to Evac	Available if Part Evac is set to Evac to Press. Time to continue to fill after target vacuum is achieved.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure source.	Basic Advanced, Admin
Evac Decay 1	Timer for the Evacuation decay test.	Basic Advanced, Admin
Inlet Off	Time delay after turning off the accumulation chamber Inlet output.	Advanced, Admin
Outlet Off	Time delay after turning off the accumulation chamber Outlet output.	Advanced, Admin
Cleanup	Maximum time allowed for the measured leak rate from the sniffer to fall below the Chamber Clean Setpoint. Remaining time is aborted once the setpoint is reached.	Basic Advanced, Admin
Dev Zero Delay	Delay time before sending the Device ZERO command to leak detector. Available on Inficon P3000.	Advanced, Admin

Timer	Description	User Display Mode
Gross Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Gross Fill	Time allocated to reach the specified Gross T-Gas Target Pressure. The source valve is pulsed open once per second for the time specified by the Gross Fill Pulse parameter.	Basic Advanced, Admin
Gross Fill Pulse	Length of time per second to open the T-Gas pressure source valve while adding pressure during Gross T-Gas Fill.	Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Gross Wait	Delay timer before beginning the gross leak rate measurement sample.	Basic Advanced, Admin
Gross Sample	Length of the gross leak rate measurement period.	Basic Advanced, Admin
Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Fill	Time allocated to reach the specified Fine T-Gas Target Pressure.	Basic Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Fine Wait	Delay timer before beginning the fine leak rate measurement sample.	Basic Advanced, Admin
Fine T-Gas Sample	Length of the fine leak rate measurement period.	Basic Advanced, Admin
T-Gas Exh	Time allocated to recovering Tracer Gas from the part after a test. During this time the Reclaim valve is opened. This timer is only present if the Reclaim Valve is defined and the T-Gas Recovery option is set to Reclaim.	Basic Advanced, Admin

Timer	Description	User Display Mode
Continue T-Gas Exh	Available if Recovery is set to Exh to Press. The testing cycle jumps to this timer when part pressure falls below T-Gas Exh Press setpoint.	Basic Advanced, Admin
Inlet On 2	Time delay after turning on the accumulation chamber Inlet output.	Advanced, Admin
Outlet On 2	Time delay after turning on the accumulation chamber Outlet output.	Advanced, Admin
Exhaust/Re-Evac	Time allocated to exhaust and re-evacuate the part after a test. This timer is present if the Re-Evacuate After Test option is Yes. The part is first exhausted, and Re-Evacuation will not begin until the part reached a safe pressure. Timer must be long enough to accommodate both.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Advanced, Admin
Gross T-Gas Min	Minimum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Gross T-Gas Target	Target pressure for Tracer Gas Gross T-Gas Fill and Test.	Basic Advanced, Admin
Gross T-Gas Max	Maximum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Min	Minimum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Target	Tracer Gas target pressure that is to be achieved. Setpoint for Sniff Test Tracer Fill.	Basic Advanced, Admin
Fine T-Gas Max	Maximum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
T-Gas Exh Press	Available if Recovery is set to Exh to Press. As this setpoint is crossed, the testing cycle jumps to the Continue T-Gas Exh timer.	Basic Advanced, Admin

## Test Parameters – Evacuation Decay

The Test parameters for the Evacuation Decay test program may be viewed and modified by going to the Program Config menu and selecting the TST:SVD1 Icon. This icon and test menu will be hidden if the Evacuation Decay test is disabled.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Gross Leak Decay & Tracer Leak Rate

The Test Parameters for the Gross T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNG2 Icon. This icon and test menu will be hidden if the Gross T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status..	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1-20	High limit T-Gas Leak Rate for the sniffer test for each of 1-20 individual test points.	Basic Advanced, Admin
Reject Rate Total	High limit T-Gas Leak Cumulative Rate. This value is the limit for total measured leak rate across all configured test points.	Basic Advanced, Admin
Reject on Slope	Enables monitoring of the tracer leak rate slope during the sample timer.	Basic Advanced, Admin
Slope Window	Time period at the end of the sample timer where the slope of tracer leak rate is calculated.	Basic Advanced, Admin
Slope Change/Sec	Reject if the change per second in tracer leak rate exceeds this value.	Basic Advanced, Admin
Permit Early Reject	If enabled, the test monitors the leak rate slope throughout the sample timer and rejects early leak rate of change exceeds the configured value.	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit

F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Fine Leak Decay & Tracer Leak Rate

The Test Parameters for the Fine T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNF2 Icon. This icon and test menu will be hidden if the Fine T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1-20	High limit T-Gas Leak Rate for the sniffer test for each of 1-20 individual test points.	Basic Advanced, Admin
Reject Rate Total	High limit T-Gas Leak Cumulative Rate. This value is the limit for total measured leak rate across all configured test points.	Basic Advanced, Admin
Reject on Slope	Enables monitoring of the tracer leak rate slope during the sample timer.	Basic Advanced, Admin
Slope Window	Time period at the end of the sample timer where the slope of tracer leak rate is calculated.	Basic Advanced, Admin
Slope Change/Sec	Reject if the change per second in tracer leak rate exceeds this value.	Basic Advanced, Admin
Permit Early Reject	If enabled, the test monitors the leak rate slope throughout the sample timer and rejects early leak rate of change exceeds the configured value.	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Inputs

Input	Description	Functional Group
Sniffer Ready	The Sniffer Ready input is used to coordinate sharing of a single leak detector between two TracerMate instruments. If the input is defined for a test, the program will wait during the sniffer initialization segment for the input to go high before attempting to communicate with the leak detector. Once active, the input must remain high until the end of the initialization segment or a Sniffer Ready Input fault will be generated.	Sniffer Control Group
Sniffer Present	When the Sniffer Present input is defined, a fault will be generated if the input is not active at any time during the test cycle where tracer gas measurements are expected.	Sniffer Control Group
Ext Press Sw 1-2	External Pressure Switch inputs for the Evac(1) and Tracer(2) sources. If defined, this input must go high before the end of the Fill segment or an ERR EXT SW fault will be generated.	Test Control Group

## Outputs

Output	Description	Functional Group
Ready To Sniff	The Ready To Sniff output goes high after the part has been charged with tracer gas and is ready for testing with the leak detector.	Sniffer Control Group
In Sample	The In Sample output goes high at the beginning of each sample period returns low at the end of each sample period.	Sniffer Result Group
Sample Accept	The Sample Accept output goes high at the end of each sample period if the evaluated value for measured leak rate is less than the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sample Reject	The Sample Reject output goes high at the end of each sample period if the evaluated value for measured leak rate exceeds the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sniffer Busy	The Sniffer Busy output is used to coordinate sharing of a single leak detector between two TracerMate instruments. It goes high at the start of the initialization segment and remains high until communication with the sniffer is completed at the end of the test sequence. This output can be used to control an external interface to provide switching of the RS232 link between the TracerMate and leak detector. The Sniffer Ready input is used as feedback to the TracerMate instruments to indicate which has connection to the leak detector.	Sniffer Control Group
T-Gas Calibration	The T-Gas Calibration output is turned on to control an external calibrated leak for use in leak detector calibration. It goes high during the Sniffer tests when the Run Leak Calibrate option is Enabled.	Chamber Control Group
In Recover	The In Recover output is high during the Tracer Gas Recovery segment.	Test Cycle Group
In Re-evac	The In Re-Evac output is high during the Tracer Gas Re-Evacuation segment.	Test Cycle Group
Inlet Blower	Blower output for purge air source	Chamber Control Group

Output	Description	Functional Group
Outlet Blower	Blower output for purge air exhaust	Chamber Control Group
Circulation Fan	Circulates the air in the accumulation chamber to achieve a homogenous trace gas sample.	Chamber Control Group


Optional Valves supported by this test:

- Reclaim Valve
- T-Gas Calibration
- Inlet Blower
- Outlet Blower
- Circulation Fan

## Chapter 5 – Basic Hard Vacuum Test

*This test performs tracer gas testing of a part in a Hard Vacuum chamber. The instrument provides part evacuation and tracer gas fill of the part and communication with the external leak detector. Hard Vac Chamber valve control is performed by the external leak detector.*

*Test Result is recorded with an overall ACCEPT/REJECT evaluation and includes multiple Pass/Fail/Skipped results depending on the test option settings. Evacuation, Gross and Fine Decay tests report Pass/Fail/Skipped with Measured Pressure and Pressure Loss. Gross and Fine Leak Rate tests report Measured T-Gas Leak Rate Pass/Fail/Skipped. Auto-Zero offset value used is included in results.*



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before filling with T-Gas. Options are: Disabled, Enabled, or Evac to Press.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Vacuum Decay	Enables vacuum decay test prior to tracer fill.	Advanced, Admin
Re-Evac After Test	Allows re-evacuation of part after Sniffer Test completion. If enabled, Exhaust/Re-Evac timer is available before the Exhaust timer.	Advanced, Admin
T-Gas Source	Specifies the manifold pressure source to utilize for the Sniff Test Tracer pressure. The T-Gas Source must be specified even if the T-Gas Fill option is Disabled.	Advanced, Admin
Gross T-Gas Fill	Fill method for the Gross T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Gross Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Gross T-Gas Decay	Enables Gross Leak Decay Test during sniffer test.	Advanced, Admin
Fine T-Gas Fill	Fill method for the Fine T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Fine Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Fine T-Gas Decay	Enables Fine Leak Decay Test during sniffer test.	Advanced, Admin
T-Gas Recovery	Specify method used to remove tracer gas from the part after a test. Options are: Fixed Timer or Exh to Press.	Advanced, Admin

## Sniffer Menu:

The Sniffer specific options for the program may be viewed by going to the Program Config menu and selecting the Sniffer Icon.

Option	Description	User Display Mode
Part Sniffer Type	Sniffer Type used by this part program.	Viewable in Basic & Advanced Editable in Admin
T-Gas Sampling	Specifies result reporting method for measured leak rate. Average reports the average leak rate measurement during the sample period. Peak reports the highest leak rate measurement during sample period.	Advanced, Admin
Sample Gas Number	Sample Gas ID number to be used by the sniffer device. This parameter is hidden if not available on the active leak detector.	Advanced, Admin
Device Zero	If enabled, forces the leak detector to set its Zero level at the end of the Cleanup segment. This parameter is available for use with the Inficon P3000 leak detector.	Advanced, Admin
Autozero Enable	Internal Autozero function. The T-Gas leak rate measurement at the end of the Autozero Delay timer will be applied as a zero offset to reported leak rate measurements during the testing cycle. This option is available in Clamshell mode.	Advanced, Admin
Min T-Gas Mode	Mode for checking Minimum T-Gas leak rate. Continuous: Leak rate must achieve and maintain setpoint. One-Time: Leak rate must achieve but need not maintain setpoint. Disabled: No minimum setpoint.	Advanced, Admin
LD Min T-Gas Setpt	Minimum Tracer Gas leak rate that must be measured for a valid test. If the measured sniffer leak rate is below this value, a Tracer Min Fault is generated.	Advanced, Admin
LD Background Limit	Maximum Tracer Gas background level allowed prior to starting a Test. If the sniffer reports a tracer level exceeding this value, a Tracer Background Fault is generated.	Advanced, Admin
Cleanup Setpoint	Leak rate setpoint for the Chamber Cleanup Fault. Part will not be charged with tracer gas if exceeds this limit.	Advanced, Admin

Option	Description	User Display Mode
Device Mode	Sniffer Device testing mode option. Some leak detectors operate in multiple modes (i.e. Sniff Mode, Accumulation mode, HardVac Mode). This parameter specifies which mode should be used. Hidden for single mode leak detectors.	Advanced, Admin

## Timers Menu:

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Sniff Init	Maximum time allowed for establishing communication with the leak detector and completing the device's initialization. When the device indicates it is ready for testing, any remaining time is aborted and the test sequence continues. If this timer expires before the device has reached a ready state, a Sniffer Not Ready fault is generated.	Advanced, Admin
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure source.	Basic Advanced, Admin
Evac Decay 1	Timer for the Evacuation decay test.	Basic Advanced, Admin
Cleanup	Maximum time allowed for the measured leak rate from the sniffer to fall below the Chamber Clean Setpoint. Remaining time is aborted once the setpoint is reached.	Basic Advanced, Admin
Cleanup Delay	Time delay after opening MS Isolation valve before checking for cleanup setpoints.	Basic Advanced, Admin
Auto-Zero Delay	Delay time for taking the T-Gas leak rate measurement to be used for Auto-Zero from the leak detector. Delay begins when the Chamber Cleanup Setpoint is achieved.	Advanced, Admin
Dev Zero Delay	Delay time before sending the Device ZERO command to leak detector. Available on Inficon P3000.	Advanced, Admin
Gross Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Gross Fill	Time allocated to reach the specified Gross T-Gas Target Pressure. The source valve is pulsed open once per second for the time specified by the Gross Fill Pulse parameter.	Basic Advanced, Admin

Timer	Description	User Display Mode
Gross Fill Pulse	Length of time per second to open the T-Gas pressure source valve while adding pressure during Gross T-Gas Fill.	Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Gross Wait	Delay timer before beginning the gross leak rate measurement sample.	Basic Advanced, Admin
Gross Sample	Length of the gross leak rate measurement period.	Basic Advanced, Admin
Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Fill	Time allocated to reach the specified Fine T-Gas Target Pressure.	Basic Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Fine Wait	Delay timer before beginning the fine leak rate measurement sample.	Basic Advanced, Admin
Fine T-Gas Sample	Length of the fine leak rate measurement period.	Basic Advanced, Admin
T-Gas Exh	Time allocated to recovering Tracer Gas from the part after a test. During this time the Reclaim valve is opened. This timer is only present if the Reclaim Valve is defined and the T-Gas Recovery option is set to Reclaim.	Basic Advanced, Admin
Continue T-Gas Exh	Available if Recovery is set to Exh to Press. The testing cycle jumps to this timer when part pressure falls below T-Gas Exh Press setpoint.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Advanced, Admin
Gross T-Gas Min	Minimum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Gross T-Gas Target	Target pressure for Tracer Gas Gross T-Gas Fill and Test.	Basic Advanced, Admin
Gross T-Gas Max	Maximum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Min	Minimum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Target	Tracer Gas target pressure that is to be achieved. Setpoint for Sniff Test Tracer Fill.	Basic Advanced, Admin
Fine T-Gas Max	Maximum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
T-Gas Exh Press	Available if Recovery is set to Exh to Press. As this setpoint is crossed, the testing cycle jumps to the Continue T-Gas Exh timer.	Basic Advanced, Admin

## Test Parameters – Evacuation Decay

The Test parameters for the Evacuation Decay test program may be viewed and modified by going to the Program Config menu and selecting the TST:SVD1 Icon. This icon and test menu will be hidden if the Evacuation Decay test is disabled.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Gross T-Gas Decay & Tracer Leak Rate

The Test Parameters for the Gross T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNG2 Icon. This icon and test menu will be hidden if the Gross T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1	High limit T-Gas Leak Rate	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Fine T-Gas Decay & Tracer Leak Rate

The Test Parameters for the Fine T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNF2 Icon. This icon and test menu will be hidden if the Fine T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1	High limit T-Gas Leak Rate	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Inputs

Input	Description	Functional Group
Sniffer Ready	The Sniffer Ready input is used to coordinate sharing of a single leak detector between two TracerMate instruments. If the input is defined for a test, the program will wait during the sniffer initialization segment for the input to go high before attempting to communicate with the leak detector. Once active, the input must remain high until the end of the initialization segment or a Sniffer Ready Input fault will be generated.	Sniffer Control Group
Sniffer Present	When the Sniffer Present input is defined, a fault will be generated if the input is not active at any time during the test cycle where tracer gas measurements are expected.	Sniffer Control Group
Ext Press Sw 1-2	External Pressure Switch inputs for the Evac(1) and Tracer(2) sources. If defined, this input must go high before the end of the Fill segment or an ERR EXT SW fault will be generated.	Test Control Group

## Outputs

Output	Description	Functional Group
Ready To Sniff	The Ready To Sniff output goes high after the part has been charged with tracer gas and is ready for testing with the leak detector.	Sniffer Control Group
In Sample	The In Sample output goes high at the beginning of each sample period returns low at the end of each sample period.	Sniffer Result Group
Sample Accept	The Sample Accept output goes high at the end of each sample period if the evaluated value for measured leak rate is less than the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sample Reject	The Sample Reject output goes high at the end of each sample period if the evaluated value for measured leak rate exceeds the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sniffer Busy	The Sniffer Busy output is used to coordinate sharing of a single leak detector between two TracerMate instruments. It goes high at the start of the initialization segment and remains high until communication with the sniffer is completed at the end of the test sequence. This output can be used to control an external interface to provide switching of the RS232 link between the TracerMate and leak detector. The Sniffer Ready input is used as feedback to the TracerMate instruments to indicate which has connection to the leak detector.	Sniffer Control Group
T-Gas Calibration	The T-Gas Calibration output is turned on to control an external calibrated leak for use in leak detector calibration.	Chamber Control Group
In Recover	The In-Recover output is high during T-Gas Recovery.	Test Cycle Group
In Re-evac	The In-Re-Evac output is high during T-Gas Re-Evacuation.	Test Cycle Group

### Optional Valves supported by this test


- Reclaim Valve
- T-Gas Calibration

## Chapter 6 – Basic HV (Pre-charged) Test

*This test performs tracer gas testing of a part in a Hard-Vacuum chamber. The instrument provides part evacuation and tracer gas fill of the part and communication with the external leak detector. Hard Vac Chamber valve control is performed by the external leak detector.*

*Test Result is recorded with an overall ACCEPT/REJECT evaluation and includes multiple Pass/Fail/Skipped results depending on the test option settings. Evacuation, Gross and Fine Decay tests report Pass/Fail/Skipped with Measured Pressure and Pressure Loss. Gross and Fine Leak Rate tests report Measured T-Gas Leak Rate Pass/Fail/Skipped. Auto-Zero offset value used is included in results.*

The Basic Hard Vac (Pre-Charged) test type is used for parts that are already charged with tracer gas before being tested. The test is the same as the regular Basic Hard Vac test except that the normal restrictions on the settings for Cleanup Setpoint (e.g. Cleanup Setpoint < Reject Setpoint) are not enforced. This allows additional flexibility in how parts are tested.



## Chapter 7 – Advanced Hard Vac Test

*This test performs tracer gas testing on a part in a Hard Vacuum chamber. The instrument provides part evacuation and tracer gas fill for the part, communication with the external leak detector, and provides valve control for the hard vacuum chamber.*

*Test Result is recorded with an overall ACCEPT/REJECT evaluation, and includes multiple Pass/Fail/Skipped results depending on the test option settings. Evacuation, Gross and Fine Decay tests report Pass/Fail/Skipped with Measured Pressure and Pressure Loss. Gross and Fine Leak Rate tests report Measured T-Gas Leak Rate Pass/Fail/Skipped. Auto-Zero offset value used is included in results.*

### Test Description

Advanced Hard Vacuum Mode Options:

1. Chamber Control for Calibrated Leak, Mass Spec Iso., Vent, Evacuation, and Chamber Vacuum Level
2. Part Evacuation /with or without Vacuum Decay
3. Gross T-Gas Fill / with or without Pressure Decay
4. Fine T-Gas Fill / with or without Pressure Decay
5. Test Point with Automatic Acc or Rej with collected test data
6. Optional Reclaim or Vent
7. Post Evacuation

Sensitivity


- Ideal sensitivity 10-11 scc/sec
- Practical production sensitivity is 10-10 scc/sec or less
- Used for reject rates from 10-8 to 1 scc/sec

Advantages

- Excellent sensitivity for all leak rates less than 10-2 scc/sec
- Sensitivity and repeatability not affected by part or ambient temperature changes
- Not affected by part elasticity or pressure changes
- Good for leak location or leak rate depending on configuration of system for sniffer or vacuum operation

- Adaptable to high production

## Advanced Hard Vacuum Test



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and

selecting the Options Icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before filling with T-Gas. Options are: Disabled, Enabled, or Evac to Press.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Vacuum Decay	Enables vacuum decay test prior to tracer fill.	Advanced, Admin
Re-Evac After Test	Allows re-evacuation of part after Sniffer Test completion. If enabled, Exhaust/Re-Evac timer is available before the Exhaust timer.	Advanced, Admin
Chmbr Evac Close	When to close Chamber Evac valve. After Crossover: Close after chamber crossover is achieved. Before Fill: Close immediately before tracer fill. Always Open: Valve remains open throughout cycle.	Advanced, Admin
T-Gas Source	Specifies the manifold pressure source to utilize for the Sniff Test Tracer pressure. The T-Gas Source must be specified even if the T-Gas Fill option is Disabled.	Advanced, Admin
Gross T-Gas Fill	Fill method for the Gross T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Gross Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Gross T-Gas Decay	Enables Gross Leak Decay Test during sniffer test.	Advanced, Admin
Fine T-Gas Fill	Fill method for the Fine T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Fine Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
Fine T-Gas Decay	Enables Fine Leak Decay Test during sniffer test.	Advanced, Admin
T-Gas Recovery	Specify method used to remove tracer gas from the part after a test. Options are: Fixed Timer or Exh to Press.	Advanced, Admin

Option	Description	User Display Mode
Chmbr Post-Purge	Specifies whether a chamber purge will be performed flowing test. No: Never purge. Reject: Only purge on part reject. Any: Always purge.	Advanced, Admin

## Sniffer Menu:

The Sniffer specific options for the program may be viewed by going to the Program Config menu and selecting the Sniffer Icon.

Option	Description	User Display Mode
Part Sniffer Type	Sniffer Type used by this part program.	Viewable in Basic & Advanced Editable in Admin
T-Gas Sampling	Specifies result reporting method for measured leak rate. Average reports the average leak rate measurement during the sample period. Peak reports the highest leak rate measurement during sample period.	Advanced, Admin
Sample Gas Number	Sample Gas ID number to be used by the sniffer device. This parameter is hidden if not available on the active leak detector.	Advanced, Admin
Device Zero	If enabled, forces the leak detector to set its Zero level at the end of the Cleanup segment. This parameter is available for use with the Inficon P3000 leak detector.	Advanced, Admin
Autozero Enable	Internal Autozero function. The T-Gas leak rate measurement at the end of the Autozero Delay timer will be applied as a zero offset to reported leak rate measurements during the testing cycle. This option is available in Clamshell mode.	Advanced, Admin
Min T-Gas Mode	Mode for checking Minimum T-Gas leak rate. Continuous: Leak rate must achieve and maintain setpoint. One-Time: Leak rate must achieve but need not maintain setpoint. Disabled: No minimum setpoint.	Advanced, Admin
LD Min T-Gas Setpt	Minimum Tracer Gas leak rate that must be measured for a valid test. If the measured sniffer leak rate is below this value, a Tracer Min Fault is generated.	Advanced, Admin

Option	Description	User Display Mode
LD Background Limit	Maximum Tracer Gas background level allowed prior to starting a Test. If the sniffer reports a tracer level exceeding this value, a Tracer Background Fault is generated.	Advanced, Admin
Cleanup Setpoint	Leak rate setpoint for the Chamber Cleanup Fault. Part will not be charged with tracer gas if exceeds this limit.	Advanced, Admin
Device Mode	Sniffer Device testing mode option. Some leak detectors operate in multiple modes (i.e. Sniff Mode, Accumulation mode, HardVac Mode). This parameter specifies which mode should be used. Hidden for single mode leak detectors.	Advanced, Admin

## Timers Menu:

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Sniff Init	Maximum time allowed for establishing communication with the leak detector and completing the device's initialization. When the device indicates it is ready for testing, any remaining time is aborted and the test sequence continues. If this timer expires before the device has reached a ready state, a Sniffer Not Ready fault is generated.	Advanced, Admin
Chmbr Pre-Purge	Time the Chamber Clean output remains on during the evacuation segment.	Advanced, Admin
Part Evac Limit	Maximum time allowed for reaching part evacuation setpoint. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Advanced, Admin
Chamber Evac Limit	Timeout for achieving Chamber Evacuation setpoint pressure. Measured from the opening of the chamber evacuation valve.	Advanced, Admin
Ch Evac Valve Delay	Delay time after closing the chamber evacuation valve.	Advanced, Admin
MS Iso Open Delay	Delay after opening the mass spec isolation valve.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure source.	Basic Advanced, Admin
Evac Decay 1	Timer for the Evacuation decay test.	Basic Advanced, Admin
Cleanup	Maximum time allowed for the measured leak rate from the sniffer to fall below the Chamber Clean Setpoint. Remaining time is aborted once the setpoint is reached.	Basic Advanced, Admin
Auto-Zero Delay	Delay time for taking the T-Gas leak rate measurement to be used for Auto-Zero from the leak detector. Delay begins when Chamber Cleanup Setpoint is achieved.	Advanced, Admin
Dev Zero Delay	Delay time before sending the Device ZERO command to leak detector. Available on Inficon P3000.	Advanced, Admin

Timer	Description	User Display Mode
Gross Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Gross Fill	Time allocated to reach the specified Gross T-Gas Target Pressure. The source valve is pulsed open once per second for the time specified by the Gross Fill Pulse parameter.	Basic Advanced, Admin
Gross Fill Pulse	Length of time per second to open the T-Gas pressure source valve while adding pressure during Gross T-Gas Fill.	Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Gross Wait 1	Delay timer before beginning the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Gross Sample 1	Length of the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Fill	Time allocated to reach the specified Fine T-Gas Target Pressure.	Basic Advanced, Admin
Continue to Fill	Time to continue to fill after target pressure is achieved.	Basic Advanced, Admin
Stabilize	Amount of time allocated to each segment for execution before continuing.	Basic Advanced, Admin
Fine Wait 1	Delay timer before beginning the sampling period at a leak rate measurement point.	Basic Advanced, Admin
Fine T-Gas Sample 1	Length of the sampling period at a leak rate measurement point.	Basic Advanced, Admin

Timer	Description	User Display Mode
T-Gas Exh	Time allocated to recovering Tracer Gas from the part after a test. During this time the Reclaim valve is opened. This timer is only present if the Reclaim Valve is defined and the T-Gas Recovery option is set to Reclaim.	Basic Advanced, Admin
Continue T-Gas Exh	Available if Recovery is set to Exh to Press. The testing cycle jumps to this timer when part pressure falls below T-Gas Exh Press setpoint.	Basic Advanced, Admin
Exhaust/Re-Evac	Time allocated to exhaust and re-evacuate the part after a test. This timer is present if the Re-Evacuate After Test option is Yes. The part is first exhausted, and Re-Evacuation will not begin until the part reached a safe pressure. Timer must be long enough to accommodate both.	Basic Advanced, Admin
Mass Spec Purge	Amount of time at the end of the Chamber Purge timer that the mass spec will be open. If 0, the mass spec is not opened during chamber purge.	Advanced, Admin
Chamber Purge	Duration of Chamber Purge at end of testing cycle. This timer begins at first Exhaust segment and runs concurrently with part exhaust.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Basic Advanced, Admin
Chmbr Pre-Purge	Defines the pressure at which the Chamber Clean output is turned on during the evacuation segment.	Basic Advanced, Admin
Chamber Crossover	Minimum pressure that must be achieved during chamber evacuation. Failure to achieve this setpoint generates a Chamber Evacuation Fault.	Basic Advanced, Admin
Gross T-Gas Min	Minimum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Gross T-Gas Target	Target pressure for Tracer Gas Gross T-Gas Fill and Test.	Basic Advanced, Admin
Gross T-Gas Max	Maximum test pressure allowed during the Gross T-Gas Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Min	Minimum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
Fine T-Gas Target	Tracer Gas target pressure that is to be achieved. Setpoint for Sniff Test Tracer Fill.	Basic Advanced, Admin
Fine T-Gas Max	Maximum test pressure allowed during the Fill and Stabilization timers.	Basic Advanced, Admin
T-Gas Exh Press	Available if Recovery is set to Exh to Press. As this setpoint is crossed, the testing cycle jumps to the Continue T-Gas Exh timer.	Basic Advanced, Admin

## Test Parameters – Evacuation Decay

The Test parameters for the Evacuation Decay test program may be viewed and modified by going to the Program Config menu and selecting the TST:SVD1 Icon. This icon and test menu will be hidden if the Evacuation Decay test is disabled.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Gross Leak Decay & Tracer Leak Rate

The Test Parameters for the Gross T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNG2 Icon. This icon and test menu will be hidden if the Gross T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1	High limit T-Gas Leak Rate	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Test Parameters – Fine Leak Decay & Tracer Leak Rate

The Test Parameters for the Fine T-Gas Decay test may be viewed and modified by going to the Program Config menu and selecting the TST:SNF2 Icon. This icon and test menu will be hidden if the Fine T-Gas Fill option is disabled. However, the Leak Rate parameters will be displayed.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes.	Advanced, Admin
T-Gas Evaluation	Determines evaluation criteria for tracer leak rates. Pass/Fail means Pass when leak rate is below setpoint, fail when leak rate is above setpoint.	Basic Advanced, Admin
Reject Rate 1	High limit T-Gas Leak Rate	Basic Advanced, Admin

Test Evaluation Code	Description
Above Hi Limit > Between Limits > Below Lo Limit	Three zones of evaluation for Pass and Fail
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Inputs

Input	Description	Functional Group
Sniffer Ready	The Sniffer Ready input is used to coordinate sharing of a single leak detector between two TracerMate instruments. If the input is defined for a test, the program will wait during the sniffer initialization segment for the input to go high before attempting to communicate with the leak detector. Once active, the input must remain high until the end of the initialization segment or a Sniffer Ready Input fault will be generated.	Sniffer Control Group
Sniffer Present	When the Sniffer Present input is defined, a fault will be generated if the input is not active at any time during the test cycle where tracer gas measurements are expected.	Sniffer Control Group
Chamber Crossover Fault	The Chamber Crossover input indicates that the vacuum chamber pressure is above the crossover threshold. It goes and stays low while crossover pressure is achieved. If the Chamber crossover does not go low during Evacuation segment, a Chamber Evacuation Fault is generated.	Chamber Control Group
Chamber Rise Fault	The Chamber Rise input goes high if chamber pressure is above the chamber rise threshold. If this occurs after crossover has been achieved and a test is in progress, a Chamber Rise fault is generated.	Chamber Control Group
Ext Press Sw 1-2	External Pressure Switch inputs for the Evac(1) and Tracer(2) sources. If defined, this input must go high before the end of the Fill segment or an ERR EXT SW fault will be generated.	Test Control Group

## Outputs

Output	Description	Functional Group
Ready To Sniff	The Ready To Sniff output goes high after the part has been charged with tracer gas and is ready for testing with the leak detector.	Sniffer Control Group
In Sample	The In Sample output goes high at the beginning of each sample period returns low at the end of each sample period.	Sniffer Result Group
Sample Accept	The Sample Accept output goes high at the end of each sample period if the evaluated value for measured leak rate is less than the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sample Reject	The Sample Reject output goes high at the end of each sample period if the evaluated value for measured leak rate exceeds the Reject Rate for the sample point. It will remain active until the start of the sample period for the next sample point. After the last sample point in a test, it will remain active until the start of a new test.	Sniffer Result Group
Sniffer Busy	The Sniffer Busy output is used to coordinate sharing of a single leak detector between two TracerMate instruments. It goes high at the start of the initialization segment and remains high until communication with the sniffer is completed at the end of the test sequence. This output can be used to control an external interface to provide switching of the RS232 link between the TracerMate and leak detector. The Sniffer Ready input is used as feedback to the TracerMate instruments to indicate which has connection to the leak detector.	Sniffer Control Group
T-Gas Calibration	The T-Gas Calibration output is turned on to control an external calibrated leak for use in leak detector calibration. It goes high during the Sniffer tests when the Run Leak Calibrate option is Enabled.	Chamber Control Group
Chamber Vent Close	The Chamber Vent Close output goes high at the start of a test, immediately before part evacuation begins. It remains high until the end of the test, during the Chamber Purge segment.	Chamber Control Group

Output	Description	Functional Group
Chamber Evac Open	The Chamber Evac Open output goes high when the Chamber Evac Delay timer expires during the evacuation sequence. It goes low at the time specified by the Chamber Evac Close parameter. It will be re-opened during the Chamber Purge segment if Chamber Purge is enabled and the Chamber Purge Method is set to Evac.	Chamber Control Group
Mass Spec Isolation Open	The Mass Spec Isolation Open output goes high when the Mass Spec Open timer expires. It remains open through end of the last leak rate sample period. If Chamber Purge is enabled and the Chamber Purge Method is set to Evac, the Mass Spec Isolation Open output will again go high during the last part of the Chamber Purge timer as specified by the Mass Spec Purge timer.	Chamber Control Group
Chamber Clean Open	The Chamber Clean Open output goes high during for the duration of the chamber Purge segment if Chamber Purge is enabled.	Chamber Control Group
Chamber Ready	The Chamber Ready output goes high when the chamber crossover is achieved and remains high until the end of the testing cycle.	Chamber Control Group
In Recover	The In Recover output is high during the Tracer Gas Recovery segment.	Test Cycle Group
In Re-evac	The In Re-Evac output is high during the part re-Evacuation segment.	Test Cycle Group
In Purge	The In Purge output is high during the Chamber Purge segment	Test Cycle Group

#### Optional Valves supported by this test:


- Reclaim Valve
- T-Gas Calibration
- Chamber Vent
- Chamber Evac
- Mass Spec Isolation
- Chamber Clean

#### Optional Analog Inputs used in this test:

- Chamber Pressure Transducer

## Chapter 8 – Adv Hard Vac (Pre-charged)


The Advanced Hard Vac (Pre-Charged) test type is used for parts that are already charged with tracer gas before being tested. The test is the same as the regular Advanced Hard Vac test except that the normal restrictions on the settings for Cleanup Setpoint (e.g. Cleanup Setpoint < Reject Setpoint) are not enforced. This allows additional flexibility in how parts are tested.



## Chapter 9 – Clean Part (Evac/Purge)

*This test type provides evacuation fill with vent of the part. It is intended for flowing air through the part to remove any residual tracer gas following a sniffer test.*

*This test has no test menu, the test reports SEQ COMP and the final pressure reading measured at end of the Clean Fill segment.*



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before fill.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Clean Part Source	Specifies the manifold pressure source to utilize for the Clean fill pressure.	Advanced, Admin
Vent During Fill	Specifies whether the exhaust valve remains open during the clean fill.	Advanced, Admin

## Timers Menu

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
Clean	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Advanced, Admin
Target Pressure	Desired part Target pressure for Clean fill.	Basic Advanced, Admin
Maximum Pressure	Maximum fill pressure.	Basic Advanced, Admin


## Chapter 10 – Evac & Fill

*This test type provides evacuation and tracer gas fill of the part. It can provide a method for evacuating and backfilling an external part (not in a chamber) with a tracer gas for testing later. It can also serve as Nitrogen backfill prior to shipping.*

This test type has no test menu. Faults are reported for high or low pressure during the part Evac & Fill segments.

When complete, the instrument reports SEQ COMP (Sequence Complete) and it reports the final pressure reading measured at end of the Fill segment.

### Typical Graph Set for the Evac & Fill Test:



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before filling with T-Gas.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Evacuation Xdcr	Selects the transducer that will be used to measure vacuum during the test.	Advanced, Admin
Re-Evac After Test	Allows re-evacuation of part after Sniffer Test completion.	Advanced, Admin
T-Gas Source	Specifies the manifold pressure source to utilize for the Sniff Test Tracer pressure. The T-Gas Source must be specified even if the T-Gas Fill option is Disabled.	Advanced, Admin
Fine T-Gas Fill	Fill method for the Fine T-Gas Decay test. Options are: Disabled (no fill, no test), No Fill (no fill, leak rate test only), Timer Fill (fill for duration of Fine Fill timer), Manual Fill (fill until operator presses the Start button), Fill to Press (fill until part pressure meets Target Pressure).	Advanced, Admin
T-Gas Recovery	Specify method used to remove tracer gas from the part after a test. Options are: Fixed Timer or Exh to Press.	Advanced, Admin

## Timers Menu

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
Prefill	Percentage of the fill timer where minimum pressure limit is not monitored. Allows time within fill for the instrument to achieve the minimum test pressure.	Basic Advanced, Admin
Fill	Time allocated to reach the specified Fine T-Gas Target Pressure.	Basic Advanced, Admin
T-Gas Exhaust	Time to exhaust/recover tracer after the test.	Basic Advanced, Admin
Exhaust/Re-Evac	Time allocated to exhaust and re-evacuate the part after a test. This timer is present if the Re-Evacuate After Test option is Yes. The part is first exhausted, and Re-Evacuation will not begin until the part reached a safe pressure. Timer must be long enough to accommodate both.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.


Pressure	Description	User Display Mode
Evacuation Setpoint	Evacuation Setpoint pressure that is to be achieved. Setpoint for Evacuation.	Basic Advanced, Admin
Allow Evac Limit	Maximum pressure allowed during evacuation. If the starting pressure is above this value, no evacuation will be performed.	Advanced, Admin
Fine T-Gas Min	Minimum fill pressure.	Basic Advanced, Admin
Fine T-Gas Target	Target pressure that is to be achieved.	Basic Advanced, Admin
Fine T-Gas Max	Maximum fill pressure.	Basic Advanced, Admin

## Chapter 11 – Step to Proof Test

*Measures and monitors the Peak Pressure achieved during up to 10 pressure steps, each with independently defined Fill and Dwell timers.*

*This test has no Test menu. Part evaluation is ACCEPT if the Target Pressure Window at the end of the Fill Timer and maintains it within the window for the Dwell Timer, at each pressure step. Otherwise reports ABOVE\_PRESS or BELOW\_PRESS fault.*

*Peak part pressure and last completed step number achieved during test.*



## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
Number of Steps	The number of pressure to be performed during the Step to Proof test.	Basic Advanced, Admin

## Timers Menu:

The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Fill 1-10	Time allocated to reach the specified fill pressure for this step.	Basic Advanced, Admin
Dwell 1-10	Time allocated monitoring the fill pressure for this step. Pressure must remain within the Target Window or a fault will be generated.	Basic Advanced, Admin
Exhaust	Time to exhaust part pressure after test.	Basic Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Target Press Window	Acceptable Target Pressure window during each pressure step.	Basic Advanced, Admin
Target Press 1-10	Target Pressure for each step during the test.	Basic Advanced, Admin
Maximum Pressure	Maximum pressure allowed during the test.	Basic Advanced, Admin
Ramp Method	Defines the physical hardware and method utilized to generate the target pressures.	Basic Advanced, Admin


## Chapter 12 – Refrigerant Fill Test

*This test type provides evacuation and refrigerant fill of the part after leak testing of the part has been completed. This test may be linked, following a normal sniffer test with an Accept result.*


The part is first evacuated to a specified vacuum setpoint using the TracerMate manifold pneumatics. Part pressure is monitored during evacuation using an external high-vacuum transducer connected to the 2<sup>nd</sup> analog port. The transducer is mounted on the refrigerant fill pneumatics. Both the TracerMate instrument manifold and the vacuum gauge are then isolated from the part and the refrigerant fill pneumatics. The part is filled with refrigerant to a specified weight as measured using a weigh scale connected to RS232\_1 serial port. An optional step allows the part weight to be manually increased by the operator using a digital input.

The Test Segment determines part Accept or Reject based on the final measured minimum and maximum weights.

### Refrigerant Evacuation and Fill



## External Pneumatics:



Each external valve is controlled by a TracerMate digital output.

The REF ISOLATION valve isolates the TracerMate instrument from both the part and the External Refrigerant Fill pneumatics. This valve is open during pressure testing, sniffer testing, and the evacuation performed at the beginning of the Refrigerant Fill Test Type. It is closed before refrigerant fill begins. When the test is complete and the part is disconnected from the Check Quick Connect Fitting, the operator presses the TEST COMPLETE digital input. The REFRIGERANT POST-TEST VENT VALVE is opened to remove refrigerant remaining in the refrigerant fill pneumatic assembly, then the REF ISOLATION VALVE is re-opened.

A normally closed valve may be included between the TracerMate instrument and the REF ISOLATION VALVE that will automatically close in the event of a power failure during a test.

### Measured Weight Value:

The refrigerant source bottle is placed on the scale before the test begins. The scale is measuring not the weight of refrigerant added to the part, but the weight removed from the source.

Early fault determination during a Prefill segment (similar to the severe leak fault during a pressure decay test) is not possible.

The value of the Measured Weight for the part is calculated from the change in source weight minus the weight of refrigerant that remains in the fill pneumatic assembly. The “Fill Assy Ref Wgt” parameter on the Weight Menu specifies this value.

### Scale interface:

The TracerMate does not perform weigh scale calibration or zero. This should be done using the scale’s user interface before loading the refrigerant fill bottle on the scale.

For the Ohaus 3000 scale interface, all user configuration parameters are forced to their factory default values during scale initialization. The TracerMate accepts weight readings from the scale in KG. This value will be converted to the units selected in the TracerMate, which are KG, G, LB or OZ. This means the weight displayed by the scale may be in different units than on the TracerMate.

### Manual Fill:

When the “Manual Fill” option is enabled, the operator is permitted to manually add refrigerant after the automatic refrigerant fill operation has been completed.

After the normal refrigerant fill operation is completed, the TracerMate display will indicate that it has entered the “Manual Fill” segment and continue to measure and display the measured weight that has been added to the part. In this segment, the instrument will display “Press Start to continue” at the bottom of the display.

An external digital input indicates a Manual Fill request from the operator. If the Manual Fill Digital Input is high on entering this segment a popup is generated and nothing happens until the input goes low. Once this condition is met, the input controls the opening and closing of the refrigerant fill valve. When the input is high, the fill valve is opened. When it is low, the fill valve is closed. The Target Weight Max Limit is still enforced during the manual fill operation. Weight that was added manually is included as a separate value in the part result data.

The Start button/input will indicate normal completion of the manual fill operation and cause the instrument to end the refrigerant fill test sequence.

If the Manual Fill segment timer is set to 0.0 there is no time limit imposed on the duration of the manual Fill segment. Otherwise, if the timer expires the segment will be ended automatically as if the operator had pressed the Start button.

The Manual Fill operation will be ended automatically if the “Max Fill Weight” limit is exceeded.

## **Test results:**

- Total weight of refrigerant that was added to the part
- Weight of refrigerant that was added during Manual operation
- Part evacuation pressure before fill
- Starting refrigerant Source weight
- Ending refrigerant Source weight

## **Hold button operation:**

The Hold function does not function during Refrigerant Fill segments.

## Options Menu

The Options for the program may be viewed by going to the Program Config menu and selecting the Options Icon.

Option	Description	User Display Mode
Part Evacuation	Enable/disable evacuation of the part before filling with Refrigerant.	Advanced, Admin
Evacuation Source	Specifies the manifold pressure source to utilize for part evacuation. The Evacuation Source must be specified even if the Part Evacuation option is Disabled.	Advanced, Admin
Manual Fill	Yes/No – this option controls whether a manual Fill segment is added between the normal refrigerant Fill segment and the Test segment.	Advanced, Admin
Refrigerant Exhaust	Yes/No – this option controls whether an optional refrigerant exhaust valve is opened after the part is filled and isolated from the external pneumatics. If this option is No, the refrigerant must be removed manually before pressing the Part Removed button.	Advanced, Admin

## Weight Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Weight	Description	User Display Mode
Scale Type	Ohaus 3000, ...	Basic Advanced, Admin
Min Tare Weight	Used during initialization – fill source must exceed this weight for test to begin.	Basic Advanced, Admin
Max Tare Weight	Used during initialization – fill source must not exceed this weight for test to begin.	Basic Advanced, Admin
Fill Assy Ref Wgt	Specifies the refrigerant weight that will be contained in the fill pneumatics assembly during the refrigerant fill sequence.	Advanced, Admin
Min Fill Weight	Minimum weight of refrigerant transferred into the part during Fill segment	Basic Advanced, Admin
Target Fill Weight	Target weight of refrigerant transferred into the part during Fill segment	Basic Advanced, Admin
Max Fill Weight	Maximum weight of refrigerant transferred into the part during Fill segment	Basic Advanced, Admin

## Timers Menu


The Timers for the program may be viewed by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Scale Init	Maximum time limit for initializing communication with the scale.	Advanced, Admin
Pre-Evac Exhaust	Time allowed for part exhaust before starting test cycle.	Advanced, Admin
Evacuate	Time allocated to evacuating the part. If the part has not reached the Evacuation Setpoint pressure by the end of the timer an Evacuation Fault is generated.	Basic Advanced, Admin
REF Iso Delay	Delay timer waiting for refrigerant isolation valve to close.	Advanced, Admin
XDCR Iso Delay	Delay timer waiting for Vacuum Xdcr Isolation valve to close.	Advanced, Admin
Fill	Time allocated to reach the specified Target Weight.	Basic Advanced, Admin
Fill Close Delay	This is a delay to allow time for the refrigerant fill valve to physically move from open to closed position. (This timer value is also used after closing the valve in Manual Fill mode)	Advanced, Admin
Manual Fill	This timer is the maximum duration of the manual Fill segment. If 0, no time limit is imposed.	Advanced, Admin
Stabilize	This timer is used to be sure a stable weight has been achieved and maintained before beginning the Test segment. Segment ends once stability is achieved.	Basic Advanced, Admin
Refrigerant Vent	This segment allows time for refrigerant to be vented or removed from the external fill pneumatics before re-opening the REF ISOLATION and TRANSDUCER ISOLATION valves.	Basic Advanced, Admin
Refrgnt Vent Close	Delay before allowing isolation valve to reopen after test is complete.	Basic Advanced, Admin

Timer	Description	User Display Mode
Ref Rest	Delay timer for resting manifold.	Advanced, Admin

## Pressure Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Evacuation Setpoint	<p>Evacuation pressure setpoint that must be achieved and maintained during part evacuation.</p> 	<p>Basic Advanced, Admin</p>
Allow Evac Limit	<p>Maximum part pressure at which evacuation will be allowed. If the starting part pressure is higher than this value a fault is generated and no evacuation will be performed.</p>	<p>Advanced, Admin</p>

## Test Menu

The Pressures for the program may be viewed by going to the Program Config menu and selecting the Pressures Icon.

Weight	Description	User Display Mode
Low Limit Weight	Low Limit for measured refrigerant weight	<p>Basic Advanced, Admin</p>
High Limit Weight	High Limit for measured refrigerant weight	<p>Basic Advanced, Admin</p>
Test Evaluation	F/P/F, etc.	<p>Basic Advanced, Admin</p>

### Digital Outputs

Output	Description	Functional Group
REF Isolation Valve	This output goes high to CLOSE the REF Isolation valve. (Controls a normally open valve type)	Refrigerant Control Group
Transducer Isolation Valve	This output goes high to OPEN the Transducer Isolation valve. (Controls a normally closed valve type)	Refrigerant Control Group
Refrigerant Fill Valve	This output goes high to OPEN the Refrigerant Fill valve. (Controls a normally closed valve type)	Refrigerant Control Group
Refrigerant Exhaust Valve	This output goes high to OPEN the Refrigerant Exhaust valve. (Controls a normally closed valve type)	Refrigerant Control Group

### Digital Inputs

Input	Description	Functional Group
Manual Fill	This input represents a Manual Refrigerant Fill from the operator. High indicates add refrigerant.	Refrigerant Status Group
Part Removed	This input indicates when the part has been removed, and that it is safe to re-open refrigerant and transducer isolation valves	Refrigerant Status Group


## Chapter 13 – Pressure Decay- $\Delta P$ Test

*This chapter explains the theory and parameters for conducting a gross leak test using pressure decay test measuring a pressure loss over time. The result of this test is the pressure loss (or vacuum loss for a vacuum test) measured over a fixed period of time. This test type is typically performed with compressed air or nitrogen and should not be confused with the Gross T-Gas Decay tests described in other chapters.*

The basic principle of operation of a pressure decay leak test instrument is to fill the test part to a specified target test pressure, isolate the test part from the source air and allow the pressure to stabilize, and then measure the pressure loss due to a leak over a defined time.

The Charts below give an overview of the parameters used to setup a Pressure Decay  $\Delta P$  Test. The Tables that follow give detailed descriptions of each parameter and also document the Display User Level associated with each parameter.

*Note: To change the Display User Level, see [Chapter 22](#).*



## Timer Parameters


The Timers for the program may be viewed and modified by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Tooling Extend	When tooling control is specified, there can be up to five extend timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin
Prefill	Checks for excessively leaking parts or lack of pressure. May be set as a % of fill time (Default), for fixed fill time tests, or a not to exceed timer. See the Chapter on Features to change the functionality of this value. Maximum time to reach the minimum pressure. If the variable is set to a not to exceed timer, this segment will exit to the next once the Minimum Pressure value is reached.	Advanced, Admin
Fill	Time to enable part to reach the Target Pressure. It may also be used as time to stabilize part pressure with additional air.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure regulator. This time directly affects the repeatability of the test.	Basic Advanced, Admin
Test	The precise time over which to measure pressure drop or decay or the precise end time to measure pressure rise.	Basic Advanced, Admin
Exhaust	Time to relieve or vent part pressure before signaling the end of test. Need time to prevent blowing out debris or fixture seals.	Basic Advanced, Admin
Tooling Retract	When tooling control is specified, there can be up to five retract timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin
Part Mark	This is used as the duration for an external part (not in a chamber) marking device and is a not to exceed timer when feedback is being utilized.	Advanced, Admin

## Pressure Parameters

The Pressure menu is located in the **Main Menu > Program Config > Pressure** icon.

Pressure	Description	User Display Mode
Minimum Pressure	The value that must be reached before the Prefill setpoint is reached and must be maintained through Fill and Stabilization segments or the testing cycle will end as a Severe Leak.	Basic Advanced, Admin
Target Pressure	The specified test pressure for the part. For vacuum test pressures enter as positive values if psiv was selected as the pressure unit. Enter as a negative if psig was selected as the pressure unit. (i.e. A test pressure 9.7 psia would be entered as 5 psiv or -5 psig.) Pressure loss may be corrected to the Target Pressure.	Basic Advanced, Admin
Maximum Pressure	The value that must not be exceeded at any time to complete a successful test. If the pressure goes above the Maximum Test Pressure, the testing cycle will end as an Over Pressure Malfunction.	Basic Advanced, Admin
Target Pressure Window	There is a window (default - +/-50%) set about the Target Pressure that must be maintained during the Test segment of the testing cycle. It generates a Target Pressure Low or High Malfunction if the actual pressure falls outside this window during test.	Advanced, Admin



## Test Parameters

The Test parameters for the program may be viewed and modified by going to the Program Config menu and selecting the TST:PLO Icon.

TST Parameter	Description	User Display Mode
Low Limit Loss	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Upper setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes	Advanced, Admin
EDC Enable	Activates Environmental Drift Correction. See Appendix B	Advanced, Admin
EDC Percentage	See Appendix B	Advanced, Admin
EDC Quantity	See Appendix B	Advanced, Admin

Test Evaluation Code	Description
<b>Above Hi Limit&gt;Between Limits&gt; Below Lo Limit</b>	<b>Three zones of evaluation for Pass and Fail</b>
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (Default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Chapter 14 – Pressure Decay-Leak Std Test

This chapter explains the theory and parameters for conducting a gross leak test using a pressure decay test with a leak standard. The result of this test is presented in units of flow calculated from the measured pressure loss over the duration of the Test segment timer.

This test type is used for leak applications with a leak rate specified in flow units. This test type is typically performed with compressed air or nitrogen and should not be confused with the Gross T-Gas Decay tests described in other chapters.


The basic principle of operation of a pressure decay leak test instrument is to fill the test part to a specified target test pressure, isolate the test part from the source air and allow the pressure to stabilize, and then measure the pressure loss due to a leak over a defined time. The measured pressure loss is used to calculate a flow rate. The correlated flow rate is based on the two pressure loss values previously measured and stored in memory from calibrations cycles performed on a non-leaking master part.



*This test type utilizes a two point calibration sequence with a non-leaking master part to set the zero flow value and the flow value at the leak standard value.*

The Chart below gives an overview of the parameters used to setup a Gross Decay-Leak Std Test. The Tables that follow give detailed descriptions of each parameter and also document the Display User Level associated with each parameter.

*Note: To change the Display User Level, see [Chapter 22](#).*



## Timer Parameters

The Timers for the program may be viewed and modified by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Tooling Extend	When tooling control is specified, there can be up to five extend timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin
Relax	Amount of time allocated before continuing to run another test on the same part. This timer is used to allow a calibration master part to return to its original temperature and size if the same master part is used for two calibration cycles.	Advanced, Admin
Prefill	Checks for excessively leaking parts or lack of pressure. May be set as a % of fill time (Default), for fixed fill time tests, or a not to exceed timer. See the Chapter on Features to change the functionality of this value. Maximum time to reach the minimum pressure. If the variable is set to a not to exceed timer, this segment will exit to the next once the Minimum Pressure value is reached.	Advanced, Admin
Fill	Time to enable part to reach the Target Pressure. It may also be used as time to stabilize part pressure with additional air.	Basic Advanced, Admin
Stabilize	Time to stabilize part pressure while isolated from the pressure regulator. This time directly affects the repeatability of the test.	Basic Advanced, Admin
Test	The precise time over which to measure pressure drop or decay or the precise end time to measure pressure rise.	Basic Advanced, Admin
Exhaust	Time to relieve or vent part pressure before signaling the end of test. Need time to prevent blowing out debris or fixture seals.	Basic Advanced, Admin
Tooling Retract	When tooling control is specified, there can be up to five retract timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin

## Pressure Parameters

The Pressures for the program may be viewed and modified by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Minimum Pressure	The value that must be reached before the Prefill setpoint is reached and must be maintained through fill and stabilization segments or the testing cycle will end as a Severe Leak.	Basic Advanced, Admin
Target Pressure	The specified test pressure for the part. For vacuum test pressures enter as positive values if psiv was selected as the pressure unit. Enter as a negative if psig was selected as the pressure unit. (i.e. A test pressure 9.7 psia would entered as 5 psiv or -5 psig.) Pressure loss may be corrected to the Target Pressure.	Basic Advanced, Admin
Maximum Pressure	The value that must not be exceeded at any time to complete a successful test. If the pressure goes above the Maximum Test Pressure, the testing cycle will end as an Over Pressure Malfunction.	Basic Advanced, Admin
Target Press Window	The is a window (default - +/-50%) set about the Target Pressure that must be maintained during the Test segment of the testing cycle. It generates a Target Pressure Low or High Malfunction if the actual pressure falls outside this window during test.	Advanced, Admin

## Test Parameters

The Test parameters for the program may be viewed and modified by going to the Program Config menu and selecting the TST:PLR Icon.

TST Parameter	Description	User Display Mode
Low Limit Leak	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Leak	Upper setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes	Advanced, Admin
Max Master+Leak Loss	The maximum value allowed for the second test during the Program Calibration sequence when the leak standard is in the test circuit.	Basic Advanced, Admin
Min Master Loss	The minimum pressure loss value allowed for the first test during the Program Calibration sequence.	Basic Advanced, Admin
Min Perform Factor	Minimum acceptable value for the Performance Factor compared after the calibration cycle to prevent improper calibrations.	Advanced, Admin
Quik Test Enable	Activates Quik Test. See Appendix A	Advanced, Admin
Quik Test Timer	See Appendix A	Advanced, Admin
Quik Test LL Band	See Appendix A	Advanced, Admin
Quik Test HL Band	See Appendix A	Advanced, Admin
EDC Enable	Activates Environmental Drift Correction. See Appendix B	Advanced, Admin
EDC Percentage	See Appendix B	Advanced, Admin
EDC Quantity	See Appendix B	Advanced, Admin

Test Evaluation Code	Description
<b>Above Hi Limit&gt;Between Limits&gt; Below Lo Limit</b>	<b>Three zones of evaluation for Pass and Fail</b>
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (Default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

*Note: If the instrument is configured multiple internal leak standards the user must select which leak standard is to be used in the Program. See Selecting the Proper Internal Leak Standard in [Chapter 22](#).*

## Program Calibration

In order to scale the flow transducer to the “zero flow” reading measured by testing a non-leaking part and the “reject” reading measured by testing the non-leaking part with a leak standard incorporated in the circuit, the instrument needs to run the “Program Cal” procedure. This procedure requires at least one known non-leaking part referred to as a “master part.” This procedure tests a non-leaking master part in the seal fixture using the timers and pressures established for the program. The procedure automatically tests the non-leaking master part twice with the Relax timer delay between tests. Within each program that uses a leak standard, Program Cal can be configured to use one of four methods. See **Setting the Cal Method and Leak Standard Location** in [Chapter 22](#).



*Remember: The Leak/Cal menu has a parameter called Leak Std/Cal Define that can be configured for the leak standard information to be used Globally, in which case it would be located under the Channel Config menu, or per Program in which case it*

*would be located under the Program menu. Make sure you check which method you have set your instrument. It is critical to make sure the leak standard values are correct for proper use. In order to view the Cal Method parameter you must be in the “Advanced” or “Admin” Display User Level. To change the Display User Level, see [Chapter 22](#).*

## Initiating the Program Cal Sequence

To initiate a Program Cal sequence, go to Main Menu and select the Program Cal Icon. The Program Cal wizard will tell you to connect a non-leaking master part. Connect the non-leaking master part to the instrument. Push the Start button to initiate the Program Cal sequence. The system will conduct an initial test of the non-leaking master part to measure the flow associated with a non-leaking part. This represents the typical offset associated with testing parts within the environment of the test system. The flow value is saved as the Master Part Flow. The system will conduct a second test on a non-leaking master part with a known calibrated leak standard included in the test. The flow value result for this test is saved as the Master+Leak Flow.

*Note: The instrument will require a Program Cal Sequence if any parameters are modified that effects the calibration.*

Several conditions must be met during the Program Calibration procedure for the instrument to accept and store the calibration results. If the procedure does not meet these conditions, any messages & error codes are displayed at the completion of testing cycle.

If the Program Cal routine is successfully completed, “Program-Cal Passed” will be displayed. If there are any problems during the Program Cal sequence an error will be displayed.

See [Appendix A](#) Messages & Error Codes.

### Calibration Parameters

Calibration parameters are values that are measured or calculated as a result of the Program Cal routine for a Gross Decay-Leak Std test. The table below describes the parameters.

Parameter	Description	User Display Mode
Performance Factor	Calculated value representing the performance of the leak test, calculated after the calibration cycles are completed.	Basic Advanced, Admin
Master Part Press	Measured pressure at the midpoint of the Test segment for the Master Part during the Auto Calibration process (the first test of the Program Cal process).	Basic Advanced, Admin
Master+Leak Press	Measured pressure at the midpoint of the Test Segment for the Master Part with the Leak Standard introduced to the pneumatic test circuit during the Auto Calibration process (the second test of the Program Cal process).	Basic Advanced, Admin
Master Part Loss	Test segment pressure loss during the calibration cycle of the non-leaking Master Part (the first test of the Program Cal process). This value is stored to represent normal loss at the specified Target Pressure.	Viewable in Basic & Advanced <b>Editable in Admin</b>
Master+Leak Loss	Test segment pressure loss during the calibration cycle of the non-leaking Master Part with the Leak Standard introduced to the pneumatic test circuit (the second test of the Program Cal process). This value is stored to represent normal loss + leak standard loss at the specified Target Pressure.	Viewable in Basic & Advanced <b>Editable in Admin</b>
Corr. Leak Std Flow	The calculated leak standard flow rate based on the Program Target Pressure, the leak standard calibrated pressure, and the leak standard calibrated flow rate.	Basic Advanced, Admin


## Chapter 15 – Occlusion Test

*This chapter explains the theory and parameters for conducting an Occlusion Test. The result of this test is the measured back pressure at the expiration of the Test segment.*

The Occlusion Test is a back-pressure test. The part is pressurized throughout the test from a fixed pressure regulator setting. At the end of the Test timer the actual test pressure is compared to the Low Limit Pressure and High Limit Pressure settings. Low Limit Pressure indicates high flow or minimum blockage or low back pressure. High Limit Pressure indicates low flow or maximum blockage or high back pressure.

The Chart below give an overview of the parameters used to setup an Occlusion Test. The Tables that follow give detailed descriptions of each parameter and document the Display User Level associated with each parameter.

*Note: To change the Display User Level, see [Chapter 22](#).*



## Timer Parameters

The Timers for the program may be viewed and modified by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Tooling Extend	When tooling control is specified, there can be up to five extend timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin
Test	At the end of this timer, the instrument will read the pressure on the pressure transducer. This pressure is due to the backpressure created in the pneumatic circuit and part.	Basic Advanced, Admin
Exhaust	Time to relieve or vent part pressure before signaling the end of test. Need time to prevent blowing out debris or fixture seals.	Basic Advanced, Admin
Tooling Retract	When tooling control is specified, there can be up to five retract timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin

## Pressure Parameters

The Pressures for the program may be viewed and modified by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Target Pressure	Target Pressure is the desired test pressure to run all tests.	Basic Advanced, Admin
Maximum Pressure	The value that must not be exceeded at any time to complete a successful test. If the pressure goes above the Maximum Test Pressure, the testing cycle will end as an Over Pressure Malfunction.	Basic Advanced, Admin

## Test Parameters

The Test parameters for the program may be viewed and modified by going to the Program Config menu and selecting the TST:OCC Icon.

TST Parameter	Description	User Display Mode
Low Limit Pressure	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Pressure	Upper setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes	Advanced, Admin

Test Evaluation Code	Description
<b>Above Hi Limit&gt;Between Limits&gt; Below Lo Limit</b>	<b>Three zones of evaluation for Pass and Fail</b>
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (Default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Chapter 16 – Pressure Verify Test

*This chapter explains the theory and parameters for conducting a Pressure Verify test.*

The Pressure Verify test is intended to test parts that generate vacuum or pressure, or to verify that the part was pre-charged to the correct pressure, or to verify that the part was evacuated or filled by an external source.

The principle of operation is to close the isolation valve on the TracerMate II internal manifold to isolate the part. The pressure transducer then reads the vacuum or pressure generated by the part or that is already in the part. At the end of the test timer, the test pressure is compared to the low limit pressure and high limit pressure settings. The Test Result is recorded with an overall ACCEPT/REJECT

If the Pressure Verify test was performed with the Self-Test cap on the test port, the only pressure measured will be the small pressure that is trapped by the isolation valve as it actuates to close.

The Tables that follow give detailed descriptions of each parameter and document the Display User Level associated with each parameter.

Note: To change the Display User Level, see [Chapter 22](#).

### Options Menu

There is no Options menu.

### Timer Parameters


The Timers for the program may be viewed and modified by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Test	Amount of time allocated to each segment for execution before continuing. The pressure measurement is made at the end of the Test segment.	Basic Advanced, Admin
Exhaust	Time to relieve or vent part pressure before signaling the end of test. Need time to prevent blowing out debris or fixture seals.	Basic Advanced, Admin

## Pressure Parameters

The Pressures for the program may be viewed and modified by going to the Program Config menu and selecting the Pressures Icon.

Pressure	Description	User Display Mode
Maximum Pressure	The value that must not be exceeded at any time to complete a successful test. If the pressure goes above the Maximum Test Pressure, the testing cycle will end as an Over Pressure Malfunction.	Basic Advanced, Admin



## Test Parameters

The Test parameters for the program may be viewed and modified by going to the Program Config menu and selecting the TST:PVT Icon.

TST Parameter	Description	User Display Mode
Low Limit Pressure	Lower setpoint value used to evaluate test results.	Basic Advanced, Admin
High Limit Loss	Upper setpoint value used to evaluate test results.	Basic Advanced, Admin
Test Evaluation	Test results are compared to two setpoints for pass or fail status. There are three areas for evaluation of results: Above high limit, Between limits, and Below low limit. See Table below for codes	Advanced, Admin

Test Evaluation Code	Description
<b>Above Hi Limit&gt;Between Limits&gt; Below Lo Limit</b>	<b>Three zones of evaluation for Pass and Fail</b>
P P F	Pass if above low limit
P F F	Pass if above high limit
F P F* (Default)	Pass if between high and low limits
F P P	Pass if below high limit
F F P	Pass if below low limit
P F P	Pass if above the high limit or below the low limit

## Chapter 17 – Program Linking

*This chapter explains the theory and parameters for conducting multiple tests by linking programs together.*

The applications for program linking fall into three basic categories: Conducting multiple tests on one part, one part with multiple chambers, or Multiple unique parts.

### Parent Program Linking

The Parent Program Linking test type is designed to group test results together for a single part. In certain applications it is desirable to conduct multiple tests on one part. These tests may either be run on the same chamber in the part or on different chambers. In any case, it is desirable to group the test results together and produce a global or “Parent” result.

This test type facilitates the linking of individual programs into a testing sequence. The parent program provides the overall control of the start and stop inputs, tooling inputs and outputs, and program result outputs for all of the test sequences. The following functions within each individual test program are ignored and controlled by the Parent Program.


Functions Overridden and Controlled by the Parent Program Test Type
Tooling options (See Advanced Tooling Control Functionality in Chapter 20)
Calibration functions
Autorun Methods
Barcode storage
Relax timer.

### Rules for Parent Program Linking

1. Child Programs may contain tooling logic, but only the tooling logic contained in the Parent Program will be executed. This is covered under [Advance Tooling Control](#) in Chapter 8.
2. A 'Malfunction' at any time or place in the test logic will result in a Vent/Halt.
3. If any of the Child Programs are Reject, the Parent result will be Reject. (Child result evaluations will be AND'd.)
4. If the user starts a Parent Program, the Monitor screen will indicate that the Parent Program is running. The Stop/Reset event during any Child Programs will not navigate the system away from the Parent Program.

### Parent Program Linking Example

In the example sequence below the user is testing a valve. There are two sides of the valve that must pass a fine leak test. If either side fails the fine leak test, another leak test is run on the failed side to determine if it is possible to repair the leaking part.



To program this test sequence, the user goes to Program Config and defines the test type for the Program 1 to be “Parent Program Linking” The test sequence example above requires two links.

Prog Num 1	Tooling	<TST TYPE>	Link1
Test Type	Parent Program Linking		
→Number of Links			2
Facilitates linking individual programs into a single test sequence. Contains tooling control parameters and link definitions. Each link defines the target program to execute and evaluation conditions for additional program execution.			
			P01

The first link screen identifies the program where the testing in the Parent Program will begin and how additional tests are initiated or linked to the first program based on the first test result. The link defines the programs that will be run next via the Evaluation Condition.

Prog Num 1	Tst type	<LINK1>	Link2
Target Program			2
Eval Condition	Accept/Reject		
Execution Pause	No		
Accept Program			3
→Reject Program			4
			P01

The second link required by the example above targets Program 3. If Part 3 is Reject then Program 5 will be run. If Program 3 is Accepted, the test sequence stops with a Program Accept light and a Program Accept.

Prog Num 1	Link1	<LINK2>	Timers
Target Program			3
Eval Condition	Reject		
Execution Pause	No		
→Reject Program			5
			P01

Evaluation Condition	Description
Accept	Directs only the accept parts for further testing using the program defined by “Accept Program”. For rejects, severe leaks, and malfunctions the test sequence stops.
Reject	Directs only reject and severe leak parts for further testing using the program defined by “Reject Program”. For accepts and malfunctions the test sequence stops.
Accept/Reject	Directs accept, reject and severe leak parts for further testing using the programs defined by “Accept Program” if the test passes or “Reject Program” if the test fails or a severe leak occurs. For malfunctions, the test sequence stops.
Any	Directs accept, reject and severe leak parts for further testing by one additional test program using the program defined by “Next Program” for accept, reject, or severe leak tests. For malfunctions, the test sequence stops.

### Link Execution Pause

There are applications where it is desirable for the instrument to pause or delay execution between the target program and the next program when utilizing the Parent Program Linking or Sequential Linking test types. An example would be allowing the operator to manipulate a part between programs, such as opening a valve, inserting a component or any action that requires an external event to take place before testing can continue. This feature is defined within each link; thus it is possible to pause during one link and not another.

Parameter	Description	User Display Mode
Execution Pause	This parameter will have three options: No, Continue on Start, and Continue after Delay. The feature is disabled when set to No, Continue on Start forces the instrument to pause and wait for a start indication to continue, and Continue after Delay forces the instrument to delay until the timer expires then continue execution.	Basic Advanced, Admin

Parameter	Description	User Display Mode
Delay	This parameter indicates the amount of time to delay after the target program, before execution can continue with the next program. The Delay timer is visible when the Execution Pause option is set to Continue after Delay, otherwise the parameter has no affect.	Basic Advanced, Admin

*Note: If you are using Parent Program Linking because you have part with multiple chambers and the instrument is configured with multiple test ports, remember to select the appropriate test port. This is described in Chapter 2 under the heading [“Selecting the Test Port”](#).*

## Timer Parameters

The Timers for the program may be viewed and modified by going to the Program Config menu and selecting the Timers Icon.

Timer	Description	User Display Mode
Tooling Extend	When tooling control is specified, there can be up to five Extend timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin
Exhaust	Time to relieve or vent part pressure before signaling the end of test. Need time to prevent blowing out debris or fixture seals.	Basic Advanced, Admin
Relax	Timer used during Program Cal sequence as a delay between Child Program Links to allow the part to recover to repeatable virgin state. Usually short relax times result in decreasing pressure losses or flows in successive tests.	Basic Advanced, Admin
Tooling Retract	When tooling control is specified, there can be up to five Retract timers for up to five tooling motions. This is a not to exceed timer when feedback is being utilized.	Advanced, Admin

## Sequential Linking

The **Sequential Linking** test type may be used to test multiple unique parts, or tests may be run on the same chamber in the part, or on different chambers. The test results will be reported individually for each program. The functionality and setup of this test type is similar to the **Parent Program Linking** test type. The differences are as follows:

- a) Each of the linked program results is stored individually.
- b) Each result has no bearing on the accept/reject criteria of past or future linked programs unless they are conditionally linked.
- c) The cycle counters increment with each linked program completed.
- d) The tooling control uses the defined motions in each of the linked programs (there is no "Parental tooling control").

## Chapter 18 – Tooling Control

*In this chapter the tooling control capability of the instrument is described. Tooling control is a powerful feature of the instrument that has the ability control cylinders and seal actuations.*

*Note: The instrument must be in Advanced or Admin mode in order to view and modify the tooling functionality. To change the Display User Level, see [Chapter 22](#).*

The instrument includes user selectable digital inputs and outputs to increase the functionality and simplify the application to various test requirements. The tooling functions are defined within each program. This allows the flexibility to use different tooling functions; permitting the ability to seal unique ports for each program. The tooling functions may be viewed and edited by going to the Program Config menu and selecting the Tooling Icon.

It is important that all precautions be taken when using the tooling control functionality of the instrument. If motions are being controlled, it is important to follow best engineering practices while designing the circuitry. This may include using safety modules in the circuit.

In order to implement the tooling functions, they must be interfaced with the inputs and outputs. See [Chapter 19](#) for the input and output instructions.

Parameter	Description	User Display Mode
Tooling Option	The options for this parameter are On, Off, and Disabled. On causes the tooling motion timers to appear on the Timers menu. When On, the instrument will perform these timers in the order they are listed. It will also allow the associated tooling outputs appear in the selectable list in the Outputs menu. When Disabled, the tooling motion timers still appear but are ignored. It will also allow the associated tooling outputs appear in the selectable list; however, the outputs will not be active in this mode. When Off, the timers will not appear or be active.	Advanced, Admin

Parameter	Description	User Display Mode
Number of Motions	This parameter defines the number of motions intended to be used. You can have up to 5 motions.	Advanced, Admin
Two Inputs to Start	For safety purposes, it may be desired to have 2 independent inputs to activate a testing cycle. The 2 inputs are Start and Cycle.	Advanced, Admin
Anti-Tie-Down	For safety purposes, it may be desired to use anti-tie-down inputs to activate a testing cycle. The anti-tie-down inputs (Start & Common) require that the inputs go high within 50 to 500 ms of each other.	Advanced, Admin
Part Present Check	This parameter is not editable. It determines that the part present input is checked when the start input is received. This parameter is active only when one of the Inputs is set to Part Present.	Advanced, Admin
Retract on Reject	This parameter determines whether or not the tooling will retract automatically after a reject. If it is set to No, the instrument will wait until a Stop/Reset input is received or the Stop button is pressed on the keypad before conducting any tooling retract timers or outputs.	Advanced, Admin
Part Mark	The options for this parameter are None, Both, Reject, and Accept. Upon completion of a test an output is available to mark Accept, Reject, or Both for all programs.	Advanced, Admin
Tooling Feedback 1–5	Sometimes it is desirable to use proximity sensors or pressure switches on cylinders or seals to determine if and when they reach their intended location. The instrument has the ability to monitor these actions using this parameter. This parameter may be set to Extend, Retract, or Both to determine which locations are to be monitored.	Advanced, Admin
Part Mark Feedback	The options for this parameter are Yes and No. This is if you want confirmation that a program marking device has completed its response then the test sequence continues on.	Advanced, Admin

## Advanced Tooling Control

*Advanced Tooling Control is used to control motions or sealing between linked programs; therefore, it is only applicable if Parent Program Linking is being used.*

There are applications where it may be required that one or more ports on the test part are blocked or opened between tests to appropriately evaluate multiple chambers of the part. To accomplish this additional part manipulation, tooling motions are required between program executions. Thus far we have covered tooling motions pre-test (Tooling Extend) and post-test (Tooling Retract), this feature adds a method for the instrument to preempt the pre/post-test tooling motions. Again, this feature is only for the Parent Program Linking test type.

On the Program Config menu select the Link icon. The Link Motion parameter defines the Tooling Motion to execute between the Target Program and the next appropriate program number. The options available for this parameter are based on the tooling Number of Motions parameter defined on the Tooling menu under the Part Config menu.

The instrument will automatically manage the pre-test and post-test tooling extend and tooling retract motions. The user only needs to determine:

- a) The total number of motions needed (with the Number of Motions parameter on the Tooling menu within the Part Config menu).
- b) How many motions may change between each linked Child program (with the Link Motion Preempt parameter on the same Tooling menu).
- c) Which motions are to occur between linked Child programs (with the numbered Link Motion parameters on the Link menu under the Program Config menu).


The following rules define this operation:

1. The instrument will place Tooling Extend motions pre-test and Tooling Retract motions post-test up to the number of defined tooling motions.
2. If any path in the decision tree contains a Link Motion configured with a Tooling Extend, with no prior Link Motion configured as a Tooling Retract of the same motion number, the pre-test Tooling Extend motion will not execute.
3. Only those Tooling Extend motions that have been executed either pre-test or using a Link Motion, will have an associated Tooling Retract motion executed post-test.

### Advanced Tooling Motion Example 1


The instrument will attempt to extend all of the tooling motions at the beginning of the test unless there is a matching Link Motion number configured as Extend (obviously there is no reason to extend the same thing twice), thus the pre-test extend is preempted—in defining the link tooling the operator is dictating to the instrument the appropriate tooling sequence. If there is a Link Motion number configured as Retract, then later a Link Motion number configured as Extend of the same motion number, then it appears the operator intended the tooling to be extended at test start (as an operator, if you defined a retract, it is assumed you wanted the tooling to be extended beforehand). At the completion of the test, the instrument is aware of what tooling motions are currently extended, thus only the appropriate retracts will be executed.

The following example of **Parent Program Linking** has two tooling motions, with one link. The instrument automatically places appropriate Tooling Extend motions pre-test and Tooling Retract motions post-test. However, the operator configured a Link Motion as Tooling Extend 2, thus the instrument will not execute the pre-test Tooling Extend 2.



## Advanced Tooling Motion Example 2

Another example of a **Parent Program Linking** scenario (shown below) has three tooling motions, with two links. The instrument automatically places appropriate Tooling Extend motions pre-test and Tooling Retract motions post-test. Since the operator configured within Link 2 a Link Motion as Tooling Extend 2, the instrument will not execute the pre-test Tooling Extend 2. The operator configured within Link 1 a Link Motion as Tooling Retract 3, so the instrument will not execute the post-test Tooling Retract 3. Also, following Program 5 the instrument will not execute the post-test Tooling Retract 2, since the Tooling Extend 2 was never executed; however, after Program 3 and Program 4, the Tooling Retract 2 and Tooling Retract 1 will both be executed.



It is helpful when designing a **Parent Program Linking** test to diagram the desired part operation to appropriately define all the link parameters correctly to achieve the correct test sequence.

## Chapter 19 – Inputs and Outputs

*In this chapter the input and output (I/O) capability of the instrument is described. The I/O is defined by going to the Program Config menu and selecting the Input and Output Icons*

*Note: The instrument must be in Advanced or Admin mode in order to view and modify the Input and Output functionality. To change the Display User Level, see [Chapter 22](#).*

The instrument includes user selectable digital inputs and outputs to increase the functionality and simplify the application to various test requirements. The inputs and outputs are divided into two groups – Universal and Program Specific. When a Universal input or output is assigned in a program, it is automatically assigned and available within all programs. When a Program Specific input or output is assigned in a program, that particular input or output will be constrained to use only the inputs or outputs within the same Functional Group. When the input or output is set to “Constrained” in a program it will not function within that program.

In order to remove the selection of an input or an output, change the parameter to either Unassign or Unassign for all. Selecting “Unassign for all” will remove the selection of the input or output for all of the programs. Selecting “Unassign” will only remove the selection from the current program. “Unassign” is not available for Universal inputs or outputs.


## Input and Output Connector Pinout

The instrument comes equipped with 12 programmable sinking inputs and 12 programmable sourcing outputs. Both inputs and outputs are 24VDC. See Detail “A”.

Detail A


### DIGITAL INPUT/OUTPUT

1-6 (24VDC NOMINAL)




### DIGITAL INPUT/OUTPUT

7-12 (24VDC NOMINAL)



Detail B

JUMPER  
FACTORY  
POSITION  
FOR  
EXTERNAL  
POWER



SWITCH JUMPER  
POSITION FOR  
INTERNAL I/O  
POWER

The instrument is supplied with the option to elect to use the internal power for the I/O supply or an external supply. If an external supply is used, the I/O Factory Jumper is already set to “External I/O Power”. See I/O Jumper in “Detail B” above.

**Input Pinout and Wiring Table**

Input	Function	Wire Color	Connector Location	Instrument Connector	Cable Connector Pin	Wire Color
1	User Selectable	Black	Top (I/O A)	1	1	Black
2	User Selectable	Brown	Top (I/O A)	2	2	Brown
3	User Selectable	Red	Top (I/O A)	3	3	Red
4	User Selectable	Orange	Top (I/O A)	4	4	Orange
5	User Selectable	Yellow	Top (I/O A)	5	5	Yellow
6	User Selectable	Green	Top (I/O A)	6	6	Green
7	User Selectable	Black	Bottom (I/O B)	1	1	Black
8	User Selectable	Brown	Bottom (I/O B)	2	2	Brown
9	User Selectable	Red	Bottom (I/O B)	3	3	Red
10	User Selectable	Orange	Bottom (I/O B)	4	4	Orange
11	User Selectable	Yellow	Bottom (I/O B)	5	5	Yellow
12	User Selectable	Green	Bottom (I/O B)	6	6	Green

User selectable or programmable inputs are listed in a table on the next page.

**Output Pinout and Wiring Table**


Output	Function	Wire Color	Connector Location	Instrument Connector	Cable Connector Pin	Wire Color
1	User Selectable	Blue	Top (I/O A)	7	7	Blue
2	User Selectable	Violet	Top (I/O A)	8	8	Violet
3	User Selectable	Gray	Top (I/O A)	9	9	Gray
4	User Selectable	White	Top (I/O A)	10	10	White
5	User Selectable	Pink	Top (I/O A)	11	11	Pink
6	User Selectable	Light Green	Top (I/O A)	12	12	Light Green
7	User Selectable	Blue	Bottom (I/O B)	7	7	Blue
8	User Selectable	Violet	Bottom (I/O B)	8	8	Violet
9	User Selectable	Gray	Bottom (I/O B)	9	9	Gray
10	User Selectable	White	Bottom (I/O B)	10	10	White
11	User Selectable	Pink	Bottom (I/O B)	11	11	Pink
12	User Selectable	Light Green	Bottom (I/O B)	12	12	Light Green

User selectable or programmable outputs are listed in a table on **page 89**.

## I/O Power Pinout and Wiring Table

Function	Wire Color	Connector Location	Instrument Connector	Cable Connector Pin	Wire Color
IO Common	Red/Black	Top (I/O A)	20	20	Red/Black
IO Common	Orange/Black	Top (I/O A)	21	21	Orange/Black
IO Common	Yellow/Black	Top (I/O A)	22	22	Yellow/Black
IO Hot	Green/Black	Top (I/O A)	23	23	Green/Black
IO Hot	Gray/Black	Top (I/O A)	24	24	Gray/Black
IO Hot	Pink/Black	Top (I/O A)	25	25	Pink/Black
IO Common	Red/Black	Bottom (I/O B)	20	20	Red/Black
IO Common	Orange/Black	Bottom (I/O B)	21	21	Orange/Black
IO Common	Yellow/Black	Bottom (I/O B)	22	22	Yellow/Black
IO Hot	Green/Black	Bottom (I/O B)	23	23	Green/Black
IO Hot	Gray/Black	Bottom (I/O B)	24	24	Gray/Black
IO Hot	Pink/Black	Bottom (I/O B)	25	25	Pink/Black

## 25 Pin Digital IO Cable Diagram and Pinout Table



CTS Part Number: **KIT,CTS,A12-770** (includes 2 cables with hardware)

PIN ID	COLOR	FUNCTION	PIN ID	COLOR	FUNCTION
1	BLACK		14	BROWN/WHITE	
2	BROWN		15	RED/WHITE	
3	RED		16	ORANGE/WHITE	
4	ORANGE		17	GREEN/WHITE	
5	YELLOW		18	BLUE/WHITE	
6	GREEN		19	VIOLET/WHITE	

7	BLUE		20	RED/BLACK	
8	VIOLET		21	ORANGE/BLACK	
9	GRAY		22	YELLOW/BLACK	
10	WHITE		23	GREEN/BLACK	
11	PINK		24	GRAY/BLACK	
12	LIGHT GREEN		25	PINK/BLACK	
13	BLACK/WHITE		SHELL	DRAIN	

## Programmable Inputs and Outputs Menus

Input Options
Start Channel
Start Program
Stop/Reset
Hold
Vent/Halt
Program Cal
Open Leak Std
Part Present
SPC Test Part
Instrument Enable
Program Select B1
Program Select B2
Program Select B3
Program Select B4
Program Select B5
Program Select B6
Program Select B7
Common
Tool Ext Fdbk 1
Tool Ext Fdbk 2
Tool Ext Fdbk 3
Tool Ext Fdbk 4
Tool Ext Fdbk 5
Ext Press Sw
Event Trigger
Tool Ret Fdbk 5
Tool Ret Fdbk 4
Tool Ret Fdbk 3
Tool Ret Fdbk 2

Output Options
Malfunction
Tool Extend 1
Tool Extend 2
Tool Extend 3
Tool Extend 4
Tool Extend 5
In Relax
Program Cal Mode
Program Cal Master
Program Cal Leak Std
Press Select
Prefill
In Fill
Fill Valve
In Stabilize
Isolation Valve
In Test
Test Passed
Test Failed
Bellow LL
Between Lim
Above HL
In Exhaust
Program Accept
Program Reject
Severe Leak
Part Acc Mark
Part Rej Mark
Tool Retract 5

Tool Ret Fdbk 1
Unassign

Tool Retract 4
Tool Retract 3
Tool Retract 2
Tool Retract 1
Unassign

The Inputs and Outputs above are listed in their menu selection order. All the options may not be available, depending on the test type and the tooling control setting (On or Off and Number of Motions). Descriptions of these menu options are on the following pages are in related groups.

**Inputs for Program Control**

Input	Description
Start Channel	Starts the active Program
Common	The Start Channel and Common inputs are universal inputs, where each part program can be set individually to use “Two Inputs to Start” or “Anti-Tie-Down” logic.
Vent/Halt	The Vent/Halt input safely ceases the operation of any tooling motion, removes all energy from the part by advancing through the exhaust segment and stops operation. Any programmed tooling motion required to return to the fully retracted positions must be initiated by the Stop/Reset input. While the Vent/Halt input is high, no additional test activity or tooling resets can occur. See description below.
Start Program	Changes the Current Program to the one assigned to this input and Starts the Program.
Stop/Reset	The Stop/Reset input is available to stop tests and retract tooling. When a stop/reset input is received the test cycle goes immediately through a Vent/Halt routine and then advances to retract the tooling. The Malfunction output (if programmed) will go high at the end of the last tooling motion for errors defined as malfunctions. See description below.
Hold	The Hold input halts or suspends the testing sequence as long as this input is high. This can be used to stop the testing while awaiting some other action to occur.
Part Present	Enabled by selecting Part Present as one of the inputs, the Part Present input must be high before a start test input is received. It also must go low between tests (after any tooling motion and before the start of the tooling motion for the next test). If more than one input is set to “Part Present”, test will execute only if all inputs are made high.
Ex Press Sw	Enabled by selecting Ext Press Sw as one of the inputs, the External Pressure Switch input must go high before the end of the fill segment. This input is generally used to validate that the test part is properly charged by detecting pressure downstream of a potential blockage point. For Occlusion test type where fill segment is not present, Ext Press Sw input must go high before the end of the test segment. If Ext Press Sw input is not made high during test execution then a malfunction occurs. For more than one input of Ext Press Sw, test will execute only if all inputs are made high before test segment of Occlusion test and fill segment for other test types.

Instrument Enable	Enabled by selecting Instrument Enable as one of the inputs, the Instrument Enable input must be high before a start test input is received. If the input doesn't go high before executing any test, it shows the malfunction message. If the input goes low in between test execution then test aborts and shows malfunction message. For more than one input of Instrument Enable, test will execute only if all inputs are made high and test aborts with malfunction message if any one input is low or made low in between test execution.
-------------------	---

### ***Vent/Halt Request***

The design of a Vent/Halt request (including initial phase of the Stop/Reset request) is to cease operation of tooling motions, safely remove all energy from the part, and stop operation.

A Vent/Halt request operation has multiple operations depending on the state of the instrument while testing. For better understanding, the test sequence can be broken into three basic groups: Tooling Extend, Part Testing, and Tooling Retract. The Program Evaluation (Accept Program/Reject Program/Malfunction/Severe Leak) is always after the Tooling Retract.

Other than a user generated Vent/Halt input, several test errors will generate a Vent/Halt request. Possible scenarios include:

#### ***Vent/Halt – Instrument Idle***

While the instrument is idle, a high Vent/Halt input will prevent the instrument from performing any test activity or tooling reset. Any type of Start or Stop request will be ignored until the Vent/Halt input is low.

#### ***Vent/Halt – Instrument execution during Tooling Extend Group***

A Vent/Halt request will cause the output related to an executing Tooling Extend to be turned off. If the extend output is completed, it will remain in its current state. Since the part has not been charged no exhaust is necessary and execution will cease. A Tooling Reset is required.

#### ***Vent/Halt – Instrument execution during Part Testing Group***

A Vent/Halt request will cause the instrument to exhaust any pressure within the part (if pressure was achieved) and execution will cease. Any output relating to Tooling Extend will remain in its current state. A Tooling Reset is required.

#### ***Vent/Halt – Instrument execution during Tooling Retract Group***

A Vent/Halt request will cause the output relating to the current executing Tooling Retract to be turned off. Since the part has already been exhausted, execution will cease. A Tooling Reset is required.

### ***Stop/Reset Request***

The design of a Stop request is to safely remove all energy from the part, place the tooling into a fully retracted state, and stop operation. Depending on whether the instrument is actively testing or idle, the stop request has two modes of operations.

- If actively testing, a Stop request will cause the instrument to exhaust any pressure within the part (if pressure was achieved), and then execute a tooling reset sequence (only if tooling is enabled). The retract motion will be executed into a known retracted state for the next test.

#### Stop – Instrument Idle

- If the instrument is idle or in a safe state with the part pressure exhausted, a Stop request will cause the instrument to execute a tooling reset sequence (only if tooling is enabled). The retract motion will be executed into a known retracted state for the next test.

Besides a user generated Stop, several test errors will generate a Stop/Reset request that causes a Vent/Halt routine and continues with the tooling reset. The possible scenarios include: Transducer Malfunction (zero or over-range), External Switch Fault (not low or high at appropriate time), Severe Leak, Pressure Low/High, Calculation Faults, Calibration Errors, and General Program Fault (setup errors)

In addition, Stop/Reset input is required:

- After any tooling motion or test malfunction where the instrument completed Vent/Halt to safe state and stopped.
- Tooling must be reset to fully retracted position to start next test.

## Inputs for Program Selection

Input	Description	
Binary Program Selection	Programs can be remotely selected using the Binary Program Selection inputs or using one of the communication methods: RS232 or TCP/IP. The number of required inputs for Binary Program Selection depends on the highest program number of the program to which access is required.	
	Program Numbers	Binary Program Inputs
	1	B1
	2 – 3	B1 and B2
	4 – 7	B1, B2, and B3
	8 – 15	B1, B2, B3, and B4
	16 – 31	B1, B2, B3, B4 and B5
	32 – 63	B1, B2, B3, B4, B5, and B6
	64 – 99	B1, B2, B3, B4, B5, B6, and B7

*Note: Programs can also be remotely selected using one of the communication methods: RS232 or TCP/IP, see [Chapter 23 - Communication](#).*

## Inputs for Program Calibration

Input	Description
Program Cal	The Program Cal input prepares the instrument to perform a Program Cal sequence. A Start input initiates the tooling motion and Program Cal sequence.
Open Leak Std	The Open Leak Standard input will open the Leak Standard Calibration valve (if equipped) during the Fill, Stabilization, Test, and Exhaust segments. The valve will only open during the testing cycle when the input is high. If the input goes low during the testing cycle, the Leak Std Calibration valve will close. This input is generally used to automatically verify the calibration of a system by indexing or placing a good part in the test fixture and adding the internal leak standard to measure a part with the leak rate equal to the internal leak standard.

SPC Test Part	<p>The SPC Test Part input identifies the next part to test as an SPC Part (often used when performing a test calibration verification test with a leak standard). This input must be high when receiving the Start input. This will mark the test results in the program result with an “*”. Also, the test result output using the communication port will include the “*” to identify these parts for separate analysis.</p>
---------------	---

**Inputs for Tooling Motion**

Input	Description
Part Marking Feedback	<p>This input must go high as a response to the Part Mark (Accept, Reject, or Both) output within the Part Mark timer that starts at the end of the exhaust timer when the Part Mark output is initiated. The Part Mark Feedback input must be requested.</p> <ul style="list-style-type: none"> <li>• Part Config/TOOLING – “Part Mark” must be set for “Accept”, “Reject”, or “Both”.</li> <li>• Part Config/TOOLING – “Part Mark Feedback” set to “Yes”.</li> <li>• Part Config/INPUT – Part Mark Feedback assigned to a terminal.</li> <li>• Part Config/OUTPUT – “Part Acc Mark” and/or “Part Rej Mark” assigned to terminal(s)</li> <li>• Part Config/TIMER – Part Mark Timer set to a time.</li> </ul> <p>Failure to receive this input before the end of the Part Mark Fdbk timer will cause a Malfunction result and an “ERROR: PART MARK FAULT” display.</p>
Tool Ext Fdbk 1 – 5	<p>If enabled by selecting Tool Ext Fdbk #x as one of the inputs, it is required that the Tool Extend Feedback input go high before the associated Tool Ext Timer expires. If the timer expires before the input goes high the instrument will issue a malfunction. A Stop/Reset will need to be initiated to reset the tooling.</p>
Tool Ret Fdbk 1 – 5	<p>If enabled by selecting Tool Ret Fdbk #x as one of the inputs, it is required that the Tool Retract Feedback input go high before the associated Tool Ret Timer expires. If the timer expires before the input goes high the instrument will issue a malfunction. A Stop/Reset will need to be initiated to reset the tooling.</p>

## Outputs for Test Cycles

Output	Description
Press Select	Pressure Select goes high during the entire test sequence from start of Prefill or Fill segment to the end of Exhaust segment. <i>This output can be used as a Test Active output.</i>
Prefill	The Prefill output goes high during the Prefill portion of the Fill segment. This output is frequently used to control an external fast-fill valve when testing large volume parts. The external fast-fill valve opens until the instrument reaches the Minimum Pressure.
In Fill	The Fill segment output goes high during the Fill segment.
Fill Valve	This output mimics the Fill Valve functionality in the instrument. It goes high during the Prefill and Fill segments.
In Stabilize	The Stabilization segment output goes high during the Stabilization segment.
Isolation Valve	This output mimics the Isolation Valve functionality in the instrument. It goes high just prior to the fill valve closing and stays energized until the end of the Test segment.
In Test	The Test segment output goes high during the Test segment.
In Exhaust	The Exhaust segment output goes high during the Exhaust segment. This output is frequently used to open an external exhaust valve that vents the test air from the part through a larger valve for fast exhaust or to bypass the instrument and avoid polluting the instrument pneumatics with dirty part air.
In Relax	The relax timer output goes high during the Relax segment between the two tests of the Program Cal sequence. It would go high at the end of the first test Exhaust segment until the start of the second test Prefill or Fill segment. The Relax segment is also functional between tests in the Auto Setup routine.

## Outputs for Program Calibration

Output	Description
Program Cal Mode	The Program Cal Mode output goes high whenever the instrument is performing a Program Cal cycle. It goes high at the beginning of the Prefill or Fill timer for the first test of the Program Cal process. It stays high until the end of the Exhaust segment for the second test of the Program Cal Process.

Prog Cal Master	The Program Calibration Master output goes high during the first complete test of the Program Cal process starting at the beginning of the Prefill or Fill segment to the end of the Exhaust segment. This output is used to alert an external process that the instrument is in the first test of calibration.
Prog Cal LS	The Program Calibration Leak Standard output goes high during the second complete test cycle of the Program Cal process when the Leak Standard is added beginning with the Prefill or Fill segment to the end of the Exhaust segment. This output is used to alert an external process that the instrument is in the second test of calibration.

**Outputs for Program Results and Test Results**

Output	Description
Program Accept	The Program Accept output goes high at the completion of the tooling motion (if tooling is turned on) or at the completion of the Exhaust segment if the test passes.
Program Reject	The Program Reject output goes high at the completion of the tooling motion (if tooling is turned on) if the test fails. Program Rejects also include Severe Leaks when Minimum Pressure is not reached before reaching the Prefill setpoint or maintained during the Fill or Stabilization segments.
Malfunction	If a test has an error or disruption to the normal process and faults out of cycle before the normal completion, a malfunction will occur. With tooling control if the error or disruption occurs during initial tooling action, the tooling will retract. If the error or disruption occurs during the testing cycle, the test will advance immediately to exhaust and the tooling will retract automatically. The Malfunction output goes high at the end of the completion of the last tooling motion.
Severe Leak	If a test fails to reach Minimum Pressure before reaching the Prefill setpoint or fails to maintain at least the Minimum Pressure during the Fill and Stabilization segments, the instrument will exhaust the pressure in the part and output Severe Leak high.
Part Acc Mark	Part Acc Mark output stamps or marks a part as Accept based on the Part Result. This output goes high during the Part Mark Timer immediately at the end of the Exhaust timer.
Part Rej Mark	Part Rej Mark output stamps or marks a part as Reject based on the Part Result. This output goes high during the Part Mark Timer immediately at the end of the Exhaust timer.
Test Passed	Signals the completion of a test that passed at the start of the Exhaust segment. This output stays on until the start of a new test.
Test Failed	Signals the completion of a failed test at the start of the Exhaust segment. This output stays on until the start of a new test.
Below LL	Below Low Limit goes high at the start of Exhaust segment when test results are below the Low Limit setpoint and stays high until the start of the next test.
Between Lim	Between Limits goes high at the start of Exhaust segment when test results are between the Low Limit and High Limit setpoints and stays high until the start


	of the next test.
Above HL	Above High Limit goes high at the start of Exhaust segment when test results are above the High Limit setpoint and stays high until the start of the next test.

**Outputs for Tooling Motion**

Output	Description
Tooling Extend 1	This output goes high during the Tooling Extend 1 segment. This option is only available if Tooling is set to “On” or “Disabled”.
Tooling Extend 2	This output goes high during the Tooling Extend 2 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 2 or more.
Tooling Extend 3	This output goes high during the Tooling Extend 3 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 3 or more.
Tooling Extend 4	This output goes high during the Tooling Extend 4 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 4 or more.
Tooling Extend 5	This output goes high during the Tooling Extend 5 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 5 or more.


Output	Description
Tooling Retract 5	This output goes high during the Tooling Retract 5 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 5 or more.
Tooling Retract 4	This output goes high during the Tooling Retract 4 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 4 or more.
Tooling Retract 3	This output goes high during the Tooling Retract 3 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 3 or more.
Tooling Retract 2	This output goes high during the Tooling Retract 2 segment. This option is only available if Tooling is set to “On” or “Disabled” and the Number of Motions is equal to 2 or more.
Tooling Retract 1	This output goes high during the Tooling Retract 1 segment. This option is only available if Tooling is set to “On” or “Disabled”.

# Output Timing Diagram



## Tooling Example

The example below shows the power and flexibility of the Input and Output functionality. In this example the inputs and outputs are being used to seal two different types of parts. The two different parts have sealing ports in different locations. The part presence sensors select the program in the instrument that controls the proper hardware based on the current part in the sealing nest.



Parameters	Program #1	Program #2
Tooling Motion	On	On
Number of Motions	1	1
Part Present Check	On Start	On Start
Retract on Reject	No	No

Input	Hardware	Program #1	Program #2
Input 1	Start Button	Start Channel	Start Channel
Input 2	Stop Button	Stop/Reset	Stop/Reset
Input 3	Part Select Switch	Program Select B1	Program Select B1
Input 4	Part Select Switch	Program Select B2	Program Select B2
Input 5	Part Presence Sensor A	Part Presence	Constrained
Input 6	Part Presence Sensor B	Constrained	Part Presence

Output	Hardware	Program #1	Program #2
Output 1	Seal A Extend	Tool Extend 1	Constrained
Output 2	Seal B Extend	Constrained	Tool Extend 1


## Chapter 20 – Communication

*In this chapter the communication capability is described. The instrument has the capability to communicate over RS232 and/or Ethernet via TELNET*

The communication parameters are set by going to the main menu and selecting the Global Config icon.

### RS232 Connector Pinout

The pinout for the RS232 connector, located on the side of the I28, is denoted in the diagram below. Pins 1, 4, and 6 are internally connected, but are unused by the instrument.



1	DCD
2	RX
3	TX
4	DTR
5	Ground
6	DSR
7	RTS
8	CTS
9	Not Connected

### Establishing RS232 Communication

In order to set the RS232 parameters, select the RS232 1 or RS232 2 icon on the Global Config screen. The first step in establishing RS232 communication with the instrument is

to set the RS232 1 or RS232 2 Interface parameter to “2- way” communication. Next, select the baud rate that matches the baud rate of the device that will be communicating with the instrument. This is done via the RS232 1 or RS232 2 Baud parameter. The options are: 115200, 57600, 38400, 19200, or 9600 bits per second.

*Note: The instrument always uses 8 data bits. The Parity is set to “None”. The instrument uses 1 stop bit. The flow control is always set to “None”.*

Once you have established communication with the desired device you may select whether you would like the instrument to “echo” back each character it receives on the RS232 communication port. If the parameter RS232 1 or RS232 2 Echo is set to “On” the instrument will output an echo for each character, it receives. If this parameter is set to “Off” the instrument will not echo anything.

## Establishing Ethernet (TCP/IP) Communication via TELNET

It is highly recommended that you consult with your company’s IT department regarding the configuration of placing the instrument on any network.

In order to set the TCP/IP parameters select the TCP/IP icon on the Global Config screen. The first step in establishing Ethernet communication with the instrument is to determine whether the instrument should be setup using DHCP or a static IP Address. This is done via the Obtain Network Settings parameter. If you set this parameter to “Manual” then you will need to set the Instrument IP Address manually. If you chose DHCP the Instrument IP Address parameter will become a read-only parameter.

The Mail Server IP Address parameter should be set to the address of the SMTP mail server. You should get this information from your company’s IT department.

The Subnet Mask parameter will need to be configured next. The most common configuration for this parameter is “255.255.255.0 unless there is more than one subnet in which case a common configuration is “255.255.0.0.”

The Gateway IP Address is the default gateway of the network domain. You should get this information from your company’s IT department.

The MAC Address is the hardware address of the instrument. This number should not be changed.

Once you have established communication with the desired device you may select whether you would like the instrument to “echo” back each character it receives on the TCP/IP 1 communication port. If the parameter TCP/IP 1 Echo is set to “On” the instrument will output an echo for each character it receives. If this parameter is set to “Off” the instrument will not echo anything.

## Understanding the Header Information

All of the information that the instrument sends over the communication ports is preempted by header information. This data is sent to help parse specific information. This header information is in the format **XXYYZZZ H**. The header is followed by a Tab as shown in the table below:

Header	Description
XX	8-Bit CRC in HEX. Used for error checking.
YY	Sequence Code in HEX. The value increments from 01 to FF. This value can be used as a verification that all data has been received and nothing was missed by the receiving device.
ZZZ	Data length in HEX.
	Tab
H	Data Type Code. See Data Type Code Table
	Tab

Data Type Code	Description
V	Variable
L	List
M	Message
Q	Result List
T	Streaming Started
S	Streaming Value
X	Streaming Stopped
R	Result

*Note: For the most up to date data type codes type “TABLE HEADER” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

## Test Results via RS232 or Ethernet (TCP/IP) Communication

In order to command the instrument to send the test result data automatically once the test is complete the parameter RS232 1 OR RS232 2 Results or TCP/IP 1 Results (depending on which type of communication is being used) is set to “On.” Once this parameter is turned on, the Result Field data parameters show on the screen. Each parameter may be

turned on or off depending on the information that is required for to accompany each result. The Test Field parameter may be set to “All Result Information” or “First 2 Test Results.” The “First 2 Test Results” will send the two primary results. The table below shows the format of the Test Result Data.

Parameter	Number of Characters	Format	Example Text	Description of Example
Channel #	4	C##	C01	Channel 1
Port #	3	N#	N1	Port 1
Program #	4	P##	P01	Program 1
Link Information	4		R--	No Link
Time	13	HH:MM:SS.XXX	16:15:14.123	16 hours, 15 minutes, 14.123 seconds
Date	9	MM/DD/YY	40179	January 01,2010
Unique Id	11	#####	0000098353	Unique test number
Program Evaluation	3	#	A	Accept
SPC Flag	2	#	*	SPC Test Data Result
Barcode	41	1...40	12345	Barcode Data

Test Field	First 2 Test Results			
Test Type	8	###	PLR	Pressure Decay Leak Std
Test Evaluation	2	#	P	Pass
Test Data 1	22	TDI Data Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
Test Data 2	22	TDI Data Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
TAB				Tab
TAB				Tab
CR				Carriage Return
LF				Line Feed
Test Field	All Result Information			

Test Type	8	###	PLR	Pressure Decay Leak Std
Test Evaluation	2	#	P	Pass
Test Data 1	22	TDI Value Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
Test Data 2	22	TDI Value Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
Test Data X	22	TDI Value Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
TAB				Tab
TAB				Tab
CR				Carriage Return
LF				Line Feed

*Note: For the most up to date Test Data Identifier codes type “TABLE VARIABLE” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

*Note: For the most up to date Test Evaluation codes type “TABLE EVALUATION” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

*Note: For the most up to date Program Evaluation codes type “TABLE RESULT” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

## Streaming Measured Data

The instrument has the ability to stream measured data via either the RS232 or TCP/IP communication port (one or the other, not both simultaneously) in real time while the test is being conducted. This data may be collected and used for analysis. The data is comma delimited. The table below shows the format of the streaming data.

Parameter		Format	Example Text	Description of Example
Channel #	Comma Delimited	C##	C01	Channel 1
Program #	Comma Delimited	P##	P01	Program 1
Segment	Comma Delimited	XXX	PRF	Prefill Segment
Test Data	Comma Delimited	TDI Value Unit	LR 0.123456 sccm	Test Data Identifier - Value - Unit
TAB				Tab
TAB				Tab
CR				Carriage Return
LF				Line Feed

*Note: For the most up to date segment codes type “TABLE SEGMENT” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

*Note: For the most up to date Test Data Identifier codes type “TABLE VARIABLE” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

## Parsing Data Packets

For users who are trying to parse data packets from the instrument, any line beginning with an asterisk “\*” should be parsed to be ignored, as these lines will not have header information to be parsed. An example of these types of lines would be the Root Menu displayed at instrument boot.

## Reports

The instrument is capable of generating a variety of reports through RS232, Ethernet, Email, or USB memory port located on the front of the unit. The reports available are in the table below.

Report	Description
Cur Program Res	Reports all of the test results for the current active program. The current program can be seen in the bottom right hand corner of the display.
All Results	Reports all of the test results in the instrument memory.
Chan Last 1000	Reports the last 1000 test results.
Chan Last 100	Reports the last 100 test results.
Chan Last 20	Reports the last 20 test results.
Chan Last Res	Reports the last test result.
Global Config	Reports all of the parameters and their settings within the Global Config menu.
Channel Config	Reports all of the parameters and their settings within the Channel Config menu.
Cur Program Config	Reports all of the parameters and their settings within the current active program. The current program can be seen in the bottom right hand corner of the display.
Program Config	Reports all of the parameters and their settings within the Program Config menu.
Regulator Cal	Reports the Electronic Regulator Calibration data if the instrument is configured with an electronic regulator.
Transducer Ver	Reports the Transducer Verification data of the last Transducer Verification conducted on the instrument.
Transducer Cal	Reports the Transducer Calibration data of the last Transducer Calibration conducted on the instrument.
Channel Cntrs	Reports all of the counters in the instrument

## Chapter 21 – Security

*In this chapter the security parameters are described. The Security menu may be accessed on the Global Config Screen and selecting the Security Icon*

*Note: The Security Icon can be hidden. To view the Security Icon, go to the Global Config menu and select the Misc Icon. Go to the parameter Edit/View Security and turn it On.*

The default security mode of the instrument is set to use a key to unlock security. In the case where a password is desired to unlock security the default password is “5555.” It is important that this be changed upon configuring the password. Remember to write down the new password. If the new password is forgotten, Cincinnati Test Systems can provide a back-door password that changes every hour.

The table below describes the all of the levels of security available.

Parameter	Description	User Display Mode
Change Password	Edit allows the entry of a new password after entering old password	Basic Advanced, Admin
Secure Calibration	Applies security to performing a program calibration.	Basic Advanced, Admin
Secure Select Program	Applies security to changing test programs by pressing Change Program buttons.	Basic Advanced, Admin
Secure Program Config	Applies security to changing test part parameters.	Basic Advanced, Admin
Secure Global/Chan Config	Applies security to changing instrument configuration parameters.	Basic Advanced, Admin
Secure Clear Data	Applies security to clearing test result data from instrument.	Basic Advanced, Admin
Secure Reset Cntrs	Applies security to clearing the counter registers from instrument.	Basic Advanced, Admin
Secure Hold Function	Applies security to hold function.	Basic Advanced, Admin
Secure Reject Release	Applies security to protect releasing the part on a reject. This security option only works if retract on reject is set	Basic Advanced, Admin

Parameter	Description	User Display Mode
	to Off in the program's Tooling menu.	
Secure Monitor Screen	Applies security to the monitor screen. If set to Yes the user will not be able to view any other screens other than the last monitor screen viewed before being secured.	Basic Advanced, Admin
Backup/Restore	Allows the user to backup and/or restore various instrument settings. <i>Note: You must have the same manifold code to restore Channel Configuration.</i>	Basic Advanced, Admin

## Chapter 22 – Features

*In this chapter the features of the instrument are described.*

### Selecting the Display User Level

There are three user levels in the instrument. This is done to minimize the number of items shown on the screen for basic users. More advanced users requiring more features may view these by changing this parameter to the appropriate setting. Throughout the manual the parameter tables have denoted the display user level required for viewing and editing access. In order to change the viewing level, go to the Global Config menu and select the Misc menu. From the Misc menu change the parameter to the appropriate level. The three levels available are Basic, Advanced, and Admin.

*Suggestion: Set the Display User Level to the most basic level for your requirements. Parameters may be locked from editing. See Security parameters in [Chapter 21](#).*

### Setting the Date & Time

The date and time will be set at the factory. However, if you are located in a different time zone, it may be desirable to change the date and time on the instrument. This is done via the Global Config menu and selecting the Misc Icon. The Date and Time parameters may be modified. The date format is selectable via the Date Format parameter on the same menu. The time format is 24:00:00.

### Changing the Instrument Language

The instrument is a multi-language instrument. The language may be changed via the Global Config menu and selecting the Misc Icon. The Language may be modified.

*Note: The instrument must be in Advanced or Admin mode in order to view and modify the Instrument Language. To change the Display User Level, see [Chapter 22](#).*

## Copy & Paste Programs

In order to simplify the setup, the instrument comes with the ability to copy all of the parameters of a program to another program. This is easily done via the Program Config menu of the program you would like to copy. Select the Misc Icon and change the Copy to Target Prog parameter to the program number to “paste” the program. Then, change the Copy Program parameter to “Yes”.

*Note: This functionality will overwrite the parameters in the “paste” program location. Make sure you want to overwrite this program before executing. If the “paste” program exists, the instrument will prompt you to make sure you want to continue.*

## Instrument Backup & Restore

The Backup and Restore function of the instrument is a feature that allows you to backup all of your parameters onto a USB memory stick. The instrument will create a backup file on the USB memory stick. This can be used to restore the instrument back to its current state. There is no limit to the number of backup files you can have for an instrument. The files will be named using the following format: YYMMDD\_I-28\_SERIALNUMBER\_NUMBER. This will be stored in a folder called Backup-Restore.

*Note: NUMBER will increment for each backup done on the instrument on the same day.*

To execute this function go to the Global Config menu and select the USB Icon. Or you may use the USB quick button on the user interface of the instrument. Move the cursor down to the “Backup/Restore” parameter. Make sure a USB memory stick is placed in the USB port on the front of the instrument. Press the Enter button to activate the edit function and select “Backup Instrument.” When it is complete a pop-up window will inform you it was successful.

## Instrument Cloning

This function should only be executed under the advice of CTS personnel. This feature is used for service and support of our products. It enables a technician to replicate the exact instrument within our facility to help with any questions or concerns. To execute this function, go to the Global Config menu and select the USB Icon. Or you may use the USB quick button on the user interface of the instrument. Move the cursor down to the “Backup/Restore” parameter. Make sure a USB memory stick is placed in the USB port on the front of the instrument. Press the Enter button to activate the edit function and select “Instr Clone.” When it is complete a pop-up window will inform you it was successful.

## Adjusting the Light Bar Control

The lighting on the front of the instrument can be set to remain on indefinitely after a test, only remain on for 3 seconds (either all lights or only Accept/Reject), or it can be turned off completely. This parameter is set by going to the Global Config menu and selecting the Misc Icon. The Lighting Control parameter can be modified to one of these settings.

The brightness on the lighting may also be adjusted. This is done by changing the Lighting Brightness parameter on the same menu.

## Open Internal Leak Standard

If the instrument is configured with one or more internal leak standards these may be manually forced open during a test to simulate a leak in the test circuit. This may be done via the Open Leak Std parameter. This parameter may be modified by going to the Channel Config menu and selecting the Leak/Cal icon.

*Note: If the instrument is configured with an internal leak standard(s), the instrument automatically introduces the leak standard during the appropriate segments of a Program Cal routine.*

## Selecting the Proper Internal Leak Standard

If the instrument is configured multiple internal leak standards the user must select which leak standard is to be used in the Program. This parameter is set by going to the Program Config menu and selecting the Misc icon. The Leak Std Select parameter will define which leak standard is used. This must be set for each program utilized.

## Self-Test

The Self-Test diagnostic provides a way to check the integrity of the instrument's pneumatic circuit. This is a great way to quickly isolate a potential leak by allowing the user to verify the instrument is working correctly. By isolating the instrument from the test part and the external tooling and plumbing, this special test will verify that the instrument is performing properly and leak free.

To run a Self-Test diagnostic, go to the Channel Config menu and select the Self-Test Icon.

Parameter	Description	User Display Mode
Self-Test Pressure	Enter the pressure setting of the pressure source chosen to use for the Self-Test diagnostic routine.	Basic Advanced, Admin
Self-Test Source	Specifies the pressure source to utilize for the Self-Test diagnostic routine.	Basic Advanced, Admin
Self-Test Level	The instrument performs two levels of Self-Test. Level 1 is a general integrity test of the pneumatic circuit. Level 2 is more stringent and should be used when testing for low leak or flow rates.	Basic Advanced, Admin
Start Self-Test	Starts the diagnostic routine.	Basic Advanced, Admin

*Note: It is important that all test ports are plugged during a Self-Test. The instrument will multiplex through the test ports to verify all circuits are operating leak free.*

## Update Firmware

The instrument can update the firmware via the USB port on the front of the instrument. Upon a proper Service request, the file can be sent by an authorized CTS person via email for transfer to a USB memory stick. The file sent via email (for transfer to a USB memory stick), will be in a zip file formatted to create the proper folder structure on a USB memory stick. Once the file is on a USB memory stick, insert the stick into the front of the instrument. Press the USB button on the user interface for quick access to the USB menu. Change the parameter “Update Firmware” to “Yes” in order to start the update process. The instrument will list all of the firmware version files on the screen. Select which file you would like to use. This will start the update process.

*Note: If the firmware version is a minor revision all the parameter settings will be kept the same. However, if the firmware version is a major revision all the settings will be cleared. See the firmware documentation to determine if the firmware version you are upgrading from will cause the settings to be cleared.*

## Saving a Barcode with Results

*Note: The instrument must be in Advanced or Admin mode in order to view and modify the communication port functionality. To change the Display User Level, see [Chapter 22](#).*

The instrument has the capability to store barcode data with each test result. The instrument will work with any RS232 barcode scanner that can supply a barcode via an ASCII string (no longer than 40 characters) followed by a carriage return. The barcode information will need to be received before a Start command is received by the instrument. There is an option to make this data necessary for the Start command to be acknowledged.

In order to setup the barcode functionality go to the Global Config screen and select the RS232 1 Icon. Change the RS232 1 OR RS232 2 Interface parameter to “Barcode”. Then change the RS232 1 OR RS232 2 Baud parameter to set the baud rate of the barcode scanner communication.

*Note: The data bits are always configured to 8. The parity is always set to None. The number of stop bits is always set to 1. The flow control is always set to None.*

If a barcode is required before a start signal is acknowledged by the instrument, go to the Program Config menu and select the Misc Icon. Cursor down to the Barcode Required parameter and change it to “Yes”.

### Holding Pressure in the Part after Test (No Exhaust)

In some applications it is desirable to keep the pressure in the part once the test sequence is complete. It is easy to accomplish this by setting the Retain Part Press parameter to “Yes” in the instrument. This parameter is edited by going to the Program Config menu and selecting the Misc Icon. The instrument will retain the pressure until either the part is removed from the sealing fixture or a Stop signal is initiated.

*Note: The instrument must be in Advanced or Admin mode in order to view and modify this functionality. To change the Display User Level, see [Chapter 22](#).*

## Changing the Functionality of the Prefill Timer

When the Prefill Timer is set to a Percent of the Fill Timer, which is the default value, the Minimum Pressure must be met before the value in the Prefill is exhausted. For example, if the Fill Timer is set to 10 seconds and the Prefill Timer is set to 80% then the part must reach Minimum Pressure within 8 seconds. This allows for fixed fill times to be utilized.

When the Prefill Timer is set to a Not to Exceed Timer, the instrument will begin the cycle in the Prefill segment. Once the pressure reaches the Minimum Pressure, the instrument will exit the Prefill segment, regardless of any time remaining, and enter the Fill segment.

To change the function of the Prefill timer go to the Program Config menu and select the Misc Icon. The parameter called Prefill Method changes the Prefill functionality.

## Turning On/Off Pressure Correction

In several test types the instrument uses pressure correction to enhance the performance of the instrument. There are times where pressure correction may not be desirable. For these cases, the instrument has the ability to select whether pressure correction is used. To do this, select the Misc Icon on the Program Config menu. Change the Pressure Correction parameter to the desired setting.

## Setting the Cal Method and Leak Standard Location

This parameter, Cal Method, is located under the Leak/Cal screen under the Channel Config menu when the Leak Standard is set to “Channel”. It is located on the Misc screen under the Program Config menu when the Leak Standard is set to “Program”.

Select Parameter	Description	Explanation
<b>One Part – Int. LS</b>	Automatic test cycling using Leak Standard located inside the instrument	Automatically tests same non-leaking master part twice; the second time using a calibrated leak standard mounted on the internal pneumatic block.
<b>One Part - Ext LS</b>	Manual testing of same part using Leak Standard provided outside the instrument	Tests same non-leaking master part twice; the second time using calibrated leak standard provided externally from the instrument. The instrument will prompt the operator to attach the leak standard when it is time.

Select Parameter	Description	Explanation
<b>Multi-Part – Int. LS</b>	Manual testing of two parts using a Leak Standard located inside the instrument	Tests two different non-leaking master parts using the calibrated leak standard mounted on the internal pneumatic block. Any tooling must retract between tests to change parts. A Start signal is required either via the user interface or remotely using programmed start test logic to initiate the second test after changing non-leaking master parts.
<b>Multi-Part – Ext LS</b>	Manual testing of two parts using Leak Standard provided outside instrument	Tests two different non-leaking master parts using the calibrated leak standard provided externally from the instrument. Any tooling must retract between tests to change parts. A Start signal is required either via the user interface or remotely using programmed start test logic to initiate the second test after changing non-leaking master part with leak standard.

## Auto Run

Sometimes it is desired to have the instrument cycle automatically without any need for a person pressing the Start button or a start signal being received via the inputs. AutoRun is designed to accomplish this. This is done via the Program Config menu and selecting the Autorun Icon

Parameter	Description	User Display Mode
Autorun Relax	The amount of time the instrument pauses in between cycles.	Advanced, Admin
Autorun Method	There are two options for this parameter. "Standard" which runs a normal leak test every cycle or "LS on 3rd" which opens the internal leak standard (if supplied) every 3rd cycle.	Advanced, Admin
Autorun Cycle Count	The number of cycles left in the Autorun sequence. This parameter is used to determine how many cycles are conducted in an Autorun	Advanced, Admin
Autorun Enable	When this parameter is set to "Yes" a start command will initiate the Autorun sequence	Advanced, Admin

## Chapter 23 – Instrument Calibration

*In this chapter the set/span parameters are described. The Set/Span menu may be accessed on the Channel Configuration Screen and selecting the Set/Span Icon.*

*Note: Calibrations are always done using Test Port #1 (the test port on the left-hand side when facing the instrument)*

### Calibrating a Transducer

The transducers have been calibrated at the factory. A calibration of the transducer should be done periodically according to the quality standards at your facility. The instrument is capable of doing a multiple point calibration. The number of points is determined by the user. You may select up to 32 points for calibration. You will need a calibrated master pressure gauge in order to calibrate the transducer on the instrument. On the Set/Span menu select which transducer you would like to calibrate. Press Enter to enable the edit function. Change the value to “Yes.” The following menu will appear on the screen.

#### Transducer Cal 1 (Pressure)

Parameter	Description	User Display Mode
Number of Points	The number of setpoints to be used for the transducer calibration procedure. Value must be 2 to 32.	Basic Advanced, Admin
Setpoints 2–32	The user can define the setpoints at which the calibration occurs. The number of setpoints shown is based on the number of points selected in the parameter above	Basic Advanced, Admin
Linearity Limit	The maximum allowed linearity variance for a successful calibration	Basic Advanced, Admin
Start Calibration	Commences the calibration procedure. A wizard will walk you through the calibration process.	Basic Advanced, Admin

*Note: A Transducer Calibration Report may be downloaded from the instrument if desired. See [Chapter 20 Reports](#).*

**Transducer Cal 3 (Hard Vacuum)**

Parameter	Description	User Display Mode
Number of Points	The number of setpoints to be used for the transducer calibration procedure. Value must be 2 to 32.	Basic Advanced, Admin
Pressure Mode	Determines whether one pressure value is utilized for all setpoints or if individual pressure values are used for each setpoint when calibrating or verifying the transducer.	Basic Advanced, Admin
Setpoints 2–32	This parameter is visible if Pressure Mode is set to "Multi Pressure." The user is able to define the setpoints at which the calibration occurs. The number of setpoints shown is based on the number of points selected in the parameter above	Basic Advanced, Admin
Cal Pressure	This parameter is visible if Pressure Mode is set to "Single Pressure." It is the desired pressure for all setpoints when calibrating or verifying the transducer.	Basic Advanced, Admin
Pressure Correction	Allows the instrument to perform measurement corrections when calibrating or verifying the transducer based upon the relationship between the setpoint pressure and the actual measured pressure.	Basic Advanced, Admin
Linearity Limit	The maximum allowed linearity variance for a successful calibration	Basic Advanced, Admin
Start Calibration	Commences the calibration procedure. A wizard will walk you through the calibration process.	Basic Advanced, Admin

*Note: A Transducer Calibration Report may be downloaded from the instrument if desired. See [Chapter 20 Reports](#).*

**Verifying a Transducer**

The transducer verification process is very similar to the calibration process. You must enter the external master gauge value at each point to step through the sequence. You will be prompted to input values so the ***Transducer Verification Report*** has this data for later review. This feature does not affect the calibration of the instrument.

*Note: A Transducer Verification Report may be downloaded from the instrument if desired. See [Chapter 20 Reports](#).*

## Calibrating an Electronic Regulator

The electronic regulator has been calibrated at the factory. The instrument can do a multiple point calibration. The number of points is determined by the user. You may select up to 20 points for calibration. You will need a calibrated master pressure gauge in order to calibrate the electronic regulator on the instrument. On the Set/Span menu select which electronic regulator you would like to calibrate. Press Enter to enable the edit function. Change the value to “Yes.” The following menu will appear on the screen.

Parameter	Description	User Display Mode
Number of Points	The number of setpoints to be used for the transducer calibration procedure. Value must be 2 to 20.	Basic Advanced, Admin
Low Limit Voltage	The user is able to define the low voltage for the calibration process	Admin
High Limit Voltage	The user is able to define the high voltage for the calibration process	Admin
Start Calibration	Commences the calibration procedure. A wizard will walk you through the calibration process.	Basic Advanced, Admin

*Note: The Low Limit Voltage and High Limit Voltage values are disregarded if both are set to zero° (default state). You should only change these values if the instrument is not able to automatically analyze the electronic regulator range and perform a proper calibration.*

*Note: The electronic regulator can remain active in between instrument testing cycles or it can be set to be idle. This parameter is edited by going to Channel Config and selecting the Hardware Icon. The parameter is called “E-Regulator Rest”*

*Note: An Electronic Regulator Calibration Report may be downloaded from the instrument if desired. See [Chapter 20 Reports](#).*

## Chapter 24– Webserver

*The instrument provides a rich web server to control and configure the instrument. The Web Server can be used to display and update configuration, backup/restore instrument configurations, upgrade instrument firmware, and navigate remotely.*

### System Requirements

To use the Web Server, you must have the following:

- a TCP/IP-based network
- a web browser installed on your computer, preferably either Google Chrome 60.0X or Microsoft Internet Explorer 11.0X and above

*Note: The web server can be accessed from any operating system that supports the TCP/IP protocol and a web browser. You cannot view the embedded web server pages from outside a firewall.*

### Viewing the Web Server

Launch your web browser. In the Address or Go to field, type the IP address assigned to the instrument (for example: <http://192.168.1.1>). For more details on setting up the IP address on the instrument, refer to [Chapter 20](#) - Communication.

### Home Page

The top section will always display the Identity information (Instrument name, Firmware Version, Serial number, and MAC address) of the instrument. The Home page is shown in Figure 1.




Figure 1 Web page - Login Page

## Web Server Login

Once you click **Login**, the web server will prompt you for a User Name and Password. You must login with the appropriate username and password to access the webserver features. For more details on security, please refer to [Chapter 22](#) - Security.


A screenshot of a web browser's 'Authentication Required' dialog box. The dialog has a title bar with a close button (X). The text inside reads: 'Authentication Required', 'http://10.78.139.8 requires a username and password.', and 'Your connection to this site is not secure'. Below this text are two input fields: 'User Name:' followed by a text box, and 'Password:' followed by a password box. At the bottom right are two buttons: 'Log In' and 'Cancel'.

Figure 2 Security login

## Navigation - Web Server

The left section lists all available menus. Clicking a menu in the left section will update the right section with content for the selected menu.

CTS  
CINCINNATI  
TEST SYSTEMS

**TMII WEBSERVER**  
Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Logged In: (User)  
Logout  
Channel config  
Global config  
Part number 1-99  
< 1 >  
Program config  
Reports  
Navigation  
Backup Restore  
Firmware Update

Please choose a menu

Figure 3 Web Page - Main Page

The **Channel config** page allows you to configure Channel Config parameters for the instrument.

CTS  
CINCINNATI  
TEST SYSTEMS

**TMII WEBSERVER**  
Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Submit

CHANNEL CONFIG  
(Admin User Level)

HARDWARE

Pneumatic Code D  
Valve Code 1 P-24V  
Valve Code 2 P-24V  
Valve Code 3 P-24V  
Valve Code 4 P-24V  
Capability Code U  
Valve Detection Disabled  
Max System Pressure 120.000 psig  
Number of Options 3  
Option 1 Pressure Source 1  
Max Pressure - Opt 1 120.000 psig  
Option 2 Vacuum Source 2

Figure 4 Web Page - Channel Config

The **Global config** page allows you to configure Global Config parameters for the instrument.

CTS CINCINNATI TEST SYSTEMS

TMII WEBSERVER

Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Submit

Logged In: (User)

Logout

Channel config

Global config

Part number 1-99

Program config

Reports

Navigation

Backup Restore

Firmware Update

## GLOBAL CONFIG

(Admin User Level)

RS232 1

RS232 1 Interface: Leak Detector

Device Type: Inficon P3000

RS232 1 Baud: 9600/8N1/none

RS232 2

RS232 2 Interface: Serial Emulator

RS232 2 Baud: 9600/8N1/none

NETWORK

Figure 5 Web Page - Global Config

The **Program config** page allows you to configure Program Config parameters for the selected program. Use the arrow keys to select the desired program number.

CTS CINCINNATI TEST SYSTEMS

TMII WEBSERVER

Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Submit

Logged In: (User)

Logout

Channel config

Global config

Part number 1-99

Program config

Reports

Navigation

Backup Restore

Firmware Update

## PART 1 CONFIG

(Admin User Level)

TST TYPE

Test Type: Occlusion

Measures the Back Pressure (part blockage). Determined from the pressure at the end of the test timer. The result is presented in units of pressure.

TIMERS

Figure 6 Web Page - Program Config

The **Reports** page allows you to generate a variety of Reports for the instrument.




Figure 7 Web Page - Reports

The **Navigation** page gives you a similar user interface to the one available on the front display of the instrument.




Figure 8 Web Page - Navigation

The **Backup Restore** page allows you to generate a backup of the instrument, generate a backup of all programs, restore a backup, or restore all programs.

**CTS** CINCINNATI TEST SYSTEMS

**TMII WEBSERVER**  
Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Logged in: (User)  
Logout

Channel config  
Global config  
Part number 1-99  
Program config  
Reports  
Navigation  
Backup Restore  
Firmware Update

### Backup Instrument

Creates a backup file of all instrument settings (Channel/Global/Program Configuration). Use to create a full backup of all system configuration settings for future restore on the *same instrument only* (catastrophic recovery).

Backup Instrument

### Backup All Programs

Creates a backup file of all Program Configuration settings. Use to create a backup for future restore on any instrument (copy test settings to another device).

Backup Programs

### Restore File

Restore any previously generated backup file. Expected file extension: \*.bak or \*.pts

Choose File | No file chosen

Note: After restoration, instrument will reboot to apply settings.

Submit

Figure 9 Web Page - Backup/Restore

The **Firmware Update** page allows you to update the instrument's main controller firmware.

**CTS** CINCINNATI TEST SYSTEMS

**TMII WEBSERVER**  
Firmware Version: 201

Instrument name: TMII Station 1  
Serial number: 12345  
MAC Address: 001127045166

Logged in: (User)  
Logout

Channel config  
Global config  
Part number 1-99  
Program config  
Reports  
Navigation  
Backup Restore  
Firmware Update

### Update Instrument Firmware

Updates the instrument's main controller firmware. Expected file extension: \*.s19

Choose File | No file chosen

Note: After upload, the instrument will validate the firmware file, erase and program the flash memory, and then reboot. This process can take up to 5 minutes to complete.

**IMPORTANT: DO NOT REMOVE POWER DURING THE FIRMWARE UPDATE PROCESS!!**

Submit

Figure 10 Web Page - Firmware Update

## Parameter Configuration via Web Server

You can edit parameters listed on the right section of webpage. Editable parameters, once changed, are highlighted in yellow. After editing any parameter, you will need to click the “Submit” button at the top of the page to make the change on the instrument.


 <b>TMII WEBSERVER</b> Firmware Version: 201		Instrument name: TMII Station 1 Serial number: 12345 MAC Address: 001127045166	
<a href="#">Logged In (User)</a> <a href="#">Logout</a> <a href="#">Channel config</a> <a href="#">Global config</a>  Part number 1-99 <a href="#">Program config</a>  <a href="#">Reports</a>  <a href="#">Navigation</a>  <a href="#">Backup/Restore</a>  <a href="#">Firmware Update</a>	Max Pressure - Opt 1	<input type="text" value="120.000"/>	psig
	Option 2	<input type="text" value="Vacuum Source 2"/>	
	Max Pressure - Opt 2	<input type="text" value="20.000"/>	psig
	Option 3	<input type="text" value="None"/>	
	Transducer 1	<input type="text" value="CTS D34-444 515PSIA"/>	
	Transducer 3	<input type="text" value="Inficon PGE"/>	
	Regulator 1	<input type="text" value="Mechanical"/>	
	Regulator 2	<input type="text" value="Mechanical"/>	
	<b>SELF TST</b>		
	Self Test Pressure	<input type="text" value="50.000"/>	psig
Self Test Source	<input type="text" value="Pressure Source 1"/>		
Self Test Level	<input type="text" value="Level 1"/>		
Start Self Test	<input type="text" value="No"/>		
Clean Part Source	<input type="text" value="Vacuum Source 2"/>		
Clean Part Timer	<input type="text" value="0.25"/>	sec	
Start Clean Part	<input type="text" value="No"/>		
<b>SET/SPAN</b>			
Pressure Select	<input type="text" value="Pressure Source 1"/>		
Set Regulator	<input type="text" value="No"/>		

Figure 11 Web page - Editing parameters

## Chapter 25– Monitor Screen Examples

*This chapter is a quick reference for the screens that display at power on and when running the various tests established for your requirements.*

### Monitor Screen Examples

These screens are available by using the right arrow on the Arrow/Enter Navigation




Figure 1: Monitor 1 highlights the numerical pressure reading:




Figure 2 - Monitor 2 highlights the location of the reading from the Min to the Max allowable pressure




Figure 3- Graph highlights the pressure as it relates to time

*Note: You can zoom/adjust the graph by pressing the Enter button. A menu will display on the right side of the screen. Additional graph screen parameters are located in Main Menu > Global Config > Graph icon.*




Figure 4 - Hardware Input highlights which of the possible 12 inputs are engaged




Figure 5 - Hardware Output highlights which of the possible 12 outputs are engaged

## Chapter 26– Results Screen Examples

*This chapter is a quick reference for the screens that display when running the various tests established for your requirements. These are examples; your screens will display similar but different data.*

### Result Data Screens

*Counters Screen*

RESULT DATA	Stats	<COUNTERS>	Results
Cycles Since New			2
Accept Cycles			1
Reject Cycles			0
Malfunction Cycles			0
Accept Percentage		100.00 %	
Reject Percentage		0.00 %	
Clear Prog Counters			No
Clear Chan Counters			No
Clear Chan Results			No

➤ P01

*Results screen*

RESULT DATA	Results	<STATS>	Counters
➤Stat History Length			500
Accept Average	0.01570	Δpsig	
Reject Average	0.00000	Δpsig	
Accept Std Dev	0.00386	Δpsig	
Sample Size			4

➤ P01

*Stats Screen*

RESULT	DATA	Counters	<RESULTS>	Stats
P01:	01/09	09:07:19		ACCEPT
PL0	P	99.844 psig	0.01143Δpsig	
P01:	01/09	09:06:52		ACCEPT
PL0	P	99.649 psig	0.02032Δpsig	
P01:	01/09	09:06:09		ACCEPT
PL0	P	99.264 psig	0.01392Δpsig	
P01:	01/06	14:38:24		ACCEPT
PL0	P	98.749 psig	0.01715Δpsig	
↓P00:	01/06	14:36:02		ACCEPT

⚙️ P01

## Appendix A – Messages & Error Codes

*This chapter is a quick general reference for the test messages & error codes that appear on the screen and through the communication ports.*

*Note: For the most up to date test Messages & Error Codes list, type “TABLE EVALUATION” into the instrument via the communication port. The instrument will return a list of Data Type Codes and Descriptions.*

Message	Code	Description	Corrective Actions
Program Accept	A	Program evaluation was successful, for multiple tests – all tests passed.	
Auto Setup Seq Complete	AC	The Auto Setup Sequence is complete	
Program Calibration Failed	AF	The test type is one that is capable of conducting a program calibration and this sequence was not successful.	
Master Part Complete	AM	The test type is one that is capable of conducting a program calibration. The first phase of the sequence is complete.	
Program Calibration Passed	AP	The test type is one that is capable of conducting a program calibration and this sequence was successful.	
Error: Anti-tie Down	AT	The two inputs (Start and Common) are not held high during all of the “extend” tooling motions. There is no resultant output.	The two inputs must go high within 0.05 seconds and be held high until the end of all extend tooling motions.
Error: Barcode Req to Start	BR	The instrument was expecting a barcode value to be received over the RS232 port. The	Check barcode reader wiring and functionality.

Message	Code	Description	Corrective Actions
		configuration was set to require this action before a start command is enabled.	Make sure the Baud Rates are set properly within the instrument.
Master+Leak Loss<Master Loss	C1	During the Program Cal routine, the instrument measured a greater pressure loss for the master part by itself than for the master part with the leak in the second test. This results in a Malfunction.	Increase the stabilization and possibly test time.  Verify the leak standard.
Master Part Loss> Max Mstr+Leak Loss	C2	The pressure loss during the first test of Program Cal on the master part exceeded the Max Mstr+Leak Loss setpoint. This results in a Malfunction.	Check the seals and master part for leaks or extend stabilization timer. Check that Max Mstr+Leak Loss was correctly set.
Master +Leak Loss > Max Mstr+Leak Loss	C3	The pressure loss during the second test of Program Cal on the master part exceeded the Max Mstr+Leak Loss setpoint. This results in a Malfunction,	Check the seals and master part for leaks or extend stabilization timer. Check to leaks about leak standard.  Check that Max Mstr+Leak Loss was correctly set.
Master Flow>Max M+L Flow	C4	The flow value during the first sequence of Program Cal on the master part exceeded the Max Mstr+Leak Flow setpoint. This results in a Malfunction.	Check the seals and master part for leaks, or extend fill or test timers. Check that Max Mstr+Leak Flow was correctly set.
Master Flow<Min Master Flow	C5	The master flow value was less than the Min Master Flow setpoint	Check that the Min Master Flow setpoint was set correctly. Verify the test line is connected to the test port and not the Self-Test cap.
Master+Leak Flow>Max M+L Flow	C6	The flow value during the second sequence of Program Cal on the master part exceeded the	Check seals and master part for leaks or extend fill or test timers. Check

Message	Code	Description	Corrective Actions
		Max Mstr+Leak Flow setpoint. This results in a Malfunction.	the leak standard. Check that Max Mstr+Leak Flow was correctly set.
Master Flow>Max Master Flow	C7	The flow value during the first sequence of Program Cal on the master part exceeded the Max Master Flow setpoint. This results in a Malfunction.	Check the seals and master part for leaks or extend fill or test timers. Check that Max Master Flow was correctly set.
Master+Leak Flow<Master Flow	C8	The flow value during the second sequence of Program Cal on the master part was less than the Max Master Flow setpoint. This results in a Malfunction.	Check the seals and master part for leaks or extend fill or test timers. Check the leak standard. Check that Max Master Flow was correctly set.
Master Loss<Min Master Loss	C9	The pressure loss reading during the first test of Program Cal cycle for a pressure decay test was less than the Min Master Loss setpoint. This results in a Malfunction.	Check for blockage in the test line of part.
Cal Program Accept	CA	The Program Calibration was successful	
Calculation Error	CE	This result occurs from illegal program configurations, calculation errors when trying to convert vacuum pressures to positive pressure readings, and other occurrences.	
Cal Required - Limit Exceeded	CF	Not Used	
Charge Pressure High	CH	Charge Pressure High	
Charge Pressure Low	CL	Charge Pressure Low	
Min Perf Factor Error	CM	The Performance Factor calculated at the end of Program Cal exceeds the Minimum Performance Factor set in the Test Factors	Check that the Minimum Performance Factor was correctly set. Increase stabilize and

Message	Code	Description	Corrective Actions
			test timers
Chamber transducer Over-Range	CO	Chamber transducer Over-Range	
Calibration Required-Parameters Changed	CP	The stabilization or test timers, target pressure, Leak Std Flow, or Leak Std Pressure have been changed since the last calibration and therefore the part needs to be recalibrated. There is no output resultant.	Recalibrate the instrument for this program.
Cal Program Reject	CR	The Program Calibration was not successful.	
Chamber Evacuation Fault	CX	Measured Hard Vacuum pressure did not reached the specified level..	
DP Transducer Fault	DF	Not Used	
DP Transducer Over Range	DO	Not Used	
DP Transducer Zero Bad	DZ	Not Used	
Elec Regulator Cal Complete	EC	The Electronic Regulator Calibration was successful.	
Elec Regulator Cal Error	EE	The Electronic Regulator Calibration was not successful.	Check the wiring of the electronic regulator. Check that the entry of each pressure calibration point was correct.
Part Evac Fault	EF	Part failed to reach evacuation setpoint.	
Instrument not enabled	EI	Instrument not enabled	
Prog Error	EP	There was an error with the program. Contact Cincinnati Test Systems Service Dept.	
System Error - Service Req	ER	There was an error with the instrument Contact Cincinnati Test Systems Service Dept.	

Message	Code	Description	Corrective Actions
Chamber Pressure High	FC	Chamber Pressure High	
Flow Transducer Over Range	FO	The flow sensor measured a value out of its range. The instrument stopped the test sequence to prevent damage to the sensor.	
Error: Excessive Flow	FX	The flow sensor measured a value out of its range. The instrument stopped the test sequence to prevent damage to the sensor.	
Flow Transducer Zero Bad	FZ	The flow transducer was not sending the proper voltage. The instrument checks to make sure that the flow transducer is within range before the test sequence begins.	Check the flow sensor wiring. If this happens multiple times, replace the flow sensor.
Helium Background Fault	HF	Not Used	
Invalid Input configuration	IC	Invalid Input configuration	
Invalid Calibration Data	ID	The calibration data has been corrupted or not properly entered. Calibrate the unit again.	
Input initial state error	IE	Input initial state error	
I/O Fault	IF	I/O Fault	
Invalid I/O Configuration	IO	Invalid I/O Configuration	
Invalid Program Selected	IP	The program selected does not exist or has not been configured.	Check BCD Input programming
Chamber Rise Input Fault	IR	Chamber Rise Input Fault	
Isolation Failure	IS	Isolation Failure	
Chamber Crossover Input Fault	IX	Chamber Crossover Input Fault	
Error: Duplicate Target Link	LD	The same child program cannot be in the same link structure. If it is desired to conduct the	

Message	Code	Description	Corrective Actions
		same test twice you will need to copy the program.	
Leak Std Select Config Error	LE	Configuration Error. The instrument was not configured properly.	
Error: Link Execution Loop	LL	There was an error in the Linking Execution	Check programming of the Parent/Child Structures
Error: No Links Defined	LN	The instrument was expecting a link that did not exist	
Error: Dissimilar Link Order	LO	When the instrument conducts a Program Calibration sequence on linked programs, the links must execute in the same order for both the first and second sequences for Program Calibration.	
Error: Link Program is Parent	LP	A Parent Program may not be a link target.	
Error: Link Prog Undefined	LU	The linked program is undefined.	
Mass Spec Contamination	MC	Mass Spec Contamination	
Error: Part Mark Fault	MF	The part mark feedback input did not receive the input in time.	Check operation of the part marker. Check wiring of the feedback input. Check wiring of the valve to fire the part marker.
Man Fill Switch	MS	Man Fill Switch	
No Event Occurred	NE	In a test that is looking for an event, this is the result when one does not occur.	
Atmospheric Pressure Complete	OC	Atmospheric Pressure Complete	
Atmospheric Pressure Error	OE	Atmospheric Pressure Error	
Above Target	PA	The instrument will stop conducting a test if the	Check pressure regulator

Message	Code	Description	Corrective Actions
Pressure		pressure rises above the target pressure window setting.	setting, cut seals, bad parts, or tooling control pressure by testing with master part
Below Target Pressure	PB	The instrument will stop conducting a test if the pressure drops below the target pressure window setting.	Check pressure regulator setting, cut seals, bad parts, or tooling control pressure by testing with master part
Part Not Changed	PC	The present input signal did not go low between tests to indicate that the part was removed from the fixture after the last test. This results in a Malfunction.	Remove the part after each test.
Part Configuration Error	PE	Required digital inputs and outputs to support the test type are not defined.	Define each of the required outputs.
Part Not Full	PF	This is an error in the Auto Setup Sequence that can occur if the instrument fails to fill the part to the desired pressure.	
Test Pressure Low	PL	Test pressure was below Minimum Pressure during fill cycle. This results in a severe leak.	
Test Pressure High	PH	Test pressure was above the Maximum Pressure during fill or stabilization cycles resulting in a Malfunction	Check pressure regulator setting and tooling control pressures
Error: Part Not Present	pp	The part present input is set for the active program and the input was not received.	Check the part presence sensor and input wiring
Power Reset	PR	Power Reset	
Part Not Stabilized	PS	This is an error in the Auto Setup Sequence that can occur if the instrument fails to stabilize the part.	
Process Fault	PV	Process Fault	
Part Not Exhausted	PX	This is an error in the Auto Setup Sequence that can occur if the instrument fails to exhaust the part.	

Message	Code	Description	Corrective Actions
Sequence Complete	QC	Sequence Complete	
Program Reject	R	Program evaluation was not successful, for multiple tests – if any test fails, the part is rejected	
Part Reject - Level 1	R1	Not Used	
Part Reject - Level 2	R2	Not Used	
Part Reject - Level 3	R3	Not Used	
Chamber Rise Fault	RF	Measured Hard Vacuum Chamber pressure has risen above the Chamber Rise Fault pressure during test.	
Pre-Pressure High	RH	Pre-Pressure High	
Pre-Pressure Low	RL	Pre-Pressure Low	
Source Pressure Exceeded	RX	The source pressure set by the factory on the hardware configuration menu was exceeded.	
Stop Button Pressed	SB	The stop button or input was received	
Start Common Input Low	SC	Not Used	
Pressure Select Config Error	SE	Configuration Error. The instrument was not configured properly.	Check configuration of each pressure source.
Self-Test Failed	SF	The Self-Test failed	Make sure the test line was removed and the test port plugged before the test was conducted. One of the internal valves may be leaking.
Error: Stop Input High	SH	The instrument cannot start a test if the Stop input is high.	

Message	Code	Description	Corrective Actions
Stop Input Received	SI	Stop Input Received.	
Severe Leak	SL	Severe Leak indicates the test process did not achieve Minimum Pressure before reaching the Prefill setpoint or failed to maintain Minimum Pressure during fill or Stabilization timers. This results in a Program Reject.	Check pressure regulator setting, cut seals, bad parts, or tooling control pressure by testing with master part
Sniffer Mode Mismatch	SM	The Sniffer Mode does not match the TracerMate instrument configuration.	Check that mode configuration settings on both the TracerMate and the leak detector are compatible.
Sniffer Not Ready	SN	Sniffer Not Ready	Check the RS232 cable. Check Sniffer Type configuration. Check baud rate and port configuration.
Self-Test Passed	SP	Self-Test process indicates no internal leak	
Sniffer Not Ready Input Fault	SR	Sniffer Not Ready Input Fault	
Sniffer Type Mismatch	ST	The Test Part is configured for a different Sniffer Type than expected.	Confirm Sniffer Type configured in Global Config / RS232 1 / Sniffer Type and in Sniffer / Part Sniffer Type.
Sniffer Units Mismatch	SU	The Leak Detector configuration for Unit type does not match the TracerMate instrument configuration.	Check that tracer leak rate unit configurations match on TracerMate and leak detector.
System Pressure Exceeded	SX	The system pressure of the unit was exceeded.	Confirm the pressure sources are configured correctly, and that previously run tests have not left the manifold in a

Message	Code	Description	Corrective Actions
			pressurized state
T-Gas Background Fault	TB	The measured leak rate from the leak detector is above the maximum allowed tracer gas background level.	Take steps to reduce background tracer gas level. Adjust the Background limit to a higher value.
T-Gas Chamber Cleanup Fault	TC	The measured leak rate from the leak detector is above the maximum allowed during the Chamber Cleanup segment.	Remove tracer gas contamination from chamber. Adjust setpoint to higher value.
Tooling Not Reset	TE	If a tooling error occurs involving any motions, there will be a tooling error. Before the start of the next test, the tooling needs to be reset by the Stop/Reset input. This results in a Malfunction.	Push the Stop/Reset Input and possibly Common to return the tooling to the Start position.
T-Gas Part Fill Fault	TF	T-Gas Part Fill Fault	
Error: Two-Input Req to Start	TI	Both Start Test and Common must go high to start a test.	
T-Gas Leak Std Fault	TL	T-Gas Leak Std Fault	
T-Gas Min Leak Rate Fault	TM	The measured leak rate from the leak detector is below the minimum allowed for the test to continue.	Confirm the leak rate reported by the leak detector is accurate. See the Min T-Gas Mode description for other adjustment options.
Test Port Select Config Error	TP	The instrument configuration is not correct.	
Error: Tooling not Retracted	TR	The instrument may not start a sequence if all of the tooling is not retracted.	
Tooling Reset	TS	Most tooling errors or some test errors may require a tooling reset with the Stop/Reset input. After completion of the reset, this	

Message	Code	Description	Corrective Actions
		message appears.	
Error: Tooling not Extended	TX	If the instrument is configured for tooling feedback this error will occur if the tooling feedback input is not received within the time allocated.	Check feedback sensor and input wiring. Make sure the tooling motion feedback timer is set properly.
Valve Load Fault	VF	Valve Load Fault	
Weight Above Max	WA	Part Weight during part evaluation is above maximum.	Part Weight during part evaluation is above maximum.
Weight Below Min	WB	Part Weight in part evaluation is below minimum.	Part Weight in part evaluation is below minimum.
Scale Config Error	WC	The Test Part is configured for a different Scale Type than expected.	Confirm Scale Type configured in Global Config / RS232 1 / Scale Type and in Weight / Scale Type.
Scale Weight High	WH	The refrigerant source weight is above the minimum required starting weight.	Check refrigerant source container.
Scale Weight Low	WL	The refrigerant source weight is below the minimum required starting weight.	Check refrigerant source container.
Scale Not Ready	WR	The external Weigh Scale is not responding to communication requests from the TracerMate Instrument.	Check the RS232 cable. Check Scale Type configuration. Check baud rate and port configuration.
Scale Not Stable	WS	Scale weight not stable.	Check scale.
Vent Part Reset Tooling	VR	Message sent when retain part pressure and tooling are both configured to be used. This message is sent upon a reset.	
Transducer Cal Complete	XC	The transducer calibration is complete and was successful.	
Transducer Cal Error	XE	There was an error when trying to calibrate the transducer	Check transducer wiring

Message	Code	Description	Corrective Actions
Pressure Transducer Fault	XF	Not used	
External Switch did not go high	XH	The External Pressure Switch input did not go high before the end of the fill timer. This results in a Malfunction.	Check the pressure switch. Make sure that the path to the pressure switch is not blocked.
External Switch did not go low	XL	The External Pressure Switch input did not go low between tests. This results in a Malfunction.	Check pressure switch to make sure it is functioning.
Transducer Over Range	XO	During the testing process the pressure exceeded the range of the transducer. This results in a Malfunction.	Check the pressure regulator setting
Transducer Verify Complete	XV	The transducer verification sequence is complete.	
Transducer Zero Bad	XZ	The pressure transducer's atmospheric pressure reading at the beginning of the testing cycle is outside of tolerance. This results in a Malfunction.	Perform transducer calibration routine in Self-Test

## Appendix B - Environmental Drift Correction

*In this appendix you will understand the theory and parameters for implementing the Environmental Drift Correction feature.*

### How it works

*The environmental drift correction routine helps to maintain the calibration of the system by continuously monitoring and calculating a correction factor for changes in the test conditions. This routine dynamically compensates for slow changes in the test environment like room temperature changes, part temperature changes, test air temperature changes, part elasticity changes, part absorption characteristics, etc. These factors influence the dynamics of how the test part reacts to the testing process and the determination of the leak rate. "Environmental Drift Correction" defines how wide of a band around the Master Part Loss or Master Part Flow value will be considered as normal variations in flow rate for a non-leaking part. The "Environmental Drift Correction (+EDC %)" is based on High Limit. The instrument continuously calculates a running average of test results that fall within the band (EDC %) about the original non-leaking master part curve. It corrects each future result by the calculated drift determined from previous test results. The drift value is calculated as shown.*

$$\text{Environmental Drift Correction} = \frac{\sum n \text{ Flow}}{n} - \text{"Master Part Flow"}$$

Typical settings for "Environmental Drift Correction" are 10, 25, 50, and 90%. The sample size is set as EDC quantity (3 or greater). Flexible parts require a greater "Environmental drift correction" than rigid parts.

The "Environmental Drift Correction" effectively defines how much shift can occur. This limits the routine from continuing to compensate for possible growing leaks in the seal or test pneumatics.

TST Parameter	Description	User Display Mode
EDC Enable	Enables Environmental Drift Compensation	Advanced, Admin
EDC Percentage	Defines the band about the master part curve where test values are saved to calculate EDC drift. Set as a percentage of the High Limit parameter.	Advanced, Admin
EDC Quantity	Defines the number of test results within the EDC band used to calculate drift.	Advanced, Admin

## Appendix C – Leak Detector Support

LEAK DETECTOR	TracerMate II Device Type	Initial Version	Reference Page
Inficon P3000	LD-1001	(CS) 101	<a href="#">218</a>
Pfeiffer ASM142	LD-1003	(CS) 101	<a href="#">220</a>
Inficon ISH2000 Adixen ASH2000 Sensistor H2000 Sentrac	LD-1002	(CS) 101	<a href="#">222</a>
Agilent VS-MR15 (Varian)	LD-1011	(CS) 101	<a href="#">224</a>
Inficon LDS2010	LD-1009	(CS) 107	<a href="#">225</a>
Pfeiffer ASI20	LD-1006	(CS) 103	<a href="#">227</a>
Agilent PHD4	LD-1005	(CS) 107	<a href="#">230</a>
Pfeiffer ASI30	LD-1007	(CS) 106	<a href="#">229</a>
Agilent VS-C15 (Varian)	LD-1014	(CS) 104	<a href="#">232</a>
Inficon HLD5000	LD-1013	(CS) 103	<a href="#">233</a>
Licor LI-7000	LD-1015	(CS) 108	<a href="#">235</a>
Inficon LDS3000	LD-1009	(CS) 108	<a href="#">237</a>
Pfeiffer 182T	LD-1003	(CS) 108	<a href="#">220</a>
Oerlikon Leybold PhoeniXL300	LD-1016	(CS) 114	<a href="#">239</a>
Pfeiffer ASM340	LD-1003	(CS) 119	<a href="#">220</a>
VIC MD-490S	LD-1017	(CS) 123	<a href="#">241</a>
Inficon E3000	LD-1010	(CS) 128	<a href="#">242</a>
Ulvac Heliot900	LD-1018	(TM II) 206	<a href="#">244</a>
Pfeiffer ASM306S	LD-1003	(TM II) 206	<a href="#">220</a>

WEIGHT SCALE	TracerMate II Device Type	Initial Version	Reference Page
Ohaus 3000	WS-1001	(CS)106	<a href="#">Error! Bookmark not defined.</a>

## Inficon P3000

### Serial Interface Cable

The cable used for the P3000 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		P3000	
DB9-Female pins		DB9-Male pins	
RX	2-----2	TX	
TX	3-----3	RX	
GND	5-----5	GND	

Neither the TracerMate instrument nor leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Inficon P3000  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Inficon P3000  
Sample Gas Number                    1-4 to set the P3000 gas selection (default=1)

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                           Set desired leak detector unit for P3000 display and communication.

### Leak Detector Configuration

INTERFACES menu:

Control location:                      Local and RS232

RS232 Protocol: ASCII  
Baud Rate & End Sign: 9600 baud, CR+LF

## Operational Notes

1. If the P3000 is in Standby Mode at start of test the TracerMate II sends a wakeup command to the sniffer. The sniffer takes a few seconds to wake up before becoming ready for test. The length of the Sniff Init timer must be long enough to accommodate this wakeup time. The default TracerMate II setting is 5.5 and is usually sufficient.
2. The TracerMate II controls the P3000 settings for Gas Number and Leak Rate Units during test. On the TracerMate II, use the Sample Gas Number and Leak Det Units to control the settings on the sniffer that will be used. The sniffer's built-in display will change to show the selected gas number and units.
3. The P3000 automatically zeroes its internally leak rate measurement at unpredictable intervals. To prevent this from occurring during a sample time while testing, the TracerMate II sends a Zero command to the P3000 during the Cleanup segment. After the measured leak rate from the P3000 is below the TracerMate II Background Limit, the TracerMate II waits expiration of the Dev Zero Delay timer and then sends a \*ZERO command to the P3000. This feature is enabled by default but may be disabled using the Device Zero parameter in the Sniffer Menu.

## Adixen ASM 142 / Adixen ASM 182T

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines. This drawing shows the minimum requirements for a hand-built cable:

TracerMate II		ASM142
DB9F		DB9F
RX	2-----	3 TX
TX	3-----	2 RX
GND	5-----	5 GND
		/---4 DTR
		\---6 DSR
		--1 n.c.
		--7 RTS
		--8 CTS
		--9 +5V

The ASM142 expects DTR and DSR to be connected on its end of the cable. A standard null-modem cable normally does this. ASM142 supports both software and hardware handshaking. The TracerMate II does not use handshaking signals, so whether the connections are present in the cable does not matter.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 Interface                      Leak Detector  
Device Type                          Adixen ASM142  
RS232 2 Baud                        9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                              Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Adixen ASM142  
Device Mode                          HardVac Mode or Sniffer Mode to match sniffer configuration

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit/Precision	desired display leak rate units – unit used for TracerMate II display/streaming
Leak Det Unit/Precision	desired leak detector unit – same units as configured on the LD

## Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Must be set to RS232-Advanced Mode.
2. Set the leak detector's Handshaking options to NONE.
3. Set leak rate units as desired – must match the TracerMate II "Leak Det Unit".

The Sniffer's serial interface is fixed at 9600/8/n/1.

## Inficon ISH2000 / Adixen ASH2000 / Sensistor H2000 / Sensistor Sentrac

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines.

TracerMate II		ASH2000
DB9-Female pins		DB9-Female pins
RX	2-----3	TX
TX	3-----2	RX
GND	5-----5	GND

Neither device uses the RS232 hardware handshaking control signals. If these connections are present in the cable they are ignored.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Adixen ASH2000  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Adixen ASH2000  
Min T-Gas Mode                        Disabled (the LD always reports 0.0 until a minimum threshold is exceeded)

CHANNEL CONFIG – UNITS menu:

(if Channel Config “Unit/Prec Define” is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                            Set units value to match the Leak Detector units (and see note below).

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. General Settings / Printer Port = Analysis Data Output. Using the other modes will cause the leak detector to generate unwanted messages.
2. Test Port = Analysis Mode.

3. Leak Rate Units – The Leak Rate Unit displayed on the ASH2000 Leak Detector is simply a text string. It is not involved in any calculations and is not communicated to the TracerMate II. The relationship between the numeric value displayed on the LD and the actual leak concentration is determined by the “Calibration Coefficient” obtained during the ASH2000 calibration procedure. Set the Leak Rate Units on the ASH2000 and TracerMate II “Leak Det Unit” to the same units as the calibration reference.
4. The LD’s serial output is fixed at 9600/8/n/1.

## Operational Notes

1. The Leak Detector does not report its Leak Rate Units setting over the serial interface. Only the numeric value of the leak is reported to the TracerMate II. If the units on TracerMate II and ASH2000 do not match no fault is generated.
2. The Leak Detector’s accuracy is heavily influenced by its setting for “Leak Alarm Level”. The LD’s internal calculations are based on this value and affect both accuracy of the measurement and recovery time between measurements. Refer to the leak detector user manual’s Description of Parameters for the recommended settings of this and other LD variables.
3. The Adixen ASH 2000 has been tested only with the default probe that is supplied with the unit. Additional optional probes are available that allow probe specific programming of the Adixen unit for additional functionality. Use of these probes might result in changes affecting the communication protocol, and would need additional testing and possibly require TracerMate II firmware changes.

## Agilent VS-MR15

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines. This drawing shows the minimum requirements for a hand-built cable:

TracerMate II		VS-MR15	
DB9F		DB9F	
RX	2-----3	TX	
TX	3-----2	RX	
GND	5-----5	GND	

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 Interface	Leak Detector
Device Type	Agilent VS-MR15
RS232 2 Baud	9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                  Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                          Agilent VS-MR15

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit/Precision                  desired display leak rate units – unit used for TracerMate II  
display/streaming

Leak Det Unit/Precision                    desired leak detector unit – same units as configured on the LD

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set Leak Rate Units – must match the TracerMate II “Leak Det Unit”.

## Inficon LDS2010

### Serial Interface Cable

The cable used for the LDS2010 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		LDS2010
DB9-Female pins		DB9-Male pins
RX	2-----	2 TX
TX	3-----	3 RX
GND	5-----	5 GND

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Inficon LDS2010  
RS232 2 Baud                            19200/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Inficon LDS2010  
Device Mode                            Sniffer Mode/HardVac Mode (\*see below)

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                            Set desired leak detector unit for LDS2010 communication.

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set Control Location for RS232.
2. Set for ASCII protocol.
3. Set leak rate units to match the TracerMate II Leak Det Unit parameter.

## Operational Notes

1. The TracerMate II Device Mode parameter controls whether or not the TracerMate II sends \*START and \*STOP commands to the LDS3000 during test. If set to Sniffer Mode the commands are not sent. In HardVac Mode the \*START command is sent during the Sniff Init segment, and the \*STOP command is sent at the end of the test cycle.

## Adixen ASI20

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines. This drawing shows the minimum requirements for a hand-built cable:

TracerMate II		ASI20	
DB9F		DB9F	
RX	2-----3	TX	
TX	3-----2	RX	
GND	5-----5	GND	

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

#### GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

#### GLOBAL CONFIG – RS232\_2 menu:

RS232 Interface                      Leak Detector  
Device Type                          Adixen ASI20  
RS232 2 Baud                        9600/8N1/none

#### PROGRAM CONFIG – TEST TYPE menu

Test Type:                              Sniffer

#### PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Adixen ASI20  
Device Mode                          HardVac Mode or Sniffer Mode to match sniffer configuration

#### CHANNEL CONFIG – UNITS menu:

(if Channel Config “Unit/Prec Define” is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit/Precision            desired display leak rate units – unit used for TracerMate II  
   display/streaming  
Leak Det Unit/Precision              desired leak detector unit – same units as configured on the LD

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set Advanced -> Input/Output -> Serial Link #1 -> RS232
2. Set COM Serial Port Mode: ADVANCED
3. Set COM Serial Port handshake: NONE

4. Leak Rate Units – must match the TracerMate II “Leak Det Unit”.

## Adixen ASI30

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines. This drawing shows the minimum requirements for a hand-built cable:

TracerMate II		ASI30	
DB9F		DB9F	
RX	2-----	3	TX
TX	3-----	2	RX
GND	5-----	5	GND

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

#### GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

#### GLOBAL CONFIG – RS232\_2 menu:

RS232 Interface                      Leak Detector  
Device Type                          Adixen ASI30  
RS232 2 Baud                        9600/8N1/none

#### PROGRAM CONFIG – TEST TYPE menu

Test Type:                              Sniffer

#### PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Adixen ASI30  
Device Mode                          HardVac Mode or Sniffer Mode to match sniffer configuration

#### CHANNEL CONFIG – UNITS menu:

(if Channel Config “Unit/Prec Define” is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit/Precision              desired display leak rate units – unit used for TracerMate II  
   display/streaming  
Leak Det Unit/Precision                desired leak detector unit – same units as configured on the LD

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set Advanced -> Input/Output -> Serial Link #1 -> RS232
2. Set COM Serial Port Mode: ADVANCED
3. Set COM Serial Port handshake: NONE
4. Leak Rate Units – must match the TracerMate II “Leak Det Unit”.

## Agilent PHD-4

### Serial Interface Cable

The cable used for the Agilent PHD-4000 is a custom cable. The DB15 connector on the PHD-4 contains several signals unrelated to the serial port, so it is important that only the 3 pins used by the RS232 interface be connected on the DB15:

TracerMate II - DB9F	PHD-4 - DB15M(VGA)
RX – 2 – BLK	TX – 2 – GRN
TX – 3 – RED	RX – 3 – BLU
GND – 5 – BRN	GND – 5 – BLK

For reference, pinout of the DB15 on the PHD4:

1	Analog out (+)
2	RS232 TX
3	RS232 RX
4	Remote IN
5	RS232 GND
6	Analog out (-)
11	Relay 1 N.O.
12	Relay 2 N.O.
13	Relay 3 N.O.
14	Relay 4 N.O.
15	Relay common

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Agilent PHD4  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                        Agilent PHD4

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)  
Leak Rate Unit                            Set desired leak rate units for TracerMate II display/streaming data.

Leak Det Unit

Must be set to PPM. (\*see note 3 below)

### Leak Detector Configuration

1. Set Communications -> Remote Control -> RS232 Control
2. Set Communications -> Baud Rate -> 9600
3. Set Option -> Unit Measurement -> to match TracerMate II Leak Rate Units (TracerMate II display units). To avoid confusion the TracerMate II display and the sniffer display should be set to the same units. However, the PHD4 uses PPM for its communication interface regardless of the display setting - so the TracerMate II Leak Rate Unit must be PPM.
4. Setup -> Pump On checkbox must be turned on.

## Agilent VS-C15

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines. This drawing shows the minimum requirements for a hand-built cable:

TracerMate II		VS-C15	
DB9F		DB9F	
RX	2-----3	TX	
TX	3-----2	RX	
GND	5-----5	GND	

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 Interface                      Leak Detector  
Device Type                          Agilent VS-C15  
RS232 2 Baud                        9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Part Config Type                      Agilent VS-C15

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Inficon P3000

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit/Precision            desired display leak rate units – unit used for TracerMate II  
   display/streaming  
Leak Det Unit/Precision            desired leak detector unit – same units as configured on the LD

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set Leak Rate Units – must match the TracerMate II “Leak Det Unit”.

## Inficon HLD5000

### Serial Interface Cable

The cable used for the HLD5000 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		HLD5000
DB9-Female pins		DB9-Male pins
RX	2-----	2 TX
TX	3-----	3 RX
GND	5-----	5 GND

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface	Leak Detector
Device Type	Inficon HLD5000
RS232 2 Baud	9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                  Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                          Inficon HLD5000

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit	Set desired leak rate units for TracerMate II display/streaming data.
Leak Det Unit	desired leak detector unit – same units as configured on the LD.

### Leak Detector Configuration

Set up the HLD5000 configuration parameters using its menu interface:

1. Set Options -> RS232 -> Protocol to Normal.
2. Set Options -> RS232 -> Baud Rate to 9600.
3. Set Leak Units to match the TracerMate II Leak Det Units parameter.

## Operational Notes

1. User must wake the device from standby mode manually by moving the probe. The wakeup command may be enabled in a later TracerMate II version.

## Licor LI-7000

### Serial Interface Cable

The cable used for the LI-7000 is a standard Null-Modem cable with female DB9 connector at both ends. This cable swaps the Rx and Tx lines.

TracerMate II		LI-7000	
DB9-Female pins		DB9-Female pins	
RX	2-----3	TX	
TX	3-----2	RX	
GND	5-----5	GND	

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

#### GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

#### GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Licor LI7000  
RS232 2 Baud                            9600/8N1/none

#### PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

#### PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Licor LI7000  
Sample Gas Number                    1=CO2A, 2=CO2B, 3=CO2D (differential) (\*see notes below)

#### CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                           Set desired leak detector unit for P3000 display and communication.

### Leak Detector Configuration

Baud Rate is fixed at 9600 baud.

## Operational Notes

1. The Licor LI-7000 documentation refers to Cell A as the Reference Cell and Cell B as the Sample Cell. This is important if measuring in differential mode since the LD will calculate the differential measurement as  $\text{LeakDiff} = (\text{CellB} - \text{CellA})$ . If using differential mode measurements, always connect Cell A as the reference gas and Cell B as the sample gas.

## Inficon LDS3000

### Serial Interface Cable

The cable used for the LDS3000 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		LDS3000	
DB9-Female pins		DB9-Male pins	
RX	2-----2	TX	
TX	3-----3	RX	
GND	5-----5	GND	

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              LDS2010/3000  
RS232 2 Baud                            19200/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      LDS2010/3000  
Device Mode                            Sniffer Mode/HardVac Mode (\*see below)  
Sample Gas Number                    2 = Hydrogen, 4 = Helium

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                            Set desired leak detector unit for LDS3000 communication.

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Set for LDS2010 compatibility Mode.
2. Set for ASCII protocol.

3. Set leak rate units to match the TracerMate II Leak Det Unit parameter.
4. (Some menu/configuration changes on the LD may require a reboot of the device to take effect)

## Operational Notes

1. The TracerMate II Device Mode parameter controls whether or not the TracerMate II sends \*START and \*STOP commands to the LDS3000 during test. If set to Sniffer Mode, the commands are not sent. In HardVac Mode the \*START command is sent during the Sniff Init segment, and the \*STOP command is sent at the end of the test cycle.
2. A firmware upgrade will change existing tests using LDS2010/3000 to Gas Number = 1 and Device Zero = Disabled. The Gas Number will need to be changed according to the tracer gas in use for the particular leak detector (4 for Helium, 2 for Hydrogen).

## Oerlikon Leybold PhoeniXL300

### Serial Interface Cable

The cable used for the PhoeniXL300 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		XL300
DB9-Female pins		DB9-Male pins
RX	2-----	2 TX
TX	3-----	3 RX
GND	5-----	5 GND

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface	Leak Detector
Device Type	PhoeniXL300
RS232 2 Baud	19200/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                  Advanced Hard Vacuum / Basic Hard Vacuum / Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                          PhoeniXL300

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit	Set desired leak rate units for TracerMate II display/streaming data.
Leak Det Unit	Set desired leak detector unit for PhoeniXL300 communication.

### Leak Detector Configuration

Set up the sniffer configuration parameters using its menu interface:

1. Menu -> Settings -> Interface Menu -> Control Location = either "Local and RS232" or "RS232".
2. Menu -> Settings -> Interface Menu -> RS232 -> Baud & End Sign = 19200, CR+LF
3. Menu -> Settings -> Interface Menu -> RS232 -> RS232 Protocol = ASCII
4. Menu -> Settings -> Interface Menu -> RS232 -> Data Parity Stop = 8 N 1

5. Menu -> Settings -> Interface Menu -> RS232 -> Remote 1 / 2 Protocol = Automatic
6. Menu -> Trigger & Alarms -> Units -> Leak Rate = set to match units selected on TracerMate II
7. Menu -> Mode = Vacuum or Sniff

## Operational Notes

- 1.

## VIC MD-490S

### Serial Interface Cable

The serial cable is a standard NULL-MODEM cable with a female DB9 connector at each end. This cable swaps the Rx and Tx lines.

TracerMate II		ASH2000	
DB9-Female pins		DB9-Female pins	
RX	2-----3	TX	
TX	3-----2	RX	
GND	5-----5	GND	

Neither device uses the RS232 hardware handshaking control signals. If these connections are present in the cable they are ignored.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              VIC MD-490S  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                        VIC MD-490S

CHANNEL CONFIG – UNITS menu:

(if Channel Config “Unit/Prec Define” is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                            Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                              Set units value to match the Leak Detector units.

## Inficon E3000

### Serial Interface Cable

The cable used for the E3000 is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		E3000
DB9-Female pins		DB9-Male pins
RX	2-----	2 TX
TX	3-----	3 RX
GND	5-----	5 GND

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Leak Detector  
Device Type                              Inficon E3000  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                      Inficon E3000  
Sample Gas Number                    1-4 to set the E3000 gas selection (default=1)

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit                          Set desired leak rate units for TracerMate II display/streaming data.  
Leak Det Unit                            Set desired leak detector unit for E3000 display and communication.

### Leak Detector Configuration

INTERFACES menu:

Control location:                      Local and RS232  
RS232 Protocol:                        ASCII  
Baud Rate & End Sign: 9600 baud, CR+LF

## Operational Notes

1. The TracerMate II controls the E3000 settings for Gas Number and Leak Rate Units during test. On the Tracermate II, use the Sample Gas Number and Leak Det Units to control the settings on the sniffer that will be used. The sniffer's built-in display will change to show the selected gas number and units.

## ULVAC Heliot900

### Serial Interface Cable

The required RS232 cable for the ULVAC Heliot900 is straight through with female DB9s on both ends. This cable does not swap the Rx and Tx lines. (Note this is NOT a standard F-F Null-Modem cable, which swaps Rx and Tx lines).

TracerMate II		Heliot900	
DB9-Female pins		DB9-Female pins	
RX	2-----2	TX	
TX	3-----3	RX	
GND	5-----5	GND	

Neither the TracerMate II nor the leak detector uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either of the serial ports on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface	Leak Detector
Device Type	ULVAC Heliot900
RS232 2 Baud	9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                  Sniffer

PROGRAM CONFIG – SNIFFER menu:

Part Config Type                          ULVAC Heliot900

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Leak Rate Unit	Set desired leak rate units for TracerMate II display/streaming data.
Leak Det Unit	Set desired leak detector unit for E3000 display and communication.

### Leak Detector Configuration

SERIAL COMM./EXT I/O:

CONTROL:	SERIAL COMM.
COMPATIBILITY:	NONE
SERIAL COMM.:	RS232C
PRINTER:	OFF

RS232C BAUD RATE:    9600

## Ohaus 3000

### Serial Interface Cable

The cable used for the Ohaus 3000 scale interface is a standard straight-through Modem cable with a male DB9 connector at one end and female DB9 at the other. This cable does not swap the Rx and Tx lines. (Note this is not a Null-Modem cable, which swaps Rx and Tx lines and has female connectors on both ends).

TracerMate II		Ohaus 3000	
DB9-Female pins		DB9-Male pins	
RX	2-----2	TX	
TX	3-----3	RX	
GND	5-----5	GND	

Neither the TracerMate II nor the scale uses the hardware handshake lines so these are not required. If these connections are present in the cable, they are unused.

### TracerMate II Configuration

Either serial port on the TracerMate II can be used but TracerMate II Global Config must be configured to use the correct port. If the RS232\_1 is configured for the leak detector the vertical serial connector is used. If the RS232\_2 is configured use the horizontal connector.

GLOBAL CONFIG – MISC menu:

Display User Level                      Admin

GLOBAL CONFIG – RS232\_2 menu:

RS232 2 Interface                      Weigh Scale  
Device Type                              Ohaus 3000  
RS232 2 Baud                            9600/8N1/none

PROGRAM CONFIG – TEST TYPE menu

Test Type:                                Refrigerant Fill

PROGRAM CONFIG – WEIGHT menu:

Part Config Type                        Ohaus 3000

CHANNEL CONFIG – UNITS menu:

(if Chan Config Unit/Prec Define is set to Program, use the PROGRAM CONFIG – UNITS menu instead)

Weight Unit                                Set desired weight units for TracerMate II display and communication.

### Leak Detector Configuration

1. Use Factory default settings.

## Appendix E - Communication Code Tables

Each table can be generated within the communications interface by providing the associated command denoted.

### Data Type or Header Codes

Type "TABLE HEADER"

	Data Type Code	Description
1	V	Variable Edit
2	L	List
3	M	Message
4	Q	Result List
5	T	Streaming Started
6	S	Streaming Value
7	X	Streaming Stopped
8	R	Result Value

### Program Evaluation Codes

Type "TABLE RESULT"

	Program Evaluation Code	Description
1	P	TEST PASSED
2	F	TEST FAILED
3	E	TEST ERROR
4	S	TEST SKIPPED
5	X	TEST FAILED - LEVEL 1
6	Y	TEST FAILED - LEVEL 2
7	Z	TEST FAILED - LEVEL 3
8	M	AUTO-CAL MASTER PART
9	L	AUTO-CAL LEAK STANDARD PART
10	N	TEST FAILED - NO EVENT
11	C	TEST COMPLETE

## Test Evaluation Codes

type “TABLE EVALUATION”

Test Eval Code	Description
A	PROGRAM ACCEPT
AC	AUTOSETUP SEQ COMPLETE
AF	PROGRAM CALIBRATION FAILED
AL	MASTER+LEAK PART COMPLETE
AM	MASTER PART COMPLETE
AP	PROGRAM CALIBRATION PASSED
AT	ERROR: ANTI-TIE DOWN
BR	ERROR: BARCODE REQ TO START
C1	MASTER+LEAK LOSS<MASTER LOSS
C2	MASTER LOSS>MAX M+L LOSS
C3	MASTER+LEAK LOSS>MAX M+L LOSS
C4	MASTER FLOW>MAX M+L FLOW
C5	MASTER FLOW<MIN MASTER FLOW
C6	MASTER+LEAK FLOW>MAX M+L FLOW
C7	MASTER FLOW>MAX MASTER FLOW
C8	MASTER+LEAK FLOW<MASTER FLOW
C9	MASTER LOSS<MIN MASTER LOSS
CA	CAL PROGRAM ACCEPT
CE	CALCULATION ERROR
CF	CAL REQUIRED - LIMIT EXCEEDED
CH	CHARGE PRESSURE HIGH
CL	CHARGE PRESSURE LOW
CM	MIN PERF FACTOR ERROR
CO	CHAMBER XDCC OVER-RANGE
CP	CAL REQUIRED - PARAM CHANGED
CR	CAL PROGRAM REJECT
CX	CHAMBER EVACUATION FAULT
DF	DP TRANSDUCER FAULT
DO	DP TRANSDUCER OVER-RANGE
DZ	DP TRANSDUCER ZERO BAD
EC	ELEC REGULATOR CAL COMPLETE
EE	ELEC REGULATOR CAL ERROR
EF	PART EVAC FAULT
EI	ERROR: INSTRUMENT NOT ENABLED
EP	PROG ERROR
ER	SYSTEM ERROR - SERVICE REQ
F1	CLAM FLOW FAULT 1
F2	CLAM FLOW FAULT 2

Test Eval Code	Description
F3	CLAM FLOW FAULT 3
F4	CLAM FLOW FAULT 4
F5	CLAM FLOW FAULT 5
FC	CHAMBER PRESSURE HIGH
FO	FLOW TRANSDUCER OVER-RANGE
FX	ERROR: EXCESSIVE FLOW
FZ	FLOW TRANSDUCER ZERO BAD
HF	HELIUM BACKGROUND FAULT
IC	INVALID INPUT CONFIGURATION
ID	INVALID CALIBRATION DATA
IE	INPUT INITIAL STATE ERROR
IF	I/O FAULT
IO	INVALID I/O CONFIGURATION
IP	INVALID PROGRAM SELECTED
IR	CHAMBER RISE INPUT FAULT
IS	ISOLATION FAILURE
IX	CHAMBER CROSSOVER INPUT FAULT
L0	MASTER LOSS>MAX MASTER LOSS
L1	MASTER+LEAK LOSS<MIN M+L LOSS
L2	LEAK LOSS<MIN LEAK LOSS
L3	LEAK LOSS>MAX LEAK LOSS
L4	MASTER+LEAK FLOW<MIN M+L FLOW
L5	LEAK FLOW<MIN LEAK FLOW
L6	LEAK FLOW > MAX LEAK FLOW
LD	ERROR: DUPLICATE TARGET LINK
LE	LEAK STD SELECT CONFIG ERROR
LL	ERROR: LINK EXECUTION LOOP
LN	ERROR: NO LINKS DEFINED
LO	ERROR: DISSIMILAR LINK ORDER
LP	ERROR: LINK PROG IS PARENT
LU	ERROR: LINK PROG UNDEFINED
MC	MASS SPEC CONTAMINATION
MF	ERROR: PART MARK FAULT
MS	MAN FILL SWITCH
NE	NO EVENT OCCURRED
OC	ATMOSPHERIC PRESSURE COMPLETE
OE	ATMOSPHERIC PRESSURE ERROR
PA	ABOVE TARGET PRESSURE
PB	BELOW TARGET PRESSURE
PC	ERROR: PART NOT CHANGED
PE	PROGRAM CONFIGURATION ERROR

Test Eval Code	Description
PF	PART NOT FULL
PH	TEST PRESSURE HIGH
PI	SNIFFER PRESENT INPUT FAULT
PL	TEST PRESSURE LOW
PP	ERROR: PART NOT PRESENT
PR	POWER RESET
PS	PART NOT STABILIZED
PV	PROCESS FAULT
PX	PART NOT EXHAUSTED
QC	SEQUENCE COMPLETE
R	PROGRAM REJECT
R1	PART REJECT - LEVEL 1
R2	PART REJECT - LEVEL 2
R3	PART REJECT - LEVEL 3
RF	CHAMBER RISE FAULT
RH	PRE-PRESSURE HIGH
RL	PRE-PRESSURE LOW
RX	SOURCE PRESSURE EXCEEDED
S1	LD ZERO < MIN
S2	LD ZERO > MAX
S3	LD LEAK < MIN
S4	LD LEAK > MAX
SB	STOP BUTTON PRESSED
SC	START COMMON INPUT LOW
SE	PRESSURE SELECT CONFIG ERROR
SF	SELF-TEST FAILED
SH	ERROR: STOP INPUT HIGH
SI	STOP INPUT RECEIVED
SL	SEVERE LEAK
SM	SNIFFER MODE MISMATCH
SN	ERROR: SNIFFER NOT READY
SP	SELF-TEST PASSED
SR	SNIFFER READY INPUT FAULT
ST	SNIFFER TYPE MISMATCH
SU	SNIFFER UNITS MISMATCH
SX	SYSTEM PRESSURE EXCEEDED
TB	T-GAS BACKGROUND FAULT
TC	T-GAS CHAMBER CLEANUP FAULT
TE	ERROR: TOOLING NOT RESET
TF	T-GAS PART FILL FAULT
TI	ERROR: TWO-INPUT REQ TO START

Test Eval Code	Description
TL	T-GAS LEAK STD FAULT
TM	T-GAS MIN LEAK RATE FAULT
TP	TEST PORT SELECT CONFIG ERROR
TR	ERROR: TOOLING NOT RETRACTED
TS	TOOLING RESET
TX	ERROR: TOOLING NOT EXTENDED
VF	VALVE LOAD FAULT
VR	VENT PART RESET TOOLING
WA	WEIGHT ABOVE MAX
WB	WEIGHT BELOW MIN
WC	SCALE CONFIG ERROR
WH	SCALE WEIGHT HIGH
WL	SCALE WEIGHT LOW
WR	SCALE NOT READY
WS	SCALE NOT STABLE
XC	TRANSDUCER CAL COMPLETE
XE	TRANSDUCER CAL ERROR
XF	PRESSURE TRANSDUCER FAULT
XH	EXT SWITCH DID NOT GO HIGH
XL	EXT SWITCH DID NOT GO LOW
XO	TRANSDUCER OVER-RANGE
XP	EXTERNAL XDCR PRESS
XV	TRANSDUCER VERIFY COMPLETE
XZ	TRANSDUCER ZERO BAD

## Segment Codes

type “TABLE SEGMENT”

	Segment Code	Description
1	%VR	Percent of Reference Volume Test
2	APC	Setup - Atmospheric Pressure Check
3	AR	Autorun Relax
4	BAL	Stabilize DP Xdcr Balance
5	CBC	Chamber - blower control
6	CC0	Chamber - circulation off
7	CC1	Chamber - circulation on
8	CCX	Chamber - accumulation rest
9	CE0	Chamber - evacuate off
10	CE1	Chamber - evacuate on
11	CHA	Exhaust - Chamber Output Rest
12	CIF	Chamber - inlet blower off
13	CIO	Chamber - inlet blower on
14	CLN	Stabilize Chamber Cleanup
15	CO0	Chamber - outlet blower off
16	CO1	Chamber - outlet blower on
17	CP0	Chamber - pre-purge
18	CPC	Chamber - clamshell purge rings control
19	CPG	Chamber - Exh/Purge
20	CPO	Chamber - clamshell purge rings option
21	CPR	Chamber - clamshell purge rings rest
22	CST	Fill Clean
23	CV0	Chamber - vent off
24	DDL	Differential Pressure Decay - Leak Rate (volume calculated)
25	DDR	Differential Pressure Decay - Rate of Pressure Loss Test (no abs pressure)
26	DLY	Delay
27	DPD	Differential Pressure Decay Test
28	DPD	Differential Pressure Decay Test (no abs pressure)
29	DPL	Differential Pressure Decay - Leak Standard Test
30	DPL	Differential Pressure Decay - Leak Standard Test (no abs pressure)
31	DPS	Setup - DP Transducer Setpoint
32	DPT	Rate of Pressure Loss Test
33	DTV	Setup - DP Transducer Verification
34	DTZ	Setup - DP Transducer Zero
35	ERA	Setup - Electronic Regulator Analyze
36	ERS	Setup - Electronic Regulator Setpoint
37	ERZ	Setup - Electronic Regulator Zero

	Segment Code	Description
38	ESI	Internal - Empty-Seq
39	EST	Fill Evac
40	EXE	Exhaust until Empty
41	EXH	Exhaust
42	EXP	Exhaust until Pressure
43	EXT	Tooling Motion Extend
44	FFL	Fill until Full
45	FGN	General Fill
46	FLC	Mass Flow - Leak Rate Test
47	FLL	Fill (without pressure monitoring)
48	FLR	Precise Mass Flow Test (Differential Flow)
49	FLW	Mass Flow Test
50	FRF	Fill Reference
51	FRP	Fill Ramp
52	FST	Fill Tracer
53	FTS	Setup - Flow Transducer Setpoint
54	FTV	Setup - Flow Transducer Verification
55	FTZ	Setup - Flow Transducer Zero
56	HVC	Chamber - hardvac control
57	LKC	Link Control
58	LNK	Link Decision
59	MVX	Setup - Mix Verification
60	OCC	Occlusion Test (Backpressure)
61	PLO	Pressure Loss Test
62	PLR	Pressure Decay - Leak Standard Test
63	PMK	Tooling Part Mark
64	PRC	Prefill - Charge Volume
65	PRF	Prefill/Fill
66	PRF	Prefill until Pressure
67	PRF	Proof Test
68	PRI	Internal - Pre-Seq
69	PRI	Internal - Evaluate Part Result
70	PRP	Prefill Pre-Pressure
71	PRS	Step Proof
72	PSI	Internal - Post-Seq
73	PTS	Setup - Pressure Transducer Setpoint
74	PTV	Setup - Pressure Transducer Verification
75	PTZ	Setup - Pressure Transducer Zero
76	PVF	Pressure Verify
77	RCF	Refrigerant Iso Off
78	RCX	Refrigerant REF Isolation

	Segment Code	Description
79	REC	Exhaust - T-Gas
80	REF	Refrigerant Fill
81	RET	Tooling Motion Retract
82	REV	Exhaust - Re-Evacuate
83	RFE	Refrigerant Evac
84	RFM	Refrigerant Manual Fill
85	RFS	Stabilize Scale
86	RFT	Refrigerant Fill
87	RFX	Refrigerant Stabilize
88	RL	Calibration Relax
89	RPS	Refrigerant Part Switch
90	RTE	Ramp to Pressure Event Test
91	RTF	Ramp to Flow Event Test
92	RTI	Ramp to Digital Input Event Test
93	RVN	Refrigerant Vent
94	SCI	Setup - Scale Init
95	SD1	Setup - Sniffer idle
96	SDP	Stabilize Balance DP
97	SDP	Stabilize for DP
98	SFS	Stabilize Tracer
99	SGL	Fill Tracer Gross
100	SGS	Stabilize Tracer Gross
101	SI1	Setup - Sniffer Init
102	SI2	Setup - Sniffer Init 2
103	SLE	Tooling Seal Extend
104	SLR	Tooling Seal Retract
105	SME	Setup - Manifold Exhaust
106	SMF	Setup - Manifold Fill
107	SMI	Setup - Manifold Isolate
108	SNF	Sniffer Test
109	SNG	Sniffer Gross Test
110	SNW	Stabilize Tracer Wait
111	SPF	Fill Step
112	SPL	Setup - Pressure Select
113	SPR	Setup - Pre-Seq
114	SPS	Setup - Post-Seq
115	SSD	Stabilize Step Dwell
116	SSR	Setup - Set Regulator
117	STE	Stabilize Evac
118	STF	Stabilize for Flow
119	STG	General Stabilize

	Segment Code	Description
120	STR	Stabilize Reference Volume
121	STR	Setup - Transducer Residual
122	STS	Stabilize until Slope
123	SVD	Evac Test
124	SXT	Stabilize for Xdcr Test
125	TMC	Tooling Motion Control
126	XDR	Transducer Test

## Variable Codes

type “TABLE VARIABLE”

Variable Code	Description
%P	Percent Precision
2in	Two Inputs to Start
AAA	Accum Autozero
AAV	Accept Average
ACT	Auto-Cycle Tst Mode
AD	Analog A/D
AER	Permit Early Reject
ALR	Alt Leak Rate
APC	Accept Percentage
APC	Atm Pressure Check
APP	Accept Program
AQ	Average Quantity
ARC	Autorun Cycle Count
ARE	Autorun Enable
ARM	Autorun Method
ARR	Autorun Relax
ASA	Short Autozero
ASD	Accept Std Dev
ASM	AutoSetup Method
ASP	Accept SPC Std Dev
ATD	Anti-Tie-Down
AZD	Autozero Delay
AZE	Autozero Enable
Ain	Analog Input
Aot	Analog Output
BC	Batch Calibration
BCM	Barcode Method
BL	Batch Layout
BQ	Batch Quantity
BR	Barcode Required
CA	Accept Cycles
CAP	Calibrate Percent
CC	Configuration Code
CC	Capability Code
CCD	Ch Evac Valve Dly
CCP	Clear Prog Counters
CCR	Clear Chan Results
CCS	Clear Chan Counters

Variable Code	Description
CEF	Chmbr Evac Limit
CEV	Chmbr Evac Close
CFS	Cleanup Setpoint
CGP	Chmbr Pre-Purge
CGT	Chmbr Pre-Purge
CHM	Post-Purge Method
CHO	Chmbr Post-Purge
CHP	Chamber Pressure
CHV	Chamber Volume
CID	REF Iso Delay
CLF	Corr. Leak Std Flow
CLM	Clamshell
CLP	Check Limit Percent
CLR	Cumulative Leak
CLR	Cal Required
CM	$\Delta P$ Cal Method
CM	Malfunction Cycles
CMN	Clean Min Pressure
CMP	Charge Min Press
CMX	Maximum Pressure
COF	Continue on Fail
COL	Cutoff Limit
CP	Current Precision
CPP	Copy Program
CPR	Charge Pressure
CPS	TLR Change/Sec
CPT	Consecutive Points
CPT	Consecutive Points
CR	Reject Cycles
CRA	Clean Part Source
CRF	Pre-Purge
CRS	Chmbr Crossover
CSC	Cycles Since Cal
CSN	Clear Since New Ctr
CSN	Cycles Since New
CST	Custom Self Test
CT	Total Cycles
CTE	Continue to Evac
CTF	Continue to Fill
CTG	Target Pressure
CTP	Copy to Target Prog

Variable Code	Description
CTP	Charge Target Press
CTR	Clean Part Timer
CTX	Continue T-Gas Exh
CXP	Charge Max Press
DA	Analog D/A
DD	Decay Direction
DFL	Direct Flow
DHP	$\Delta$ Hard Vac Precision
DHU	$\Delta$ Hard Vac Unit
DKL	DP Leak Loss
DL	Diff Press Loss
DLL	DP Master+Leak Loss
DLR	Diff Press Loss Rd
DLT	Delay Timer
DML	DP Master Part Loss
DMR	DP Mstr Part Lss Rd
DP	Diff Pressure
DPI	DP iso Percent
DPP	$\Delta$ Press Precision
DVF	Vent During Fill
DVM	Test Mode
DVO	Device Mode
Dt	Date
ECL	ERC Crossover Limit
EDC	EDC Offset
EDE	EDC Enabled
EDP	Event $\Delta$ P
EDP	EDC Percentage
EDQ	EDC Quantity
EDT	Event $\Delta$ T
EIL	ERC Increment Limit
EM	Exhaust Method
EMP	Ext Xdcr Pressure
ENB	E-NOB
ENC	Enable Calibration
ENT	Enable Tooling I/O
EOL	ERC Offset Limit
EPP	Pressure Precision
EPR	Pressure Reference
EPV	Estimated Part Size
ERA	Atm Pressure

Variable Code	Description
ERC	ERC Method
ERE	ERC Enabled
ERP	ERC Rate/Period
ERQ	ERC Quantity
ERR	E-Regulator Rest
ERV	Re-Evac After Test
ESC	Ext Switch Low Chk
ESN	External Sniffer
ESP	Exhaust Setpoint
ET	Elapsed Time
ETP	Evacuation Setpoint
ETP	Fine T-Gas Target
ETW	ERC Target Window
ETW	ERC Target Window
ETY	Edge Type
EUP	Pressure Unit
EVA	Evacuation Source
EVC	Eval Condition
EVD	Vacuum Decay
EVL	Test Evaluation
EVM	Allow Evac Limit
EVP	Event Pressure
EVT	Event Type
EXD	Evacuation Xdcr
EXP	Execution Pause
FCC	Force Cal Cycles
FCD	FCal Date Limit
FCL	FCal Cyc Limit
FCM	Force Cal Mode
FCT	FCal Time Limit
FCT	Force Cal Time
FDC	T-Gas Fill Option
FEL	Flow Event Limit
FL	Flow
FLD	Fine T-Gas Decay
FLF	Fine T-Gas Fill
FMV	Finish Mix Verify
FNB	FF-NOB
FP	Flow Precision
FPR	Fill Pressure
FPS	Fine Sample

Variable Code	Description
FSW	Final Src Weight
FTA	Dwell
FTA	Fill
FTX	Test Failed Text
Fdb	Tooling Feedback
GLD	Gross T-Gas Decay
GLF	Gross T-Gas Fill
GLN	Gross T-Gas Min
GLT	Gross T-Gas Target
GLX	Gross T-Gas Max
GPS	Gross Sample
GPT	Gross Fill Pulse
HLE	High Limit Event
HLF	High Limit Flow
HLL	High Limit Loss
HLP	High Limit Pressure
HLQ	High Limit Leak
HLR	High Limit Rate
HLV	High Limit %Vref
HVP	Hard Vac Precision
HVU	Hard Vac Unit
I/O	I/O ID
IET	Event Type
IF	Instrument Flow
IIS	Input Initial State
ILS	Level State
ILT	Level Time
IPR	Close Inner Purge
IS	Input State
ISO	Isolation
LAV	Leak Alarm Volume
LCD	$\Delta$ P Leak Std/Cal Define
LCD	$\Delta$ P Leak Std Cal Date
LCF	Correction Factor
LDP	Leak Det Precision
LDT	Dev Zero Delay
LDU	Leak Det Unit
LDZ	Device Zero
LF	Master+Leak Flow
LFC	$\Delta$ P Leak Std Cal Flow
LFR	Master+Leak Flow Rd

Variable Code	Description
LIN	Linearity
LKF	Leak Flow
LKL	Leak Loss
LKM	Link Motion
LL	Master+Leak Loss
LLE	Low Limit Event
LLF	Low Limit Flow
LLL	Low Limit Loss
LLP	Low Limit Pressure
LLQ	Low Limit Leak
LLR	Master+Leak Loss Rd
LLR	Low Limit Rate
LLV	Low Limit %Vref
LMP	Link Motion Preempt
LNL	Linearity Limit
LOF	Loss Offset
LQ	Master+Leak QL
LQD	DP Mstr+Lk QL Rd
LQD	DP Master+Leak QL
LQF	Master+Leak QF Rd
LQF	Master+Leak QF
LQR	Master+Leak QL Rd
LR	Leak Rate
LRC	$\Delta P$ Leak Std Recert
LRO	Leak Rate Offset
LRO	Leak Rate Offset
LSC	$\Delta P$ Leak Std Chk
LSP	$\Delta P$ Leak Std Pressure
LSS	$\Delta P$ Leak Std Select
LSV	$\Delta P$ Leak Std Value
LV	Launch Validation
ME	Malfunction Eval
MF	Master Part Flow
MFO	Manual Fill
MFR	Master Part Flow Rd
MFT	Manual Fill
ML	Master Part Loss
MLF	Min Mstr+Leak Flow
MLF	Min Leak Flow
MLL	Min Leak Loss
MLR	Master Part Loss Rd

Variable Code	Description
MMF	Min Master Flow
MMF	Min Master Flow
MML	Max Master Loss
MML	Min Mstr+Leak Loss
MML	Min Master Loss
MNT	Min Tare Weight
MO	Master Flow Offset
MOR	Master Flow Offset
MPC	Malfunction Percent
MPF	Min Perform Factor
MPP	Max System Pressure
MQ	Master Part QL
MQD	DP Mstr Part QL Rd
MQD	DP Master Part QL
MQF	Master Part QF Rd
MQF	Master Part QF
MQR	Master Part QL Rd
MSL	Reject Rate
MSO	MS Iso Open Delay
MSP	Max Pressure - Opt
MSR	Mark Severe Lk Rej
MST	Mass Spec Purge
MTM	Min T-Gas Mode
MTS	T-Gas Source
MV	T-Gas Mix Verify
MVF	T-Gas Tgt Press
MVH	Leakrate High Limit
MVL	Leakrate Low Limit
MVM	T-Gas Leak Rate
MVS	Start Mix Verify
MVT	T-Gas Fill Timer
MXT	Max Tare Weight
Mot	Motion Number
Mot	Number of Motions
NAM	Program Name
NBC	Number of Barcodes
NLK	Number of Links
NOP	Number of Options
NPP	Next Program
NPS	Number of Steps
NTP	Sample Points

Variable Code	Description
NUM	Number of Programs
OLS	Open $\Delta$ P Leak Std
OPT	Option
OTL	Open T-Gas Leak Std
P	Master Gauge Press
P	Instrument Pressure
P	Meas Pressure
P%V	Part %Vref
PC	Pneumatic Code
PCL	$\Delta$ P Leak Std Cal Press
PCR	Pressure Correction
PCT	Chmbr Post-Purge
PDL	Press Delta Limit
PET	Part Evac Limit
PEV	Part Evacuation
PEX	Partial Exhaust
PF	Performance Factor
PFL	Part Flow
PFM	Prefill Method
PG	Target Pressure
PKP	Peak Pressure
PL	Pressure Loss
PLP	Predicted Loss
PLQ	Master+Leak Q-Press
PLR	Pressure Loss Rd
PLR	DP Mstr+Lk Loss Rd
PM	Part Mark
PM	Master Part Press
PMF	Part Mark Feedback
PML	Master+Leak Press
PMN	Minimum Pressure
PMQ	Master Part Q-Press
PMX	Maximum Pressure
PNM	Sniffer Test Point
PP	Proof Pressure
PP	Pressure Precision
PPC	Part Present Check
PPC	Prefill Press Check
PPE	Pre-Press Enable
PPR	Pre-Pressure
PPS	Pre-Press Select

Variable Code	Description
PPW	Pre-Pressure Window
PQ	Predicted Leak
PRF	Prefill
PRI	Programmable Input
PRO	Programmable Output
PRR	Pressure Restrict
PSL	Pressure Select
PSL	Pressure Select
PSL	Pressure Select
PSP	Setpoint Pressure
PST	Self Test Pressure
PSV	Part Sniffer Type
PT	Target Pressure
PTF	Prefill
PTG	Gross Prefill
PTP	$\Delta P/\Delta T$ Precision
PTS	Part Seal
PTS	Port Select
PTU	$\Delta P/\Delta T$ Unit
PTX	Test Passed Text
PW	Weight Precision
Pp	Part Pressure
Pr	Ref Pressure
Ps	Standard Pressure
Pt	Target Pressure
Pt	Apply to Program #
Pt	Program Number
Pt	Test Pressure
QF	Quik Flow
QHL	Quik Test HL Band
QL	Quik Loss
QLL	Quik Test LL Band
QP	Quik Test Pressure
QPT	Quantity Points
QTE	Quik Test Enable
RAN	Number of Points
RAP	Analysis Pressure
RAS	Analysis Voltage
RAT	Analysis Percent
RAV	Reject Average
RC	Elec Regulator Cal

Variable Code	Description
RC1	EReg Zero DA Cal
RC2	EReg Span DA Cal
RC3	EReg Zero Base Cal
RC4	EReg Span Base Cal
RCA	Analog Value
RCD	Last Cal Date
RCI	Instrument Pressure
RCP	Retention Cutoff
RCS	Setpoint Voltage
RCT	Last Cal Time
RCV	Master Value
RDI	Restore Default I/O
RDT	Reg Dwell Timer
RED	Refrgnt Vent Close
REG	Regulator
REO	Refrigerant Vent
REX	Refrigerant Vent
RFC	Fill Close Delay
RFL	Reference Loss
RL	Loss Rate
RLC	Run Leak Calibrate
RLR	Loss Rate Rd
RLV	T-Gas LeakStd Value
RMX	EReg Span DA Cal
RNP	Number of Points
ROS	Reject on Slope
RPC	Reject Percentage
RPM	Ramp Method
RPP	Reject Program
RPP	Retain Part Press
RR	Retract on Reject
RR	Ramp Rate
RRT	Reject Rate Total
RSI	Result Information
RSP	Slope Window
RSR	Slope Change/Sec
RST	Stabilize
RVH	High Limit Voltage
RVH	High Limit Voltage
RVL	Low Limit Voltage
RVL	Low Limit Voltage

Variable Code	Description
RVP	Retain Volume Press
RXM	Pre-Evac Exhaust
SAM	Sample Size
SAS	Start AutoSetup
SCF	Cal Coefficient
SCL	T-Gas LeakStd Value
SCO	Cal Offset
SCP	Start Clean Part
SCR	Reject Rate Percent
SCT	Scale Type
SDH	ST DP High Limit
SDL	ST DP Low Limit
SEV	Leak Rate Window
SF	Standard Flow
SGN	Sample Gas Number
SIO	Sniffer Init
SMP	Sample Time
SN	Step Number
SNR	SNR
SOD	Shut Off Delay
SP	Starting Pressure
SP	Standard Pressure
SPM	Fine Wait
SPT	Gross Wait
SR	Set Regulator
SRC	Start Calibration
SRH	LD Leak Val Max
SRH	ST RPL High Limit
SRL	LD Leak Val Min
SRL	ST RPL Low Limit
SSW	Starting Src Weight
STH	ST TPL High Limit
STL	Self Test Level
STL	ST TPL Low Limit
STM	Self Test Method
STN	Self Test Program
STP	Target Press
STS	Self Test Source
STS	Start Self Test
STT	Self Test Limit
STV	Step Target Press

Variable Code	Description
STW	Target Window
SXC	Start Calibration
SXT	Start Xdcr Test
SXV	Start Verification
SZH	LD Zero Val Max
SZL	LD Zero Val Min
Ser	Serial Number
Stn	Channel Number
T	Timer
T	Timer
TBF	LD Background Limit
TEP	T-Gas Exh Press
TGE	T-Gas Evaluation
TI	Iso Delay Timer
TL	Tooling Option
TLK	Test Leak Rate
TLP	Leak Rate Precision
TLR	T-Gas Leak Rate
TLU	Leak Rate Unit
TML	LD Min T-Gas Setpt
TMN	Fine T-Gas Min
TMP	Temp Precision
TMX	Fine T-Gas Max
TP	Time Precision
TPP	Target Program
TPW	Target Press Window
TQ	Quik Test Timer
TR1	Cleanup Delay
TRA	T-Gas Source
TRM	T-Gas Recovery
TSM	T-Gas Sampling
TT	Test Sel Timer
TT	Test Execution Time
TTF	TracerMate Flags
TTY	Test Type
TTY	Test Type
TV	Valve Delay Timer
TW	Target Weight
TWN	Min Fill Weight
TWX	Max Fill Weight
Tcy	Desired Cycle Time

Variable Code	Description
Tm	Time
Tm	Timer Mode
UC	Current Unit
UDP	$\Delta$ Pressure Unit
UF	Flow Unit
UP	Pressure Unit
UP	Percent Unit
UPD	Unit/Prec Define
UT	Time Unit
UTM	Temperature Unit
UV	Voltage Unit
UV	Volume Unit
UW	Weight Unit
V	V
VAN	Valve A Num - Opt
VAP	Valve A PWM - Opt
VAT	Valve A Type - Opt
VBN	Valve B Num - Opt
VBP	Valve B PWM - Opt
VBT	Valve B Type - Opt
VC	Valve Code
VCN	Valve C Num - Opt
VCP	Valve C PWM - Opt
VCT	Valve C Type - Opt
VDN	Valve D Num - Opt
VDP	Valve D PWM - Opt
VDT	Valve D Type - Opt
VFL	Virtual Flow
VHT	Vent/Halt Tooling
VLD	Valve Detection
VLP	Volume Precision
VLV	Valve Number
VNP	Number of Points
VP	Voltage Precision
VPS	Setpoint Pressure
VPW	Valve PWM
VSP	Setpoint Voltage
VTP	Hard Vac Setpoint
VWO	Residual Offset
Vi	Instrument Volume
Vp	Part Volume

Variable Code	Description
WGT	Refrigerant Weight
WHL	High Limit
WIN	Stat History Length
WLL	Low Limit
XAN	Xdcr Zero LL
XAX	Xdcr Base Max
XBH	Xdcr Zero Hwin
XBL	Xdcr Zero Lwin
XC	Transducer Cal
XC1	Xdcr Zero AD Cal
XC2	Xdcr Span AD Cal
XC3	Xdcr Zero Base Cal
XC4	Xdcr Span Base Cal
XCA	Analog Value
XCB	Atm Pressure
XCD	Last Cal Date
XCF	Instrument Flow
XCI	Instrument Pressure
XCL	Xdcr Curr Limit
XCM	Master Reading
XCP	Cal Pressure
XCS	Setpoint Pressure
XCT	Last Cal Time
XCV	Master Value
XCX	Xdcr Cal X Array
XCX	Xdcr Cal Y Array
XFC	Xdcr Filter Code
XFP	Flow Precision
XID	Xdcr Iso Delay
XIS	Xdcr Span Inter Cal
XIZ	Xdcr Zero Inter Cal
XLF	Max Leak Flow
XLF	Max Mstr+Leak Flow
XLL	Max Leak Loss
XMF	Max Master Flow
XML	Max Mstr+Leak Loss
XMN	Xdcr Base Min
XMN	Xdcr Base Max
XNP	Number of Points
XOP	Crossover Pressure
XPC	Pressure Correction

Variable Code	Description
XPM	Pressure Mode
XPP	Pressure Precision
XPR	Pressure Reference
XRL	Xdcr Residual Limit
XRW	Xdcr Residual Warn
XSP	Setpoint Pressure
XT	Transducer
XT	Xdcr Tare
XTG	Xdcr Tare Range
XTR	Xdcr Typ Residual
XUF	Flow Unit
XUP	Pressure Unit
XV	Transducer Verify
XVD	Verify Date
XVF	Instrument Flow
XVI	Instrument Pressure
XVM	Master Reading
XVS	Setpoint Pressure
XVT	Verify Time
XVV	Master Value
XZC	Xdcr Zero Check
XZH	Xdcr Zero HL
XZL	Xdcr Zero LL
XZW	Xdcr Zero Window
t	Test Time

# Technical Specifications

## Outside Physical Dimensions

Wall mount model (W x H x D): 16 x 16 x 8 (inches) 406 x 406 x 204 (mm)

## Electrical Specifications

Supply power: 100-240 VAC 50-60 Hz auto sensing/switching Input

power fuse: 3 Amp 250VAC, slow, 5X20MM, glass

I/O driver fuse: 1 Amp 250VAC, fast, 5X20MM, glass

Board fuse: 3.125 Amp 250VAC, fast, radial leads, plastic can, vertical plug in fuse Output

current limit for each output: 0.5-amp max

Output current limit for all outputs combined: 1-amp max

Instrument may operate at  $\pm 10\%$  of nominal voltage

## Environmental Factors

Operating temperature Range: 5°C to 40° C (41°F to 104°F)

Maximum humidity 90% relative humidity, non-condensing

Maximum operating altitude 2,500 meters (8,200 feet) Indoor use

only, IP20

## Inlet Ports & Connection Type

P1 1/4-18 FNPT or 1/4-19 BSPT fitting

1/4-18 FNPT or 1/4-19 BSPT fitting

1/8 FNPT or 1/8 BSPT fitting

Press 1/4-18 FNPT or 1/4-19 BSPT fitting

## Connection Type & Max Pressure Rating

Vacuum to 200 psi (1380 kPa) \* P2

Vacuum to 200 psi (1380 kPa) \* Pilot

65 to 105 psi (540 kPa to 725 kPa) Hi

0 to 500 psi (3450 kPa)

\* See label on instrument enclosure to determine whether port is for pressure or vacuum

## Air Cleanliness Specifications

Max Particulate Size: 0.3-micron

Max Dew Point: -30°C

Max Oil: 0.1mg/m<sup>3</sup>

## Recommended Filter Sets (available separately)

Small filter (includes 5.0-micron and 0.3-micron filters) for parts less than 300 ml

Medium filter (includes 5.0-micron and 0.3-micron filters) for parts from 300 ml to 13,000 ml Large

filter (includes 5.0-micron and 0.3-micron filters) for parts larger than 13,000 ml

Contact Cincinnati Test Systems Service Department

By phone 513-202-5108 or by email [service@cincinnati-test.com](mailto:service@cincinnati-test.com) 8am-5pm eastern US

For after-hours, 24/7 emergency phone support, call 513-202-5174